



TABLE OF CONTENTS

Ch	apter 1. Modules	1
	.1. Mathematical Functions	1
	.2. Single Precision Mathematical Functions	1
	acosf	2
	acoshf	2
	asinf	2
	asinhf	3
	atan2f	3
	atanf	4
	atanhf	4
	cbrtf	4
	ceilf	5
	copysignf	5
	cosf	5
	coshf	6
	cospif	6
	cyl_bessel_i0f	7
	cyl_bessel_i1f	7
	erfcf	7
	erfcinvf	8
	erfcxf	8
	erff	9
	erfinvf	9
	exp10f	9
	exp2f	.10
	expf	. 10
	expm1f	. 11
	fabsf	. 11
	fdimf	. 11
	fdividef	. 12
	floorf	.12
	fmaf	.13
	fmaxf	. 13
	fminf	. 14
	fmodf	. 14
	frexpf	. 15
	hypotf	.15
	ilogbf	16
	isfinite	. 16
	isinf	16

isnan	17
j0f	17
j1f	17
jnf	18
ldexpf	18
lgammaf	19
llrintf	19
llroundf	20
log10f	20
log1pf	20
log2f	21
logbf	21
logf	22
lrintf	
lroundf	22
modff	23
nanf	23
nearbyintf	
nextafterf	
norm3df	
norm4df	
normcdff	
normcdfinvf	
powf	
rcbrtf	
remainderf	
remquof	
rhypotf	
rintf	
rnorm3df	
roundf	
rsqrtf	
scalblnf	
scalbnf	
signbit	
sincosf	
sincospif	
sinf	
sinhf	
sinpif	
sqrtf	
tanf	
tanhf	
~~····································	J T

	tgammaf	.35
	truncf	. 35
	y0f	. 35
	y1f	. 36
	ynf	.36
1.	3. Double Precision Mathematical Functions	. 37
	acos	37
	acosh	.37
	asin	. 38
	asinh	38
	atan	. 39
	atan2	.39
	atanh	39
	cbrt	40
	ceil	40
	copysign	41
	cos	41
	cosh	41
	cospi	42
	cyl_bessel_i0	42
	cyl_bessel_i1	42
	erf	. 43
	erfc	43
	erfcinv	. 44
	erfcx	44
	erfinv	44
	exp	45
	exp10	45
	exp2	.46
	expm1	46
	fabs	46
	fdim	. 47
	floorfloor	.47
	fma	. 48
	fmax	48
	fmin	. 49
	fmod	49
	frexp	50
	hypot	.50
	ilogb	51
	isfinite	. 51
	isinf	51
	isnan	52

j0	52
j1	52
jn	53
ldexp	53
lgamma	54
llrint	. 54
llround	55
log	55
log10	55
log1p	56
log2	56
logb	57
lrint	57
lround	57
modf	58
nan	58
nearbyint	58
nextafter	59
norm3d	59
norm4d	60
normcdf	60
normcdfinv	60
pow	. 61
rcbrt	. 62
remainder	62
remquo	63
rhypot	. 63
rint	64
rnorm3d	64
round	. 64
rsqrt	65
scalbln	65
scalbn	66
signbit	. 66
sin	66
sincos	67
sincospi	67
sinh	68
sinpi	68
sqrt	68
tan	. 69
tanh	69
tgamma	70

trunc	70
y0	70
y1	71
yn	71
1.4. Single Precision Intrinsics	72
cosf	72
exp10f	72
expf	7 3
fadd_rd	7 3
fadd_rn	74
fadd_ru	74
fadd_rz	74
fdiv_rd	75
fdiv_rn	75
fdiv_ru	76
fdiv_rz	76
fdividef	76
fmaf_rd	77
fmaf_rn	77
fmaf_ru	78
fmaf_rz	78
fmul_rd	79
fmul_rn	79
fmul_ru	80
fmul_rz	80
frcp_rd	80
frcp_rn	81
frcp_ru	81
frcp_rz	82
frsqrt_rn	
fsqrt_rd	82
fsqrt_rn	
fsqrt_ru	83
fsqrt_rz	83
fsub_rd	84
fsub_rn	
fsub_ru	
fsub_rz	
log10f	85
log2f	
logf	
powf	
saturatef	

sincosf	87
sinf	88
tanf	88
1.5. Double Precision Intrinsics	89
ddiv_rd	89
ddiv_rn	89
ddiv_ru	89
ddiv_rz	90
drcp_rd	90
drcp_rn	91
drcp_ru	91
drcp_rz	91
dsqrt_rd	92
dsqrt_rn	92
dsqrt_ru	93
dsqrt_rz	93
1.6. Integer Intrinsics	93
brev	94
brevll	94
byte_perm	94
clz	95
clzll	95
ffs	95
ffsll	96
hadd	96
mul24	96
mul64hi	97
mulhi	97
popc	97
popcll	97
rhadd	98
sad	98
uhadd	98
umul24	99
umul64hi	99
umulhi	99
urhadd	100
usad	100
1.7. Type Casting Intrinsics	100
double2int_rz	101
double2ll_rz	101
double2uint_rz	101
double?ull_rz	102

_	_float2half_rn	102
_	_float2int_rd	102
_	_float2int_rn	103
_	_float2int_ru	103
_	_float2int_rz	103
_	_float2ll_rd	104
_	_float2ll_rn	104
_	_float2ll_ru	104
_	_float2ll_rz	105
_	_float2uint_rd	105
_	_float2uint_rn	105
_	_float2uint_ru	106
_	_float2uint_rz	106
_	_float2ull_rd	106
_	_float2ull_rn	107
_	_float2ull_ru	107
_	_float2ull_rz	107
_	_float_as_int	108
_	_half2float	108
_	_int2float_rd	108
_	_int2float_rn	109
_	_int2float_ru	109
_	_int2float_rz	109
_	_int_as_float	110
_	_ll2float_rd	110
_	_ll2float_rn	110
_	_ll2float_ru	111
_	_ll2float_rz	111
_	_uint2float_rd	111
_	_uint2float_rn	112
_	_uint2float_ru	112
_	_uint2float_rz	112
_	_ull2float_rd	113
_	_ull2float_rn	113
_	_ull2float_ru	113
_	_ull2float_rz	114
1.8	. SIMD Intrinsics	114
_	_vabs2	114
_	_vabs4	114
_	_vabsdiffs2	115
_	_vabsdiffs4	115
_	_vabsdiffu2	115
	vabsdiffu4	116

vabsss2	116
vabsss4	116
vadd2	117
vadd4	117
vaddss2	117
vaddss4	118
vaddus2	118
vaddus4	
vavgs2	119
vavgs4	119
vavgu2	119
vavgu4	120
vcmpeq2	
vcmpeq4	
vcmpges2	
vcmpges4	
vcmpgeu2	121
vcmpgeu4	122
vcmpgts2	122
vcmpgts4	122
vcmpgtu2	
vcmpgtu4	
vcmples2	123
vcmples4	124
vcmpleu2	
vcmpleu4	
vcmplts2	
vcmplts4	
vcmpltu2	125
vcmpltu4	126
•	
	
vhaddu2	127
vhaddu4	127
vmaxs2	
	
vmaxu2	128
vmaxu4	128
vmins2	129
	129
vminu4	
vneg2	

vneg4	130
vnegss2	131
vnegss4	131
vsads2	131
vsads4	132
vsadu2	132
vsadu4	132
vseteq2	133
vseteq4	133
vsetges2	133
vsetges4	134
vsetgeu2	134
vsetgeu4	134
vsetgts2	135
vsetgts4	135
vsetgtu2	135
vsetgtu4	136
vsetles2	136
vsetles4	136
vsetleu2	137
vsetleu4	137
vsetlts2	137
vsetlts4	138
vsetltu2	138
vsetltu4	138
vsetne2	139
vsetne4	139
vsub2	139
vsub4	140
vsubss2	140
vsubss4	140
vsubus2	141
vsubus4	141

Chapter 1. MODULES

Here is a list of all modules:

- Mathematical Functions
- Single Precision Mathematical Functions
- Double Precision Mathematical Functions
- Single Precision Intrinsics
- Double Precision Intrinsics
- ► Integer Intrinsics
- ► Type Casting Intrinsics
- SIMD Intrinsics

1.1. Mathematical Functions

CUDA mathematical functions are always available in device code. Some functions are also available in host code as indicated.

Note that floating-point functions are overloaded for different argument types. For example, the log() function has the following prototypes:

```
f double log(double x);
    float log(float x);
    float logf(float x);
```

1.2. Single Precision Mathematical Functions

This section describes single precision mathematical functions.

__host____device__ float acosf (float x)

Calculate the arc cosine of the input argument.

Returns

Result will be in radians, in the interval $[0, \pi]$ for x inside [-1, +1].

- ightharpoonup acosf(1) returns +0.
- \blacktriangleright acosf(x) returns NaN for x outside [-1, +1].

Description

Calculate the principal value of the arc cosine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float acoshf (float x)

Calculate the nonnegative arc hyperbolic cosine of the input argument.

Returns

Result will be in the interval $[0, +\infty]$.

- acoshf(1) returns 0.
- ▶ acoshf(x) returns NaN for x in the interval $[-\infty, 1)$.

Description

Calculate the nonnegative arc hyperbolic cosine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host___device__ float asinf (float x)

Calculate the arc sine of the input argument.

Returns

Result will be in radians, in the interval $[-\pi/2, +\pi/2]$ for x inside [-1, +1].

- ightharpoonup asinf(0) returns +0.
- asinf(x) returns NaN for x outside [-1, +1].

Calculate the principal value of the arc sine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float asinhf (float x)

Calculate the arc hyperbolic sine of the input argument.

Returns

asinhf(0) returns 1.

Description

Calculate the arc hyperbolic sine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float atan2f (float y, float x)

Calculate the arc tangent of the ratio of first and second input arguments.

Returns

Result will be in radians, in the interval $[-\pi, +\pi]$.

▶ atan2f(0, 1) returns +0.

Description

Calculate the principal value of the arc tangent of the ratio of first and second input arguments y / x. The quadrant of the result is determined by the signs of inputs y and x.



__host____device__ float atanf (float x)

Calculate the arc tangent of the input argument.

Returns

Result will be in radians, in the interval $[-\pi/2, +\pi/2]$.

ightharpoonup atanf(0) returns +0.

Description

Calculate the principal value of the arc tangent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float atanhf (float x)

Calculate the arc hyperbolic tangent of the input argument.

Returns

- atanhf(± 0) returns ± 0 .
- ▶ atanhf(± 1) returns $\pm \infty$.
- ▶ atanhf(x) returns NaN for x outside interval [-1, 1].

Description

Calculate the arc hyperbolic tangent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float cbrtf (float x)

Calculate the cube root of the input argument.

Returns

Returns $x^{1/3}$.

- cbrtf(± 0) returns ± 0 .
- cbrtf($\pm \infty$) returns $\pm \infty$.

Calculate the cube root of x, $x^{1/3}$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float ceilf (float x)

Calculate ceiling of the input argument.

Returns

Returns [x] expressed as a floating-point number.

- ceilf(± 0) returns ± 0 .
- ceilf($\pm \infty$) returns $\pm \infty$.

Description

Compute the smallest integer value not less than x.

__host____device__ float copysignf (float x, float y)

Create value with given magnitude, copying sign of second value.

Returns

Returns a value with the magnitude of x and the sign of y.

Description

Create a floating-point value with the magnitude x and the sign of y.

__host____device__ float cosf (float x)

Calculate the cosine of the input argument.

Returns

- ightharpoonup cosf(0) returns 1.
- ▶ $cosf(\pm \infty)$ returns NaN.

Description

Calculate the cosine of the input argument x (measured in radians).



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float coshf (float x)

Calculate the hyperbolic cosine of the input argument.

Returns

- coshf(0) returns 1.
- $\cosh(\pm \infty)$ returns NaN.

Description

Calculate the hyperbolic cosine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float cospif (float x)

Calculate the cosine of the input argument $\times \pi$.

Returns

- cospif(± 0) returns 1.
- ▶ cospif($\pm \infty$) returns NaN.

Description

Calculate the cosine of $x \times \pi$ (measured in radians), where x is the input argument.



__host____device__ float cyl_bessel_i0f (float x)

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument.

Returns

Returns the value of the regular modified cylindrical Bessel function of order 0.

Description

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument x, $I_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float cyl_bessel_i1f (float x)

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument.

Returns

Returns the value of the regular modified cylindrical Bessel function of order 1.

Description

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument x, $I_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float erfcf (float x)

Calculate the complementary error function of the input argument.

Returns

- erfcf($-\infty$) returns 2.
- erfcf($+\infty$) returns +0.

Calculate the complementary error function of the input argument x, 1 - erf(x).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float erfcinvf (float y)

Calculate the inverse complementary error function of the input argument.

Returns

- erfcinvf(0) returns $+\infty$.
- erfcinvf(2) returns $-\infty$.

Description

Calculate the inverse complementary error function of the input argument y, for y in the interval [0, 2]. The inverse complementary error function find the value x that satisfies the equation $y = \operatorname{erfc}(x)$, for $0 \le y \le 2$, and $-\infty \le x \le \infty$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float erfcxf (float x)

Calculate the scaled complementary error function of the input argument.

Returns

- erfcxf($-\infty$) returns $+\infty$
- erfcxf($+\infty$) returns +0
- erfcxf(x) returns $+\infty$ if the correctly calculated value is outside the single floating point range.

Description

Calculate the scaled complementary error function of the input argument x, $e^{x^2} \cdot \operatorname{erfc}(x)$.



__host____device__ float erff (float x)

Calculate the error function of the input argument.

Returns

- erff(± 0) returns ± 0 .
- erff($\pm \infty$) returns ± 1 .

Description

Calculate the value of the error function for the input argument \times , $\frac{2}{\sqrt{\pi}} \int_{0}^{x} e^{-t^2} dt$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float erfinvf (float y)

Calculate the inverse error function of the input argument.

Returns

- erfinvf(1) returns $+\infty$.
- erfinvf(-1) returns $-\infty$.

Description

Calculate the inverse error function of the input argument y, for y in the interval [-1, 1]. The inverse error function finds the value x that satisfies the equation y = erf(x), for $-1 \le y \le 1$, and $-\infty \le x \le \infty$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float exp10f (float x)

Calculate the base 10 exponential of the input argument.

Returns

Returns 10^x .

Calculate the base 10 exponential of the input argument x.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float exp2f (float x)

Calculate the base 2 exponential of the input argument.

Returns

Returns 2^x .

Description

Calculate the base 2 exponential of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float expf (float x)

Calculate the base *e* exponential of the input argument.

Returns

Returns e^x .

Description

Calculate the base e exponential of the input argument x, e^x .



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float expm1f (float x)

Calculate the base *e* exponential of the input argument, minus 1.

Returns

Returns $e^x - 1$.

Description

Calculate the base e exponential of the input argument x, minus 1.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float fabsf (float x)

Calculate the absolute value of its argument.

Returns

Returns the absolute value of its argument.

- fabs($\pm \infty$) returns $+\infty$.
- fabs(± 0) returns 0.

Description

Calculate the absolute value of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float fdimf (float x, float y)

Compute the positive difference between x and y.

Returns

Returns the positive difference between x and y.

- fdimf(x, y) returns x y if x > y.
- fdimf(x, y) returns +0 if $x \le y$.

Compute the positive difference between x and y. The positive difference is x - y when x > y and +0 otherwise.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float fdividef (float x, float y)

Divide two floating point values.

Returns

Returns x / y.

Description

Compute \times divided by y. If $-use_fast_math$ is specified, use $__fdividef()$ for higher performance, otherwise use normal division.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float floorf (float x)

Calculate the largest integer less than or equal to x.

Returns

Returns $log_{\alpha}(1+x)$ expressed as a floating-point number.

- floorf($\pm \infty$) returns $\pm \infty$.
- floorf(± 0) returns ± 0 .

Description

Calculate the largest integer value which is less than or equal to x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float fmaf (float x, float y, float z)

Compute $x \times y + z$ as a single operation.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fmaf($\pm \infty$, ± 0 , z) returns NaN.
- fmaf(± 0 , $\pm \infty$, z) returns NaN.
- ▶ fmaf(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- ▶ fmaf(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Description

Compute the value of $x \times y + z$ as a single ternary operation. After computing the value to infinite precision, the value is rounded once.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float fmaxf (float x, float y)

Determine the maximum numeric value of the arguments.

Returns

Returns the maximum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- ▶ If one argument is NaN, returns the numeric argument.

Description

Determines the maximum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



__host____device__ float fminf (float x, float y)

Determine the minimum numeric value of the arguments.

Returns

Returns the minimum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- ▶ If one argument is NaN, returns the numeric argument.

Description

Determines the minimum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float fmodf (float x, float y)

Calculate the floating-point remainder of x / y.

Returns

- Returns the floating point remainder of x / y.
- fmodf(± 0 , y) returns ± 0 if y is not zero.
- ▶ fmodf(x, y) returns NaN and raised an invalid floating point exception if x is $\pm \infty$ or y is zero.
- fmodf(x, y) returns zero if y is zero or the result would overflow.
- fmodf(x, $\pm \infty$) returns x if x is finite.
- fmodf(x, 0) returns NaN.

Description

Calculate the floating-point remainder of x / y. The absolute value of the computed value is always less than y 's absolute value and will have the same sign as x.



__host____device__ float frexpf (float x, int *nptr)

Extract mantissa and exponent of a floating-point value.

Returns

Returns the fractional component m.

- frexp(0, nptr) returns 0 for the fractional component and zero for the integer component.
- frexp(± 0 , nptr) returns ± 0 and stores zero in the location pointed to by nptr.
- frexp($\pm \infty$, nptr) returns $\pm \infty$ and stores an unspecified value in the location to which nptr points.
- frexp(NaN, y) returns a NaN and stores an unspecified value in the location to which nptr points.

Description

Decomposes the floating-point value x into a component m for the normalized fraction element and another term n for the exponent. The absolute value of m will be greater than or equal to 0.5 and less than 1.0 or it will be equal to 0; $x = m \cdot 2^n$. The integer exponent n will be stored in the location to which nptr points.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float __CRTDECL hypotf (float x, float y)

Calculate the square root of the sum of squares of two arguments.

Returns

Returns the length of the hypotenuse $\sqrt{x^2 + y^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculates the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



__host____device__ int ilogbf (float x)

Compute the unbiased integer exponent of the argument.

Returns

- ▶ If successful, returns the unbiased exponent of the argument.
- ▶ ilogbf(0) returns INT MIN.
- ▶ ilogbf(NaN) returns NaN.
- ilogbf(x) returns INT MAX if x is ∞ or the correct value is greater than INT MAX.
- ▶ ilogbf(x) return INT_MIN if the correct value is less than INT_MIN.

Description

Calculates the unbiased integer exponent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ __RETURN_TYPE isfinite (float a)

Determine whether argument is finite.

Returns

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is a finite value.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is a finite value.

Description

Determine whether the floating-point value a is a finite value (zero, subnormal, or normal and not infinity or NaN).

__host____device__ __RETURN_TYPE isinf (float a)

Determine whether argument is infinite.

Returns

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is a infinite value.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is a infinite value.

Determine whether the floating-point value a is an infinite value (positive or negative).

__host____device__ __RETURN_TYPE isnan (float a)

Determine whether argument is a NaN.

Returns

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is a NaN value.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is a NaN value.

Description

Determine whether the floating-point value a is a NaN.

__host____device__ float j0f (float x)

Calculate the value of the Bessel function of the first kind of order 0 for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order 0.

- ▶ $i0f(\pm \infty)$ returns +0.
- ▶ j0f(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the first kind of order 0 for the input argument x, $J_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host___device__float j1f (float x)

Calculate the value of the Bessel function of the first kind of order 1 for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order 1.

- $i1f(\pm 0)$ returns ± 0 .
- ▶ $j1f(\pm \infty)$ returns +0.
- ▶ j1f(NaN) returns NaN.

Calculate the value of the Bessel function of the first kind of order 1 for the input argument x, $J_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float jnf (int n, float x)

Calculate the value of the Bessel function of the first kind of order n for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order n.

- ▶ jnf(n, NaN) returns NaN.
- $\inf(n, x)$ returns NaN for n < 0.
- ▶ $\inf(n, +\infty)$ returns +0.

Description

Calculate the value of the Bessel function of the first kind of order n for the input argument x, $J_n(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float ldexpf (float x, int exp)

Calculate the value of $x \cdot 2^{exp}$.

Returns

▶ ldexpf(x) returns $\pm \infty$ if the correctly calculated value is outside the single floating point range.

Description

Calculate the value of $x \cdot 2^{exp}$ of the input arguments x and exp.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float lgammaf (float x)

Calculate the natural logarithm of the absolute value of the gamma function of the input argument.

Returns

- ▶ lgammaf(1) returns +0.
- ▶ lgammaf(2) returns +0.
- ▶ lgammaf(x) returns $\pm \infty$ if the correctly calculated value is outside the single floating point range.
- ▶ lgammaf(x) returns $+\infty$ if $x \le 0$.
- ▶ lgammaf($-\infty$) returns $-\infty$.
- ▶ lgammaf($+\infty$) returns $+\infty$.

Description

Calculate the natural logarithm of the absolute value of the gamma function of the input argument x, namely the value of $log_e \int_0^\infty e^{-t} t^{x-1} dt$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ long long int llrintf (float x)

Round input to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded towards zero. If the result is outside the range of the return type, the result is undefined.

__host____device__ long long int llroundf (float x)

Round to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the result is undefined.



This function may be slower than alternate rounding methods. See llrintf().

__host____device__ float log10f (float x)

Calculate the base 10 logarithm of the input argument.

Returns

- ▶ $\log 10 f(\pm 0)$ returns $-\infty$.
- ightharpoonup log 10f(1) returns +0.
- ▶ log10f(x) returns NaN for x < 0.
- ▶ $log10f(+\infty)$ returns $+\infty$.

Description

Calculate the base 10 logarithm of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float log1pf (float x)

Calculate the value of $log_e(1+x)$.

Returns

- ▶ $log1pf(\pm 0)$ returns $-\infty$.
- \blacktriangleright log1pf(-1) returns +0.
- ▶ log1pf(x) returns NaN for x < -1.
- ▶ $log1pf(+\infty)$ returns $+\infty$.

Calculate the value of $log_o(1+x)$ of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float log2f (float x)

Calculate the base 2 logarithm of the input argument.

Returns

- ▶ $\log 2f(\pm 0)$ returns $-\infty$.
- ightharpoonup log2f(1) returns +0.
- ▶ log2f(x) returns NaN for x < 0.
- ▶ $\log 2f(+\infty)$ returns $+\infty$.

Description

Calculate the base 2 logarithm of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float logbf (float x)

Calculate the floating point representation of the exponent of the input argument.

Returns

- ▶ logbf ± 0 returns $-\infty$
- ▶ $logbf + \infty returns + \infty$

Description

Calculate the floating point representation of the exponent of the input argument x.



__host____device__ float logf (float x)

Calculate the natural logarithm of the input argument.

Returns

- ▶ $\log f(\pm 0)$ returns $-\infty$.
- ▶ logf(1) returns +0.
- ▶ logf(x) returns NaN for x < 0.
- ▶ $logf(+\infty)$ returns $+\infty$.

Description

Calculate the natural logarithm of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ long int lrintf (float x)

Round input to nearest integer value.

Returns

Returns rounded integer value.

Description

Round x to the nearest integer value, with halfway cases rounded towards zero. If the result is outside the range of the return type, the result is undefined.

__host___device__ long int lroundf (float x)

Round to nearest integer value.

Returns

Returns rounded integer value.

Description

Round x to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the result is undefined.



This function may be slower than alternate rounding methods. See lrintf().

__host____device__ float modff (float x, float *iptr)

Break down the input argument into fractional and integral parts.

Returns

- modff($\pm x$, iptr) returns a result with the same sign as x.
- ▶ modff($\pm \infty$, iptr) returns ± 0 and stores $\pm \infty$ in the object pointed to by iptr.
- modff(NaN, iptr) stores a NaN in the object pointed to by iptr and returns a NaN.

Description

Break down the argument x into fractional and integral parts. The integral part is stored in the argument iptr. Fractional and integral parts are given the same sign as the argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float nanf (const char *tagp)

Returns "Not a Number" value.

Returns

nanf(tagp) returns NaN.

Description

Return a representation of a quiet NaN. Argument tagp selects one of the possible representations.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float nearbyintf (float x)

Round the input argument to the nearest integer.

Returns

- nearbyintf(± 0) returns ± 0 .
- ▶ nearbyintf($\pm \infty$) returns $\pm \infty$.

Round argument x to an integer value in single precision floating-point format.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float nextafterf (float x, float y)

Return next representable single-precision floating-point value afer argument.

Returns

• nextafterf($\pm \infty$, y) returns $\pm \infty$.

Description

Calculate the next representable single-precision floating-point value following x in the direction of y. For example, if y is greater than x, nextafterf() returns the smallest representable number greater than x



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float norm3df (float a, float b,
float c)

Calculate the square root of the sum of squares of three coordinates of the argument.

Returns

Returns the length of the 3D $\sqrt{p.x^2+p.y^2+p.z^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculates the length of three dimensional vector p in euclidean space without undue overflow or underflow.



__host____device__ float norm4df (float a, float b, float c, float d)

Calculate the square root of the sum of squares of four coordinates of the argument.

Returns

Returns the length of the 4D vector $\sqrt{p.x^2 + p.y^2 + p.z^2 + p.t^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculates the length of four dimensional vector p in euclidean space without undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float normcdff (float y)

Calculate the standard normal cumulative distribution function.

Returns

- normcdff($+\infty$) returns 1
- ▶ normcdff($-\infty$) returns +0

Description

Calculate the cumulative distribution function of the standard normal distribution for input argument y, $\Phi(y)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float normcdfinvf (float y)

Calculate the inverse of the standard normal cumulative distribution function.

Returns

- ▶ normcdfinvf(0) returns $-\infty$.
- ▶ normcdfinvf(1) returns $+\infty$.
- ▶ normcdfinvf(x) returns NaN if x is not in the interval [0,1].

Calculate the inverse of the standard normal cumulative distribution function for input argument y, $\Phi^{-1}(y)$. The function is defined for input values in the interval (0, 1).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

_host____device__ float powf (float x, float y)

Calculate the value of first argument to the power of second argument.

Returns

- ▶ powf(± 0 , y) returns $\pm \infty$ for y an integer less than 0.
- powf(± 0 , y) returns ± 0 for y an odd integer greater than 0.
- powf(± 0 , y) returns +0 for y > 0 and not and odd integer.
- powf(-1, $\pm \infty$) returns 1.
- \triangleright powf(+1, y) returns 1 for any y, even a NaN.
- powf(x, ± 0) returns 1 for any x, even a NaN.
- ightharpoonup powf(x, y) returns a NaN for finite x < 0 and finite non-integer y.
- ▶ powf(x, $-\infty$) returns $+\infty$ for |x| < 1.
- ▶ powf(x, $-\infty$) returns +0 for |x| > 1.
- ▶ powf(x, $+\infty$) returns +0 for |x| < 1.
- ▶ powf(x, $+\infty$) returns $+\infty$ for |x| > 1.
- ▶ powf($-\infty$, y) returns -0 for y an odd integer less than 0.
- ▶ powf($-\infty$, y) returns +0 for y < 0 and not an odd integer.
- ▶ powf($-\infty$, y) returns $-\infty$ for y an odd integer greater than 0.
- ▶ powf($-\infty$, y) returns $+\infty$ for y > 0 and not an odd integer.
- ▶ powf($+\infty$, y) returns +0 for y < 0.
- ▶ powf($+\infty$, y) returns $+\infty$ for y > 0.

Description

Calculate the value of x to the power of y.



__host____device__ float rcbrtf (float x)

Calculate reciprocal cube root function.

Returns

- rcbrt(± 0) returns $\pm \infty$.
- rcbrt($\pm \infty$) returns ± 0 .

Description

Calculate reciprocal cube root function of x



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float remainderf (float x, float y)

Compute single-precision floating-point remainder.

Returns

- remainderf(x, 0) returns NaN.
- ▶ remainderf($\pm \infty$, y) returns NaN.
- remainder $f(x, \pm \infty)$ returns x for finite x.

Description

Compute single-precision floating-point remainder r of dividing x by y for nonzero y. Thus r = x - ny. The value n is the integer value nearest $\frac{x}{y}$. In the case when $|n - \frac{x}{y}| = \frac{1}{2}$, the even n value is chosen.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float remquof (float x, float y, int *quo)

Compute single-precision floating-point remainder and part of quotient.

Returns

Returns the remainder.

- ► remquof(x, 0, quo) returns NaN.
- remquof($\pm \infty$, y, quo) returns NaN.
- remquof(x, $\pm \infty$, quo) returns x.

Compute a double-precision floating-point remainder in the same way as the remainderf() function. Argument quo returns part of quotient upon division of x by y. Value quo has the same sign as $\frac{x}{y}$ and may not be the exact quotient but agrees with the exact quotient in the low order 3 bits.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float rhypotf (float x, float y)

Calculate one over the square root of the sum of squares of two arguments.

Returns

Returns one over the length of the hypotenuse $\frac{1}{\sqrt{x^2 + y^2}}$. If the square root would overflow, returns 0. If the square root would underflow, returns $+\infty$.

Description

Calculates one over the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float rintf (float x)

Round input to nearest integer value in floating-point.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value in floating-point format, with halfway cases rounded towards zero.

__host____device__ float rnorm3df (float a, float b, float c)

Calculate one over the square root of the sum of squares of three coordinates of the argument.

Returns

Returns one over the length of the 3D vector $\frac{1}{\sqrt{p.x^2+p.y^2+p.z^2}}$. If the square root would overflow, returns 0. If the square root would underflow, returns $+\infty$.

Description

Calculates one over the length of three dimension vector p in euclidean space without undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float roundf (float x)

Round to nearest integer value in floating-point.

Returns

Returns rounded integer value.

Description

Round x to the nearest integer value in floating-point format, with halfway cases rounded away from zero.



This function may be slower than alternate rounding methods. See rintf().

_host___device__ float rsqrtf (float x)

Calculate the reciprocal of the square root of the input argument.

Returns

Returns $1/\sqrt{x}$.

▶ rsqrtf($+\infty$) returns +0.

- rsqrtf(± 0) returns $\pm \infty$.
- rsqrtf(x) returns NaN if x is less than 0.

Calculate the reciprocal of the nonnegative square root of x, $1/\sqrt{x}$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float scalblnf (float x, long int n)

Scale floating-point input by integer power of two.

Returns

Returns $x * 2^n$.

- scalblnf(± 0 , n) returns ± 0 .
- scalblnf(x, 0) returns x.
- ▶ scalblnf($\pm \infty$, n) returns $\pm \infty$.

Description

Scale \times by 2^n by efficient manipulation of the floating-point exponent.

__host____device__ float scalbnf (float x, int n)

Scale floating-point input by integer power of two.

Returns

Returns $x * 2^n$.

- scalbnf(± 0 , n) returns ± 0 .
- scalbnf(x, 0) returns x.
- ▶ scalbnf($\pm \infty$, n) returns $\pm \infty$.

Description

Scale \times by 2^n by efficient manipulation of the floating-point exponent.

host	device	RETURN_	_TYPE s	ignbit	(float	a)
Return the sig	gn bit of the input.					

Returns

Reports the sign bit of all values including infinities, zeros, and NaNs.

- With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is negative.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is negative.

Description

Determine whether the floating-point value a is negative.

__host____device__ void sincosf (float x, float *sptr,
float *cptr)

Calculate the sine and cosine of the first input argument.

Returns

none

Description

Calculate the sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

See also:

sinf() and cosf().



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ void sincospif (float x, float *sptr, float *cptr)

Calculate the sine and cosine of the first input argument $\times \pi$.

Returns

none

Description

Calculate the sine and cosine of the first input argument, x (measured in radians), x. The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

See also:

sinpif() and cospif().



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float sinf (float x)

Calculate the sine of the input argument.

Returns

- $sinf(\pm 0)$ returns ± 0 .
- ▶ $sinf(\pm \infty)$ returns NaN.

Description

Calculate the sine of the input argument x (measured in radians).



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float sinhf (float x)

Calculate the hyperbolic sine of the input argument.

Returns

- $\sinh(\pm 0)$ returns ± 0 .
- ▶ $\sinh(\pm \infty)$ returns NaN.

Description

Calculate the hyperbolic sine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float sinpif (float x)

Calculate the sine of the input argument $\times \pi$.

Returns

- sinpif(± 0) returns ± 0 .
- ▶ sinpif($\pm \infty$) returns NaN.

Description

Calculate the sine of $x \times \pi$ (measured in radians), where x is the input argument.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host___device__ float sgrtf (float x)

Calculate the square root of the input argument.

Returns

Returns \sqrt{x} .

- sqrtf(± 0) returns ± 0 .
- sqrtf($+\infty$) returns $+\infty$.
- $\operatorname{sqrtf}(x)$ returns NaN if x is less than 0.

Calculate the nonnegative square root of x, \sqrt{x} .



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float tanf (float x)

Calculate the tangent of the input argument.

Returns

- $tanf(\pm 0)$ returns ± 0 .
- ▶ $tanf(\pm \infty)$ returns NaN.

Description

Calculate the tangent of the input argument x (measured in radians).



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This function is affected by the --use_fast_math compiler flag. See the CUDA C Programming Guide, Appendix D.2, Table 8 for a complete list of functions affected.

__host____device__ float tanhf (float x)

Calculate the hyperbolic tangent of the input argument.

Returns

• tanhf(± 0) returns ± 0 .

Description

Calculate the hyperbolic tangent of the input argument x.



__host____device__ float tgammaf (float x)

Calculate the gamma function of the input argument.

Returns

- tgammaf(± 0) returns $\pm \infty$.
- ▶ tgammaf(2) returns +0.
- tgammaf(x) returns $\pm \infty$ if the correctly calculated value is outside the single floating point range.
- tgammaf(x) returns NaN if x < 0.
- tgammaf($-\infty$) returns NaN.
- tgammaf($+\infty$) returns $+\infty$.

Description

Calculate the gamma function of the input argument x, namely the value of $\int_{0}^{\infty} e^{-t}t^{x-1}dt$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float truncf (float x)

Truncate input argument to the integral part.

Returns

Returns truncated integer value.

Description

Round x to the nearest integer value that does not exceed x in magnitude.

__host____device__ float y0f (float x)

Calculate the value of the Bessel function of the second kind of order 0 for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order 0.

- ▶ y0f(0) returns $-\infty$.
- ▶ y0f(x) returns NaN for x < 0.
- $y0f(+\infty)$ returns +0.

▶ y0f(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order 0 for the input argument x, $Y_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float y1f (float x)

Calculate the value of the Bessel function of the second kind of order 1 for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order 1.

- ▶ y1f(0) returns $-\infty$.
- ▶ y1f(x) returns NaN for x < 0.
- $v1f(+\infty)$ returns +0.
- ▶ y1f(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order 1 for the input argument x, $Y_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ float ynf (int n, float x)

Calculate the value of the Bessel function of the second kind of order n for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order n.

- vnf(n, x) returns NaN for n < 0.
- ▶ ynf(n, 0) returns $-\infty$.
- ynf(n, x) returns NaN for x < 0.
- $ynf(n, +\infty)$ returns +0.

ynf(n, NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order n for the input argument x, $Y_n(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

1.3. Double Precision Mathematical Functions

This section describes double precision mathematical functions.

__host____device__ double acos (double x)

Calculate the arc cosine of the input argument.

Returns

Result will be in radians, in the interval $[0, \pi]$ for x inside [-1, +1].

- ightharpoonup acos(1) returns +0.
- acos(x) returns NaN for x outside [-1, +1].

Description

Calculate the principal value of the arc cosine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double acosh (double x)

Calculate the nonnegative arc hyperbolic cosine of the input argument.

Returns

Result will be in the interval $[0, +\infty]$.

- acosh(1) returns 0.
- $a\cosh(x)$ returns NaN for x in the interval $[-\infty, 1)$.

Calculate the nonnegative arc hyperbolic cosine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double asin (double x)

Calculate the arc sine of the input argument.

Returns

Result will be in radians, in the interval $[-\pi/2, +\pi/2]$ for x inside [-1, +1].

- ightharpoonup asin(0) returns +0.
- asin(x) returns NaN for x outside [-1, +1].

Description

Calculate the principal value of the arc sine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double asinh (double x)

Calculate the arc hyperbolic sine of the input argument.

Returns

asinh(0) returns 1.

Description

Calculate the arc hyperbolic sine of the input argument x.



__host____device__ double atan (double x)

Calculate the arc tangent of the input argument.

Returns

Result will be in radians, in the interval $[-\pi/2, +\pi/2]$.

ightharpoonup atan(0) returns +0.

Description

Calculate the principal value of the arc tangent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host___device__ double atan2 (double y, double x)

Calculate the arc tangent of the ratio of first and second input arguments.

Returns

Result will be in radians, in the interval $[-\pi/, +\pi]$.

▶ atan2(0, 1) returns +0.

Description

Calculate the principal value of the arc tangent of the ratio of first and second input arguments y / x. The quadrant of the result is determined by the signs of inputs y and x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double atanh (double x)

Calculate the arc hyperbolic tangent of the input argument.

Returns

- atanh(± 0) returns ± 0 .
- ▶ atanh(± 1) returns $\pm \infty$.
- ▶ atanh(x) returns NaN for x outside interval [-1, 1].

Calculate the arc hyperbolic tangent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host____device__ double cbrt (double x)

Calculate the cube root of the input argument.

Returns

Returns $x^{1/3}$.

- cbrt(± 0) returns ± 0 .
- cbrt($\pm \infty$) returns $\pm \infty$.

Description

Calculate the cube root of x, $x^{1/3}$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double ceil (double x)

Calculate ceiling of the input argument.

Returns

Returns [x] expressed as a floating-point number.

- ceil(± 0) returns ± 0 .
- ceil($\pm \infty$) returns $\pm \infty$.

Description

Compute the smallest integer value not less than x.



Create value with given magnitude, copying sign of second value.

Returns

Returns a value with the magnitude of x and the sign of y.

Description

Create a floating-point value with the magnitude x and the sign of y.

__host____device__ double cos (double x)

Calculate the cosine of the input argument.

Returns

- $\cos(\pm 0)$ returns 1.
- ▶ $\cos(\pm \infty)$ returns NaN.

Description

Calculate the cosine of the input argument x (measured in radians).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double cosh (double x)

Calculate the hyperbolic cosine of the input argument.

Returns

- cosh(0) returns 1.
- $\cosh(\pm \infty)$ returns $+\infty$.

Description

Calculate the hyperbolic cosine of the input argument x.



__host____device__ double cospi (double x)

Calculate the cosine of the input argument $\times \pi$.

Returns

- cospi(± 0) returns 1.
- cospi($\pm \infty$) returns NaN.

Description

Calculate the cosine of $x \times \pi$ (measured in radians), where x is the input argument.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host___device_ double cyl_bessel_i0 (double x)

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument.

Returns

Returns the value of the regular modified cylindrical Bessel function of order 0.

Description

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument x, $I_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double cyl_bessel_i1 (double x)

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument.

Returns

Returns the value of the regular modified cylindrical Bessel function of order 1.

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument x, $I_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double erf (double x)

Calculate the error function of the input argument.

Returns

- erf(± 0) returns ± 0 .
- erf($\pm \infty$) returns ± 1 .

Description

Calculate the value of the error function for the input argument x, $\frac{2}{\sqrt{\pi}} \int_{0}^{x} e^{-t^2} dt$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double erfc (double x)

Calculate the complementary error function of the input argument.

Returns

- erfc($-\infty$) returns 2.
- erfc($+\infty$) returns +0.

Description

Calculate the complementary error function of the input argument x, 1 - erf(x).



__host____device__ double erfcinv (double y)

Calculate the inverse complementary error function of the input argument.

Returns

- erfcinv(0) returns $+\infty$.
- erfcinv(2) returns $-\infty$.

Description

Calculate the inverse complementary error function of the input argument y, for y in the interval [0, 2]. The inverse complementary error function find the value x that satisfies the equation $y = \operatorname{erfc}(x)$, for $0 \le y \le 2$, and $-\infty \le x \le \infty$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double erfcx (double x)

Calculate the scaled complementary error function of the input argument.

Returns

- erfcx($-\infty$) returns $+\infty$
- erfcx($+\infty$) returns +0
- erfcx(x) returns $+\infty$ if the correctly calculated value is outside the double floating point range.

Description

Calculate the scaled complementary error function of the input argument x, $e^{x^2} \cdot \operatorname{erfc}(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host___device_ double erfinv (double y)

Calculate the inverse error function of the input argument.

Returns

- erfinv(1) returns $+\infty$.
- erfinv(-1) returns $-\infty$.

Calculate the inverse error function of the input argument y, for y in the interval [-1, 1]. The inverse error function finds the value x that satisfies the equation y = erf(x), for $-1 \le y \le 1$, and $-\infty \le x \le \infty$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double exp (double x)

Calculate the base *e* exponential of the input argument.

Returns

Returns e^x .

Description

Calculate the base e exponential of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double exp10 (double x)

Calculate the base 10 exponential of the input argument.

Returns

Returns 10^x .

Description

Calculate the base 10 exponential of the input argument x.



__host____device__ double exp2 (double x)

Calculate the base 2 exponential of the input argument.

Returns

Returns 2^x .

Description

Calculate the base 2 exponential of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double expm1 (double x)

Calculate the base *e* exponential of the input argument, minus 1.

Returns

Returns $e^x - 1$.

Description

Calculate the base *e* exponential of the input argument x, minus 1.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double fabs (double x)

Calculate the absolute value of the input argument.

Returns

Returns the absolute value of the input argument.

- fabs($\pm \infty$) returns $+\infty$.
- fabs(± 0) returns 0.

Description

Calculate the absolute value of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double fdim (double x, double y)

Compute the positive difference between x and y.

Returns

Returns the positive difference between x and y.

- fdim(x, y) returns x y if x > y.
- fdim(x, y) returns +0 if $x \le y$.

Description

Compute the positive difference between x and y. The positive difference is x - y when x > y and +0 otherwise.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__host____device__ double floor (double x)

Calculate the largest integer less than or equal to x.

Returns

Returns $log_{o}(1+x)$ expressed as a floating-point number.

- floor($\pm \infty$) returns $\pm \infty$.
- floor(± 0) returns ± 0 .

Description

Calculates the largest integer value which is less than or equal to x.



__host____device__ double fma (double x, double y, double z)

Compute $x \times y + z$ as a single operation.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fma($\pm \infty$, ± 0 , z) returns NaN.
- fma(± 0 , $\pm \infty$, z) returns NaN.
- fma(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- fma(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Description

Compute the value of $x \times y + z$ as a single ternary operation. After computing the value to infinite precision, the value is rounded once.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double fmax (double, double)

Determine the maximum numeric value of the arguments.

Returns

Returns the maximum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- ▶ If one argument is NaN, returns the numeric argument.

Description

Determines the maximum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



__host____device__ double fmin (double x, double y)

Determine the minimum numeric value of the arguments.

Returns

Returns the minimum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- ▶ If one argument is NaN, returns the numeric argument.

Description

Determines the minimum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double fmod (double x, double y)

Calculate the floating-point remainder of x / y.

Returns

- Returns the floating point remainder of x / y.
- fmod(± 0 , y) returns ± 0 if y is not zero.
- ▶ fmod(x, y) returns NaN and raised an invalid floating point exception if x is $\pm \infty$ or y is zero.
- \blacktriangleright fmod(x, y) returns zero if y is zero or the result would overflow.
- fmod(x, $\pm \infty$) returns x if x is finite.
- fmod(x, 0) returns NaN.

Description

Calculate the floating-point remainder of x / y. The absolute value of the computed value is always less than y 's absolute value and will have the same sign as x.



__host____device__ double frexp (double x, int *nptr)

Extract mantissa and exponent of a floating-point value.

Returns

Returns the fractional component m.

- frexp(0, nptr) returns 0 for the fractional component and zero for the integer component.
- frexp(± 0 , nptr) returns ± 0 and stores zero in the location pointed to by nptr.
- frexp($\pm \infty$, nptr) returns $\pm \infty$ and stores an unspecified value in the location to which nptr points.
- frexp(NaN, y) returns a NaN and stores an unspecified value in the location to which nptr points.

Description

Decompose the floating-point value x into a component m for the normalized fraction element and another term n for the exponent. The absolute value of m will be greater than or equal to 0.5 and less than 1.0 or it will be equal to 0; $x = m \cdot 2^n$. The integer exponent n will be stored in the location to which nptr points.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double __CRTDECL hypot (double x, double y)

Calculate the square root of the sum of squares of two arguments.

Returns

Returns the length of the hypotenuse $\sqrt{x^2 + y^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculate the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



__host____device__ int ilogb (double x)

Compute the unbiased integer exponent of the argument.

Returns

- ▶ If successful, returns the unbiased exponent of the argument.
- ▶ ilogb(0) returns INT MIN.
- ▶ ilogb(NaN) returns NaN.
- ▶ ilogb(x) returns INT MAX if x is ∞ or the correct value is greater than INT MAX.
- ▶ ilogb(x) return INT_MIN if the correct value is less than INT_MIN.

Description

Calculates the unbiased integer exponent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ __RETURN_TYPE isfinite (double a)

Determine whether argument is finite.

Returns

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is a finite value.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is a finite value.

Description

Determine whether the floating-point value a is a finite value (zero, subnormal, or normal and not infinity or NaN).

__host____device__ __RETURN_TYPE isinf (double a)

Determine whether argument is infinite.

Returns

- With Visual Studio 2013 host compiler: Returns true if and only if a is a infinite value.
- With other host compilers: Returns a nonzero value if and only if a is a infinite value.

Determine whether the floating-point value a is an infinite value (positive or negative).

__host____device__ __RETURN_TYPE isnan (double a)

Determine whether argument is a NaN.

Returns

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is a NaN value.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is a NaN value.

Description

Determine whether the floating-point value a is a NaN.

__host____device__ double j0 (double x)

Calculate the value of the Bessel function of the first kind of order 0 for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order 0.

- $i0(\pm\infty)$ returns +0.
- ▶ j0(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the first kind of order 0 for the input argument x, $J_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double j1 (double x)

Calculate the value of the Bessel function of the first kind of order 1 for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order 1.

- $j1(\pm 0)$ returns ± 0 .
- ▶ $j1(\pm \infty)$ returns +0.
- ▶ j1(NaN) returns NaN.

Calculate the value of the Bessel function of the first kind of order 1 for the input argument x, $J_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host____device__ double jn (int n, double x)

Calculate the value of the Bessel function of the first kind of order n for the input argument.

Returns

Returns the value of the Bessel function of the first kind of order n.

- ▶ jn(n, NaN) returns NaN.
- jn(n, x) returns NaN for n < 0.
- ▶ $jn(n, +\infty)$ returns +0.

Description

Calculate the value of the Bessel function of the first kind of order n for the input argument x, $J_n(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double ldexp (double x, int exp)

Calculate the value of $x \cdot 2^{exp}$.

Returns

▶ ldexp(x) returns $\pm \infty$ if the correctly calculated value is outside the double floating point range.

Description

Calculate the value of $x \cdot 2^{exp}$ of the input arguments x and exp.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double lgamma (double x)

Calculate the natural logarithm of the absolute value of the gamma function of the input argument.

Returns

- ▶ lgamma(1) returns +0.
- ▶ lgamma(2) returns +0.
- ▶ lgamma(x) returns $\pm \infty$ if the correctly calculated value is outside the double floating point range.
- ▶ lgamma(x) returns $+\infty$ if $x \le 0$.
- ▶ lgamma($-\infty$) returns $-\infty$.
- ▶ lgamma($+\infty$) returns $+\infty$.

Description

Calculate the natural logarithm of the absolute value of the gamma function of the input argument x, namely the value of $\log_e \left| \int_0^\infty e^{-t} t^{x-1} dt \right|$



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ long long int llrint (double x)

Round input to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded towards zero. If the result is outside the range of the return type, the result is undefined.

__host____device__ long long int llround (double x)

Round to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the result is undefined.



This function may be slower than alternate rounding methods. See llrint().

__host____device__ double log (double x)

Calculate the base *e* logarithm of the input argument.

Returns

- ▶ $\log(\pm 0)$ returns $-\infty$.
- ightharpoonup log(1) returns +0.
- ▶ log(x) returns NaN for x < 0.
- ▶ $log(+\infty)$ returns $+\infty$

Description

Calculate the base e logarithm of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double log10 (double x)

Calculate the base 10 logarithm of the input argument.

Returns

- ▶ $\log 10(\pm 0)$ returns $-\infty$.
- ightharpoonup log 10(1) returns +0.
- ▶ log10(x) returns NaN for x < 0.
- ▶ $\log 10(+\infty)$ returns $+\infty$.

Calculate the base 10 logarithm of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host____device__ double log1p (double x)

Calculate the value of $log_a(1+x)$.

Returns

- ▶ $log1p(\pm 0)$ returns $-\infty$.
- \triangleright log1p(-1) returns +0.
- ▶ log1p(x) returns NaN for x < -1.
- ▶ $log1p(+\infty)$ returns $+\infty$.

Description

Calculate the value of $log_o(1+x)$ of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double log2 (double x)

Calculate the base 2 logarithm of the input argument.

Returns

- ▶ $\log 2(\pm 0)$ returns $-\infty$.
- \blacktriangleright log2(1) returns +0.
- ▶ log2(x) returns NaN for x < 0.
- ▶ $\log 2(+\infty)$ returns $+\infty$.

Description

Calculate the base 2 logarithm of the input argument x.



__host____device__ double logb (double x)

Calculate the floating point representation of the exponent of the input argument.

Returns

- ▶ logb ± 0 returns $-\infty$
- ▶ logb $\pm \infty$ returns $+\infty$

Description

Calculate the floating point representation of the exponent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ long int lrint (double x)

Round input to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded towards zero. If the result is outside the range of the return type, the result is undefined.

__host____device__ long int lround (double x)

Round to nearest integer value.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the result is undefined.



This function may be slower than alternate rounding methods. See lrint().

__host____device__ double modf (double x, double *iptr)

Break down the input argument into fractional and integral parts.

Returns

- modf($\pm x$, iptr) returns a result with the same sign as x.
- ▶ modf($\pm \infty$, iptr) returns ± 0 and stores $\pm \infty$ in the object pointed to by iptr.
- modf(NaN, iptr) stores a NaN in the object pointed to by iptr and returns a NaN.

Description

Break down the argument x into fractional and integral parts. The integral part is stored in the argument iptr. Fractional and integral parts are given the same sign as the argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double nan (const char *tagp)

Returns "Not a Number" value.

Returns

nan(tagp) returns NaN.

Description

Return a representation of a quiet NaN. Argument tagp selects one of the possible representations.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host___device_ double nearbyint (double x)

Round the input argument to the nearest integer.

Returns

- nearbyint(± 0) returns ± 0 .
- ▶ nearbyint($\pm \infty$) returns $\pm \infty$.

Round argument x to an integer value in double precision floating-point format.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double nextafter (double x, double
y)

Return next representable double-precision floating-point value after argument.

Returns

• nextafter($\pm \infty$, y) returns $\pm \infty$.

Description

Calculate the next representable double-precision floating-point value following x in the direction of y. For example, if y is greater than x, nextafter() returns the smallest representable number greater than x



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double norm3d (double a, double b, double c)

Calculate the square root of the sum of squares of three coordinates of the argument.

Returns

Returns the length of 3D vector $\sqrt{p.x^2 + p.y^2 + p.z^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculate the length of three dimensional vector p in euclidean space without undue overflow or underflow.



__host____device__ double norm4d (double a, double b, double c, double d)

Calculate the square root of the sum of squares of four coordinates of the argument.

Returns

Returns the length of 4D vector $\sqrt{p.x^2 + p.y^2 + p.z^2 + p.t^2}$. If the correct value would overflow, returns $+\infty$. If the correct value would underflow, returns 0.

Description

Calculate the length of four dimensional vector p in euclidean space without undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double normcdf (double y)

Calculate the standard normal cumulative distribution function.

Returns

- normcdf($+\infty$) returns 1
- ▶ normcdf($-\infty$) returns +0

Description

Calculate the cumulative distribution function of the standard normal distribution for input argument y, $\Phi(y)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double normcdfinv (double y)

Calculate the inverse of the standard normal cumulative distribution function.

Returns

- ▶ normcdfinv(0) returns $-\infty$.
- ▶ normcdfinv(1) returns $+\infty$.
- normcdfinv(x) returns NaN if x is not in the interval [0,1].

Calculate the inverse of the standard normal cumulative distribution function for input argument y, $\Phi^{-1}(y)$. The function is defined for input values in the interval (0, 1).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host____device__ double pow (double x, double y)

Calculate the value of first argument to the power of second argument.

Returns

- ▶ pow(± 0 , y) returns $\pm \infty$ for y an integer less than 0.
- pow(± 0 , y) returns ± 0 for y an odd integer greater than 0.
- pow(± 0 , y) returns +0 for y > 0 and not and odd integer.
- pow(-1, $\pm \infty$) returns 1.
- \triangleright pow(+1, y) returns 1 for any y, even a NaN.
- pow(x, ± 0) returns 1 for any x, even a NaN.
- \triangleright pow(x, y) returns a NaN for finite x < 0 and finite non-integer y.
- ▶ pow(x, $-\infty$) returns $+\infty$ for |x| < 1.
- ▶ pow(x, $-\infty$) returns +0 for |x| > 1.
- ▶ pow(x, $+\infty$) returns +0 for |x| < 1.
- ▶ pow(x, $+\infty$) returns $+\infty$ for |x| > 1.
- ▶ pow($-\infty$, y) returns -0 for y an odd integer less than 0.
- ▶ pow($-\infty$, y) returns +0 for y < 0 and not an odd integer.
- ▶ pow($-\infty$, y) returns $-\infty$ for y an odd integer greater than 0.
- ▶ pow($-\infty$, y) returns $+\infty$ for y > 0 and not an odd integer.
- ▶ pow($+\infty$, y) returns +0 for y < 0.
- ▶ pow($+\infty$, y) returns $+\infty$ for y > 0.

Description

Calculate the value of x to the power of y



__host____device__ double rcbrt (double x)

Calculate reciprocal cube root function.

Returns

- rcbrt(± 0) returns $\pm \infty$.
- rcbrt($\pm \infty$) returns ± 0 .

Description

Calculate reciprocal cube root function of x



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double remainder (double x,
double y)

Compute double-precision floating-point remainder.

Returns

- remainder(x, 0) returns NaN.
- remainder($\pm \infty$, y) returns NaN.
- remainder(x, $\pm \infty$) returns x for finite x.

Description

Compute double-precision floating-point remainder r of dividing x by y for nonzero y. Thus r = x - ny. The value n is the integer value nearest $\frac{x}{y}$. In the case when $|n - \frac{x}{y}| = \frac{1}{2}$, the even n value is chosen.



__host____device__ double remquo (double x, double y, int *quo)

Compute double-precision floating-point remainder and part of quotient.

Returns

Returns the remainder.

- ► remquo(x, 0, quo) returns NaN.
- remquo($\pm \infty$, y, quo) returns NaN.
- remquo(x, $\pm \infty$, quo) returns x.

Description

Compute a double-precision floating-point remainder in the same way as the remainder() function. Argument quo returns part of quotient upon division of x by y. Value quo has the same sign as $\frac{x}{y}$ and may not be the exact quotient but agrees with the exact quotient in the low order 3 bits.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double rhypot (double x, double y)

Calculate one over the square root of the sum of squares of two arguments.

Returns

Returns one over the length of the hypotenuse $\frac{1}{\sqrt{x^2 + y^2}}$. If the square root would overflow, returns 0. If the square root would underflow, returns $+\infty$.

Description

Calculate one over the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

	host	device	double rint ((double x)
--	------	--------	---------------	------------

Round to nearest integer value in floating-point.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value in floating-point format, with halfway cases rounded to the nearest even integer value.

__host____device__ double rnorm3d (double a, double b, double c)

Calculate one over the square root of the sum of squares of three coordinates of the argument.

Returns

Returns one over the length of the 3D vetor $\frac{1}{\sqrt{p.x^2+p.y^2+p.z^2}}$. If the square root would overflow, returns 0. If the square root would underflow, returns $+\infty$.

Description

Calculate one over the length of three dimensional vector p in euclidean space undue overflow or underflow.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double round (double x)

Round to nearest integer value in floating-point.

Returns

Returns rounded integer value.

Description

Round \times to the nearest integer value in floating-point format, with halfway cases rounded away from zero.



This function may be slower than alternate rounding methods. See rint().

__host____device__ double rsqrt (double x)

Calculate the reciprocal of the square root of the input argument.

Returns

Returns $1/\sqrt{x}$.

- ► rsqrt($+\infty$) returns +0.
- rsqrt(± 0) returns $\pm \infty$.
- rsqrt(x) returns NaN if x is less than 0.

Description

Calculate the reciprocal of the nonnegative square root of x, $1/\sqrt{x}$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double scalbln (double x, long int n)

Scale floating-point input by integer power of two.

Returns

Returns $x * 2^n$.

- scalbln(± 0 , n) returns ± 0 .
- scalbln(x, 0) returns x.
- scalbln($\pm \infty$, n) returns $\pm \infty$.

Description

Scale \times by 2^n by efficient manipulation of the floating-point exponent.

TIOSE ACTICE ADADIC SCALDIT (ADADIC A, IIIL I	host	device	double scalbn	(double x,	int n
---	------	--------	---------------	------------	-------

Scale floating-point input by integer power of two.

Returns

Returns $x * 2^n$.

- scalbn(± 0 , n) returns ± 0 .
- ightharpoonup scalbn(x, 0) returns x.
- ▶ scalbn($\pm \infty$, n) returns $\pm \infty$.

Description

Scale \times by 2^n by efficient manipulation of the floating-point exponent.

__host____device__ __RETURN_TYPE signbit (double a)

Return the sign bit of the input.

Returns

Reports the sign bit of all values including infinities, zeros, and NaNs.

- ▶ With Visual Studio 2013 host compiler: __RETURN_TYPE is 'bool'. Returns true if and only if a is negative.
- ▶ With other host compilers: __RETURN_TYPE is 'int'. Returns a nonzero value if and only if a is negative.

Description

Determine whether the floating-point value a is negative.

__host____device__ double sin (double x)

Calculate the sine of the input argument.

Returns

- $ightharpoonup \sin(\pm 0)$ returns ± 0 .
- ▶ $\sin(\pm \infty)$ returns NaN.

Description

Calculate the sine of the input argument x (measured in radians).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ void sincos (double x, double *sptr, double *cptr)

Calculate the sine and cosine of the first input argument.

Returns

none

Description

Calculate the sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

See also:

sin() and cos().



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ void sincospi (double x, double *sptr, double *cptr)

Calculate the sine and cosine of the first input argument $\times \pi$.

Returns

none

Description

Calculate the sine and cosine of the first input argument, x (measured in radians), $x\pi$. The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

See also:

sinpi() and cospi().



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double sinh (double x)

Calculate the hyperbolic sine of the input argument.

Returns

• $\sinh(\pm 0)$ returns ± 0 .

Description

Calculate the hyperbolic sine of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double sinpi (double x)

Calculate the sine of the input argument $\times \pi$.

Returns

- $sinpi(\pm 0)$ returns ± 0 .
- ▶ $sinpi(\pm \infty)$ returns NaN.

Description

Calculate the sine of $x \times \pi$ (measured in radians), where x is the input argument.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double sqrt (double x)

Calculate the square root of the input argument.

Returns

Returns \sqrt{x} .

- sqrt(± 0) returns ± 0 .
- sqrt($+\infty$) returns $+\infty$.

• $\operatorname{sqrt}(x)$ returns NaN if x is less than 0.

Description

Calculate the nonnegative square root of x, \sqrt{x} .



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host___device__ double tan (double x)

Calculate the tangent of the input argument.

Returns

- $tan(\pm 0)$ returns ± 0 .
- ▶ $tan(\pm \infty)$ returns NaN.

Description

Calculate the tangent of the input argument x (measured in radians).



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double tanh (double x)

Calculate the hyperbolic tangent of the input argument.

Returns

• $\tanh(\pm 0)$ returns ± 0 .

Description

Calculate the hyperbolic tangent of the input argument x.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double tgamma (double x)

Calculate the gamma function of the input argument.

Returns

- tgamma(± 0) returns $\pm \infty$.
- ▶ tgamma(2) returns +0.
- tgamma(x) returns $\pm \infty$ if the correctly calculated value is outside the double floating point range.
- tgamma(x) returns NaN if x < 0.
- ▶ tgamma($-\infty$) returns NaN.
- ▶ tgamma($+\infty$) returns $+\infty$.

Description

Calculate the gamma function of the input argument x, namely the value of $\int_{0}^{\infty} e^{-t}t^{x-1}dt$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double trunc (double x)

Truncate input argument to the integral part.

Returns

Returns truncated integer value.

Description

Round x to the nearest integer value that does not exceed x in magnitude.

__host____device__ double y0 (double x)

Calculate the value of the Bessel function of the second kind of order 0 for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order 0.

- ▶ y0(0) returns $-\infty$.
- y0(x) returns NaN for x < 0.
- ▶ $y0(+\infty)$ returns +0.

▶ y0(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order 0 for the input argument x, $Y_0(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

_host____device__ double y1 (double x)

Calculate the value of the Bessel function of the second kind of order 1 for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order 1.

- ▶ y1(0) returns $-\infty$.
- y1(x) returns NaN for x < 0.
- $v1(+\infty)$ returns +0.
- ▶ y1(NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order 1 for the input argument x, $Y_1(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

__host____device__ double yn (int n, double x)

Calculate the value of the Bessel function of the second kind of order n for the input argument.

Returns

Returns the value of the Bessel function of the second kind of order n.

- yn(n, x) returns NaN for n < 0.
- ▶ yn(n, 0) returns $-\infty$.
- yn(n, x) returns NaN for x < 0.
- $yn(n, +\infty)$ returns +0.

yn(n, NaN) returns NaN.

Description

Calculate the value of the Bessel function of the second kind of order n for the input argument x, $Y_n(x)$.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.

1.4. Single Precision Intrinsics

This section describes single precision intrinsic functions that are only supported in device code.

__DEVICE_FUNCTIONS_DECL__ float __cosf (float x)

Calculate the fast approximate cosine of the input argument.

Returns

Returns the approximate cosine of x.

Description

Calculate the fast approximate cosine of the input argument x, measured in radians.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- ▶ Input and output in the denormal range is flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __exp10f (float x)

Calculate the fast approximate base 10 exponential of the input argument.

Returns

Returns an approximation to 10^x .

Description

Calculate the fast approximate base 10 exponential of the input argument x, 10^x .



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Most input and output values around denormal range are flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __expf (float x)

Calculate the fast approximate base e exponential of the input argument.

Returns

Returns an approximation to e^x .

Description

Calculate the fast approximate base e exponential of the input argument x, e^x .



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Most input and output values around denormal range are flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __fadd_rd (float x, float y)

Add two floating point values in round-down mode.

Returns

Returns x + y.

Description

Compute the sum of x and y in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fadd_rn (float x, float y)

Add two floating point values in round-to-nearest-even mode.

Returns

Returns x + y.

Description

Compute the sum of x and y in round-to-nearest-even rounding mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fadd_ru (float x, float y)

Add two floating point values in round-up mode.

Returns

Returns x + y.

Description

Compute the sum of x and y in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fadd_rz (float x, float y)

Add two floating point values in round-towards-zero mode.

Returns

Returns x + y.

Compute the sum of x and y in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fdiv_rd (float x, float y)

Divide two floating point values in round-down mode.

Returns

Returns x / y.

Description

Divide two floating point values x by y in round-down (to negative infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fdiv_rn (float x, float y)

Divide two floating point values in round-to-nearest-even mode.

Returns

Returns x / y.

Description

Divide two floating point values x by y in round-to-nearest-even mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fdiv_ru (float x, float y)

Divide two floating point values in round-up mode.

Returns

Returns x / y.

Description

Divide two floating point values x by y in round-up (to positive infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fdiv_rz (float x, float y)

Divide two floating point values in round-towards-zero mode.

Returns

Returns x / y.

Description

Divide two floating point values x by y in round-towards-zero mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fdividef (float x, float y)

Calculate the fast approximate division of the input arguments.

Returns

Returns x / y.

- **_**fdividef(∞ , y) returns NaN for $2^{126} < y < 2^{128}$.
- fdividef(x, y) returns 0 for $2^{126} < y < 2^{128}$ and $x \neq \infty$.

Calculate the fast approximate division of x by y.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.

__DEVICE_FUNCTIONS_DECL__ float __fmaf_rd (float x, float y, float z)

Compute $x \times y + z$ as a single operation, in round-down mode.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fmaf($\pm \infty$, ± 0 , z) returns NaN.
- fmaf(± 0 , $\pm \infty$, z) returns NaN.
- fmaf(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- ▶ fmaf(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Description

Computes the value of $x \times y + z$ as a single ternary operation, rounding the result once in round-down (to negative infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fmaf_rn (float x, float y, float z)

Compute $x \times y + z$ as a single operation, in round-to-nearest-even mode.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fmaf($\pm \infty$, ± 0 , z) returns NaN.
- fmaf(± 0 , $\pm \infty$, z) returns NaN.
- fmaf(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- ▶ fmaf(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Computes the value of $x \times y + z$ as a single ternary operation, rounding the result once in round-to-nearest-even mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fmaf_ru (float x, float y, float z)

Compute $x \times y + z$ as a single operation, in round-up mode.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fmaf($\pm \infty$, ± 0 , z) returns NaN.
- fmaf(± 0 , $\pm \infty$, z) returns NaN.
- fmaf(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- fmaf(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Description

Computes the value of $x \times y + z$ as a single ternary operation, rounding the result once in round-up (to positive infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fmaf_rz (float x, float y, float z)

Compute $x \times y + z$ as a single operation, in round-towards-zero mode.

Returns

Returns the rounded value of $x \times y + z$ as a single operation.

- fmaf($\pm \infty$, ± 0 , z) returns NaN.
- fmaf(± 0 , $\pm \infty$, z) returns NaN.
- fmaf(x, y, $-\infty$) returns NaN if $x \times y$ is an exact $+\infty$.
- ▶ fmaf(x, y, $+\infty$) returns NaN if $x \times y$ is an exact $-\infty$.

Computes the value of $x \times y + z$ as a single ternary operation, rounding the result once in round-towards-zero mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fmul_rd (float x, float y)

Multiply two floating point values in round-down mode.

Returns

Returns x * y.

Description

Compute the product of x and y in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ► This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fmul_rn (float x, float y)

Multiply two floating point values in round-to-nearest-even mode.

Returns

Returns x * y.

Description

Compute the product of x and y in round-to-nearest-even mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fmul_ru (float x, float y)

Multiply two floating point values in round-up mode.

Returns

Returns x * y.

Description

Compute the product of x and y in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fmul_rz (float x, float y)

Multiply two floating point values in round-towards-zero mode.

Returns

Returns x * y.

Description

Compute the product of x and y in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float ___frcp_rd (float x)

Compute $\frac{1}{x}$ in round-down mode.

Returns

Returns $\frac{1}{x}$.

Compute the reciprocal of x in round-down (to negative infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float ___frcp_rn (float x)

Compute $\frac{1}{x}$ in round-to-nearest-even mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-to-nearest-even mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __frcp_ru (float x)

Compute $\frac{1}{x}$ in round-up mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-up (to positive infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __frcp_rz (float x)

Compute $\frac{1}{x}$ in round-towards-zero mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-towards-zero mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __frsqrt_rn (float x)

Compute $1/\sqrt{x}$ in round-to-nearest-even mode.

Returns

Returns $1/\sqrt{x}$.

Description

Compute the reciprocal square root of x in round-to-nearest-even mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fsqrt_rd (float x)

Compute \sqrt{x} in round-down mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-down (to negative infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fsqrt_rn (float x)

Compute \sqrt{x} in round-to-nearest-even mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of \boldsymbol{x} in round-to-nearest-even mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fsqrt_ru (float x)

Compute \sqrt{x} in round-up mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-up (to positive infinity) mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL___ float ___fsqrt_rz (float x)

Compute \sqrt{x} in round-towards-zero mode.

Returns

Returns \sqrt{x} .

Compute the square root of x in round-towards-zero mode.



For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.

__DEVICE_FUNCTIONS_DECL__ float __fsub_rd (float x, float y)

Subtract two floating point values in round-down mode.

Returns

Returns x - y.

Description

Compute the difference of x and y in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fsub_rn (float x, float y)

Subtract two floating point values in round-to-nearest-even mode.

Returns

Returns x - y.

Description

Compute the difference of x and y in round-to-nearest-even rounding mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fsub_ru (float x, float y)

Subtract two floating point values in round-up mode.

Returns

Returns x - y.

Description

Compute the difference of x and y in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __fsub_rz (float x, float y)

Subtract two floating point values in round-towards-zero mode.

Returns

Returns x - y.

Description

Compute the difference of x and y in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 6.
- ▶ This operation will never be merged into a single multiply-add instruction.

__DEVICE_FUNCTIONS_DECL__ float __log10f (float x)

Calculate the fast approximate base 10 logarithm of the input argument.

Returns

Returns an approximation to $\log_{10}(x)$.

Calculate the fast approximate base 10 logarithm of the input argument x.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Most input and output values around denormal range are flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __log2f (float x)

Calculate the fast approximate base 2 logarithm of the input argument.

Returns

Returns an approximation to $\log_2(x)$.

Description

Calculate the fast approximate base 2 logarithm of the input argument x.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- ▶ Input and output in the denormal range is flushed to sign preserving 0.0.

DEVICE FUNCTIONS DECL float logf (float x)

Calculate the fast approximate base e logarithm of the input argument.

Returns

Returns an approximation to $\log_{e}(x)$.

Description

Calculate the fast approximate base e logarithm of the input argument x.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Most input and output values around denormal range are flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __powf (float x, float y)

Calculate the fast approximate of x^y .

Returns

Returns an approximation to x^y .

Description

Calculate the fast approximate of x, the first input argument, raised to the power of y, the second input argument, x^y .



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Most input and output values around denormal range are flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __saturatef (float x)

Clamp the input argument to [+0.0, 1.0].

Returns

- ► __saturatef(x) returns 0 if x < 0.
- ▶ __saturatef(x) returns 1 if x > 1.
- ► __saturatef(x) returns x if $0 \le x \le 1$.
- __saturatef(NaN) returns 0.

Description

Clamp the input argument x to be within the interval [+0.0, 1.0].

__DEVICE_FUNCTIONS_DECL__ void __sincosf (float x, float *sptr, float *cptr)

Calculate the fast approximate of sine and cosine of the first input argument.

Returns

none

Calculate the fast approximate of sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Denorm input/output is flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __sinf (float x)

Calculate the fast approximate sine of the input argument.

Returns

Returns the approximate sine of x.

Description

Calculate the fast approximate sine of the input argument x, measured in radians.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- Input and output in the denormal range is flushed to sign preserving 0.0.

__DEVICE_FUNCTIONS_DECL__ float __tanf (float x)

Calculate the fast approximate tangent of the input argument.

Returns

Returns the approximate tangent of x.

Description

Calculate the fast approximate tangent of the input argument x, measured in radians.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.2, Table 9.
- ► The result is computed as the fast divide of __sinf() by __cosf(). Denormal input and output are flushed to sign-preserving 0.0 at each step of the computation.

1.5. Double Precision Intrinsics

This section describes double precision intrinsic functions that are only supported in device code.

__device__ double __ddiv_rd (double x, double y)

Divide two floating point values in round-down mode.

Returns

Returns x / y.

Description

Divides two floating point values x by y in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- Requires compute capability >= 2.0.

__device__ double __ddiv_rn (double x, double y)

Divide two floating point values in round-to-nearest-even mode.

Returns

Returns x / y.

Description

Divides two floating point values x by y in round-to-nearest-even mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- Requires compute capability >= 2.0.

__device__ double __ddiv_ru (double x, double y)

Divide two floating point values in round-up mode.

Returns

Returns x / y.

Divides two floating point values x by y in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __ddiv_rz (double x, double y)

Divide two floating point values in round-towards-zero mode.

Returns

Returns x / y.

Description

Divides two floating point values x by y in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __drcp_rd (double x)

Compute $\frac{1}{x}$ in round-down mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- Requires compute capability >= 2.0.

__device__ double __drcp_rn (double x)

Compute $\frac{1}{x}$ in round-to-nearest-even mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-to-nearest-even mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __drcp_ru (double x)

Compute $\frac{1}{x}$ in round-up mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __drcp_rz (double x)

Compute $\frac{1}{x}$ in round-towards-zero mode.

Returns

Returns $\frac{1}{x}$.

Description

Compute the reciprocal of x in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- Requires compute capability >= 2.0.

__device__ double __dsqrt_rd (double x)

Compute \sqrt{x} in round-down mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-down (to negative infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __dsqrt_rn (double x)

Compute \sqrt{x} in round-to-nearest-even mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-to-nearest-even mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __dsqrt_ru (double x)

Compute \sqrt{x} in round-up mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-up (to positive infinity) mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ► Requires compute capability >= 2.0.

__device__ double __dsqrt_rz (double x)

Compute \sqrt{x} in round-towards-zero mode.

Returns

Returns \sqrt{x} .

Description

Compute the square root of x in round-towards-zero mode.



- For accuracy information for this function see the CUDA C Programming Guide, Appendix D.1, Table 7.
- ▶ Requires compute capability >= 2.0.

1.6. Integer Intrinsics

This section describes integer intrinsic functions that are only supported in device code.

__DEVICE_FUNCTIONS_DECL__ unsigned int __brev (unsigned int x)

Reverse the bit order of a 32 bit unsigned integer.

Returns

Returns the bit-reversed value of x. i.e. bit N of the return value corresponds to bit 31-N of x.

Description

Reverses the bit order of the 32 bit unsigned integer x.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __brevll (unsigned long long int x)

Reverse the bit order of a 64 bit unsigned integer.

Returns

Returns the bit-reversed value of x. i.e. bit N of the return value corresponds to bit 63-N of x.

Description

Reverses the bit order of the 64 bit unsigned integer x.

__DEVICE_FUNCTIONS_DECL__ unsigned int __byte_perm (unsigned int x, unsigned int y, unsigned int s)

Return selected bytes from two 32 bit unsigned integers.

Returns

The returned value r is computed to be: result[n] := input[selector[n]] where result[n] is the nth byte of r.

Description

byte_perm(x,y,s) returns a 32-bit integer consisting of four bytes from eight input bytes provided in the two input integers x and y, as specified by a selector, s.

The input bytes are indexed as follows: input[0] = x<7:0> input[1] = x<15:8> input[2] = x<23:16> input[3] = x<31:24> input[4] = y<7:0> input[5] = y<15:8> input[6] = y<23:16> input[7] = y<31:24> The selector indices are as follows (the upper 16-bits of the selector

are not used): selector[0] = s<2:0> selector[1] = s<6:4> selector[2] = s<10:8> selector[3] = s<14:12>

Return the number of consecutive high-order zero bits in a 32 bit integer.

Returns

Returns a value between 0 and 32 inclusive representing the number of zero bits.

Description

Count the number of consecutive leading zero bits, starting at the most significant bit (bit 31) of x.

Count the number of consecutive high-order zero bits in a 64 bit integer.

Returns

Returns a value between 0 and 64 inclusive representing the number of zero bits.

Description

Count the number of consecutive leading zero bits, starting at the most significant bit (bit 63) of x.

Find the position of the least significant bit set to 1 in a 32 bit integer.

Returns

Returns a value between 0 and 32 inclusive representing the position of the first bit set.

__ffs(0) returns 0.

Description

Find the position of the first (least significant) bit set to 1 in \times , where the least significant bit position is 1.

__DEVICE_FUNCTIONS_DECL__ int __ffsll (long long int x)

Find the position of the least significant bit set to 1 in a 64 bit integer.

Returns

Returns a value between 0 and 64 inclusive representing the position of the first bit set.

► __ffsll(0) returns 0.

Description

Find the position of the first (least significant) bit set to 1 in \times , where the least significant bit position is 1.

__DEVICE_FUNCTIONS_DECL__ int __hadd (int, int)

Compute average of signed input arguments, avoiding overflow in the intermediate sum.

Returns

Returns a signed integer value representing the signed average value of the two inputs.

Description

Compute average of signed input arguments x and y as (x + y) >> 1, avoiding overflow in the intermediate sum.

__DEVICE_FUNCTIONS_DECL__ int __mul24 (int x, int y)

Calculate the least significant 32 bits of the product of the least significant 24 bits of two integers.

Returns

Returns the least significant 32 bits of the product x * y.

Description

Calculate the least significant 32 bits of the product of the least significant 24 bits of x and y. The high order 8 bits of x and y are ignored.

__DEVICE_FUNCTIONS_DECL__ long long int __mul64hi (long long int x, long long int y)

Calculate the most significant 64 bits of the product of the two 64 bit integers.

Returns

Returns the most significant 64 bits of the product x * y.

Description

Calculate the most significant 64 bits of the 128-bit product \times * y, where \times and y are 64-bit integers.

__DEVICE_FUNCTIONS_DECL__ int __mulhi (int x, int y)

Calculate the most significant 32 bits of the product of the two 32 bit integers.

Returns

Returns the most significant 32 bits of the product x * y.

Description

Calculate the most significant 32 bits of the 64-bit product x * y, where x * y are 32-bit integers.

__DEVICE_FUNCTIONS_DECL__ int __popc (unsigned int x)

Count the number of bits that are set to 1 in a 32 bit integer.

Returns

Returns a value between 0 and 32 inclusive representing the number of set bits.

Description

Count the number of bits that are set to 1 in \times .

__DEVICE_FUNCTIONS_DECL__ int __popcll (unsigned long long int x)

Count the number of bits that are set to 1 in a 64 bit integer.

Returns

Returns a value between 0 and 64 inclusive representing the number of set bits.

Count the number of bits that are set to 1 in \times .

__DEVICE_FUNCTIONS_DECL__ int __rhadd (int, int)

Compute rounded average of signed input arguments, avoiding overflow in the intermediate sum.

Returns

Returns a signed integer value representing the signed rounded average value of the two inputs.

Description

Compute average of signed input arguments x and y as (x + y + 1) >> 1, avoiding overflow in the intermediate sum.

__DEVICE_FUNCTIONS_DECL__ unsigned int __sad (int x, int y, unsigned int z)

Calculate |x - y| + z, the sum of absolute difference.

Returns

Returns |x - y| + z.

Description

Calculate |x - y| + z, the 32-bit sum of the third argument z plus and the absolute value of the difference between the first argument, x, and second argument, y.

Inputs x and y are signed 32-bit integers, input z is a 32-bit unsigned integer.

__DEVICE_FUNCTIONS_DECL__ unsigned int __uhadd (unsigned int, unsigned int)

Compute average of unsigned input arguments, avoiding overflow in the intermediate sum.

Returns

Returns an unsigned integer value representing the unsigned average value of the two inputs.

Description

Compute average of unsigned input arguments x and y as (x + y) >> 1, avoiding overflow in the intermediate sum.

__DEVICE_FUNCTIONS_DECL__ unsigned int __umul24 (unsigned int x, unsigned int y)

Calculate the least significant 32 bits of the product of the least significant 24 bits of two unsigned integers.

Returns

Returns the least significant 32 bits of the product x * y.

Description

Calculate the least significant 32 bits of the product of the least significant 24 bits of x and y. The high order 8 bits of x and y are ignored.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __umul64hi (unsigned long long int x, unsigned long long int y)

Calculate the most significant 64 bits of the product of the two 64 unsigned bit integers.

Returns

Returns the most significant 64 bits of the product x * y.

Description

Calculate the most significant 64 bits of the 128-bit product x * y, where x and y are 64-bit unsigned integers.

__DEVICE_FUNCTIONS_DECL__ unsigned int __umulhi (unsigned int x, unsigned int y)

Calculate the most significant 32 bits of the product of the two 32 bit unsigned integers.

Returns

Returns the most significant 32 bits of the product x * y.

Description

Calculate the most significant 32 bits of the 64-bit product x * y, where x and y are 32-bit unsigned integers.

__DEVICE_FUNCTIONS_DECL__ unsigned int __urhadd (unsigned int, unsigned int)

Compute rounded average of unsigned input arguments, avoiding overflow in the intermediate sum.

Returns

Returns an unsigned integer value representing the unsigned rounded average value of the two inputs.

Description

Compute average of unsigned input arguments x and y as (x + y + 1) >> 1, avoiding overflow in the intermediate sum.

__DEVICE_FUNCTIONS_DECL__ unsigned int __usad (unsigned int x, unsigned int y, unsigned int z)

Calculate |x - y| + z, the sum of absolute difference.

Returns

Returns |x - y| + z.

Description

Calculate |x - y| + z, the 32-bit sum of the third argument z plus and the absolute value of the difference between the first argument, x, and second argument, y.

Inputs x, y, and z are unsigned 32-bit integers.

1.7. Type Casting Intrinsics

This section describes type casting intrinsic functions that are only supported in device code.

__DEVICE_FUNCTIONS_DECL__ int __double2int_rz (double)

Convert a double to a signed int in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the double-precision floating point value x to a signed integer value in round-towards-zero mode.

Convert a double to a signed 64-bit int in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the double-precision floating point value x to a signed 64-bit integer value in round-towards-zero mode.

Convert a double to an unsigned int in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the double-precision floating point value \times to an unsigned integer value in round-towards-zero mode.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __double2ull_rz (double)

Convert a double to an unsigned 64-bit int in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the double-precision floating point value x to an unsigned 64-bit integer value in round-towards-zero mode.

Convert a single-precision float to a half-precision float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the single-precision float value x to a half-precision floating point value represented in unsigned short format, in round-to-nearest-even mode.

Convert a float to a signed integer in round-down mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to a signed integer in round-down (to negative infinity) mode.

__DEVICE_FUNCTIONS_DECL__ int __float2int_rn (float x)

Convert a float to a signed integer in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to a signed integer in round-to-nearest-even mode.

Convert a float to a signed integer in round-up mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to a signed integer in round-up (to positive infinity) mode.

Convert a float to a signed integer in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to a signed integer in round-towards-zero mode.

__DEVICE_FUNCTIONS_DECL__ long long int __float2ll_rd (float x)

Convert a float to a signed 64-bit integer in round-down mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to a signed 64-bit integer in round-down (to negative infinity) mode.

Convert a float to a signed 64-bit integer in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to a signed 64-bit integer in round-to-nearest-even mode.

Convert a float to a signed 64-bit integer in round-up mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to a signed 64-bit integer in round-up (to positive infinity) mode.

__DEVICE_FUNCTIONS_DECL__ long long int __float2ll_rz (float x)

Convert a float to a signed 64-bit integer in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to a signed 64-bit integer in round-towards-zero mode.

Convert a float to an unsigned integer in round-down mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to an unsigned integer in round-down (to negative infinity) mode.

Convert a float to an unsigned integer in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to an unsigned integer in round-to-nearest-even mode.

__DEVICE_FUNCTIONS_DECL__ unsigned int __float2uint_ru (float x)

Convert a float to an unsigned integer in round-up mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to an unsigned integer in round-up (to positive infinity) mode.

Convert a float to an unsigned integer in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value \times to an unsigned integer in round-towards-zero mode.

Convert a float to an unsigned 64-bit integer in round-down mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to an unsigned 64-bit integer in round-down (to negative infinity) mode.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __float2ull_rn (float x)

Convert a float to an unsigned 64-bit integer in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to an unsigned 64-bit integer in round-to-nearest-even mode.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __float2ull_ru (float x)

Convert a float to an unsigned 64-bit integer in round-up mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to an unsigned 64-bit integer in round-up (to positive infinity) mode.

__DEVICE_FUNCTIONS_DECL__ unsigned long long int __float2ull_rz (float x)

Convert a float to an unsigned 64-bit integer in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the single-precision floating point value x to an unsigned 64-bit integer in round-towards_zero mode.

__DEVICE_FUNCTIONS_DECL__ int __float_as_int (float x)

Reinterpret bits in a float as a signed integer.

Returns

Returns reinterpreted value.

Description

Reinterpret the bits in the single-precision floating point value x as a signed integer.

__DEVICE_FUNCTIONS_DECL__ float __half2float (unsigned short x)

Convert a half-precision float to a single-precision float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the half-precision floating point value x represented in unsigned short format to a single-precision floating point value.

Convert a signed integer to a float in round-down mode.

Returns

Returns converted value.

Description

Convert the signed integer value x to a single-precision floating point value in round-down (to negative infinity) mode.

Convert a signed integer to a float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the signed integer value \times to a single-precision floating point value in round-to-nearest-even mode.

Convert a signed integer to a float in round-up mode.

Returns

Returns converted value.

Description

Convert the signed integer value x to a single-precision floating point value in round-up (to positive infinity) mode.

Convert a signed integer to a float in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the signed integer value \times to a single-precision floating point value in round-towards-zero mode.

__DEVICE_FUNCTIONS_DECL__ float __int_as_float (int x)

Reinterpret bits in an integer as a float.

Returns

Returns reinterpreted value.

Description

Reinterpret the bits in the signed integer value \times as a single-precision floating point value.

__DEVICE_FUNCTIONS_DECL__ float __ll2float_rd (long long int x)

Convert a signed integer to a float in round-down mode.

Returns

Returns converted value.

Description

Convert the signed integer value x to a single-precision floating point value in round-down (to negative infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __ll2float_rn (long long int x)

Convert a signed 64-bit integer to a float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the signed 64-bit integer value x to a single-precision floating point value in round-to-nearest-even mode.

__DEVICE_FUNCTIONS_DECL__ float __ll2float_ru (long long int x)

Convert a signed integer to a float in round-up mode.

Returns

Returns converted value.

Description

Convert the signed integer value \times to a single-precision floating point value in round-up (to positive infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __ll2float_rz (long long int x)

Convert a signed integer to a float in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the signed integer value \times to a single-precision floating point value in round-towards-zero mode.

__DEVICE_FUNCTIONS_DECL__ float __uint2float_rd (unsigned int x)

Convert an unsigned integer to a float in round-down mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-down (to negative infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __uint2float_rn (unsigned int x)

Convert an unsigned integer to a float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-to-nearest-even mode.

__DEVICE_FUNCTIONS_DECL__ float __uint2float_ru (unsigned int x)

Convert an unsigned integer to a float in round-up mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-up (to positive infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __uint2float_rz (unsigned int x)

Convert an unsigned integer to a float in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-towards-zero mode.

__DEVICE_FUNCTIONS_DECL__ float __ull2float_rd (unsigned long long int x)

Convert an unsigned integer to a float in round-down mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value \times to a single-precision floating point value in round-down (to negative infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __ull2float_rn (unsigned long long int x)

Convert an unsigned integer to a float in round-to-nearest-even mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value \times to a single-precision floating point value in round-to-nearest-even mode.

__DEVICE_FUNCTIONS_DECL__ float __ull2float_ru (unsigned long long int x)

Convert an unsigned integer to a float in round-up mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-up (to positive infinity) mode.

__DEVICE_FUNCTIONS_DECL__ float __ull2float_rz (unsigned long long int x)

Convert an unsigned integer to a float in round-towards-zero mode.

Returns

Returns converted value.

Description

Convert the unsigned integer value x to a single-precision floating point value in round-towards-zero mode.

1.8. SIMD Intrinsics

This section describes SIMD intrinsic functions that are only supported in device code.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabs2 (unsigned int a)

Computes per-halfword absolute value.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes, then computes absolute value for each of parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabs4 (unsigned int a)

Computes per-byte absolute value.

Returns

Returns computed value.

Description

Splits argument by bytes. Computes absolute value of each byte. Result is stored as unsigned int.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsdiffs2 (unsigned int a, unsigned int b)

Computes per-halfword sum of absolute difference of signed integer.

Returns

Returns computed value.

Description

Splits 4 bytes of each into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute difference. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsdiffs4 (unsigned int a, unsigned int b)

Computes per-byte absolute difference of signed integer.

Returns

Returns computed value.

Description

Splits 4 bytes of each into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute difference. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsdiffu2 (unsigned int a, unsigned int b)

Performs per-halfword absolute difference of unsigned integer computation: |a - b|.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute difference. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsdiffu4 (unsigned int a, unsigned int b)

Computes per-byte absolute difference of unsigned integer.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute difference. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsss2 (unsigned int a)

Computes per-halfword absolute value with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes, then computes absolute value with signed saturation for each of parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vabsss4 (unsigned int a)

Computes per-byte absolute value with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte, then computes absolute value with signed saturation for each of parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vadd2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed addition, with wrap-around: a + b.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs unsigned addition on corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vadd4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed addition.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte, then performs unsigned addition on corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vaddss2 (unsigned int a, unsigned int b)

Performs per-halfword addition with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs addition with signed saturation on corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vaddss4 (unsigned int a, unsigned int b)

Performs per-byte addition with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte, then performs addition with signed saturation on corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vaddus2 (unsigned int a, unsigned int b)

Performs per-halfword addition with unsigned saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs addition with unsigned saturation on corresponding parts.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vaddus4 (unsigned int a, unsigned int b)

Performs per-byte addition with unsigned saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte, then performs addition with unsigned saturation on corresponding parts.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vavgs2 (unsigned int a, unsigned int b)

Performs per-halfword signed rounded average computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. then computes signed rounded avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vavgs4 (unsigned int a, unsigned int b)

Computes per-byte signed rounder average.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes signed rounded avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vavgu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned rounded average computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. then computes unsigned rounded avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vavgu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned rounded average.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes unsigned rounded avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpeq2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

Returns

Returns 0xffff computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if they are equal, and 0000 otherwise. For example __vcmpeq2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpeq4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

Returns

Returns 0xff if a = b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if they are equal, and 00 otherwise. For example __vcmpeq4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpges2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: $a \ge b$? 0xffff : 0.

Returns

Returns 0xffff if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part >= 'b' part, and 0000 otherwise. For example __vcmpges2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpges4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 0xff if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part >= 'b' part, and 00 otherwise. For example __vcmpges4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgeu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: $a \ge b$? 0xffff : 0.

Returns

Returns 0xffff if a >= b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part >= 'b' part, and 0000 otherwise. For example __vcmpgeu2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgeu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 0xff if a = b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part >= 'b' part, and 00 otherwise. For example __vcmpgeu4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a > b ? 0xffff : 0.

Returns

Returns 0xffff if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part > 'b' part, and 0000 otherwise. For example __vcmpgts2(0x1234aba5, 0x1234aba6) returns 0x00000000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 0xff if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part > 'b' part, and 00 otherwise. For example __vcmpgts4(0x1234aba5, 0x1234aba6) returns 0x00000000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgtu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a > b ? 0xffff : 0.

Returns

Returns 0xffff if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part > 'b' part, and 0000 otherwise. For example __vcmpgtu2(0x1234aba5, 0x1234aba6) returns 0x00000000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpgtu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 0xff if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part > 'b' part, and 00 otherwise. For example __vcmpgtu4(0x1234aba5, 0x1234aba6) returns 0x00000000.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmples2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a <= b ? 0xffff : 0.

Returns

Returns 0xffff if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part <= 'b' part, and 0000 otherwise. For example __vcmples2(0x1234aba5, 0x1234aba6) returns 0xffffffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmples4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 0xff if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part <= 'b' part, and 00 otherwise. For example __vcmples4(0x1234aba5, 0x1234aba6) returns 0xffffffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpleu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: $a \le b$? 0xffff : 0.

Returns

Returns 0xffff if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part <= 'b' part, and 0000 otherwise. For example __vcmpleu2(0x1234aba5, 0x1234aba6) returns 0xffffffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpleu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 0xff if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part <= 'b' part, and 00 otherwise. For example __vcmpleu4(0x1234aba5, 0x1234aba6) returns 0xffffffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmplts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a < b ? 0xffff : 0.

Returns

Returns 0xffff if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part < 'b' part, and 0000 otherwise. For example __vcmplts2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmplts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 0xff if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part < 'b' part, and 00 otherwise. For example __vcmplts4(0x1234aba5, 0x1234aba6) returns 0x0000000ff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpltu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a < b ? 0xffff : 0.

Returns

Returns 0xffff if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part < 'b' part, and 0000 otherwise. For example __vcmpltu2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpltu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 0xff if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part < 'b' part, and 00 otherwise. For example __vcmpltu4(0x1234aba5, 0x1234aba6) returns 0x000000ff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpne2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison: a != b ? 0xffff : 0.

Returns

Returns 0xffff if a != b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part != 'b' part, and 0000 otherwise. For example __vcmplts2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vcmpne4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

Returns

Returns 0xff if a != b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part != 'b' part, and 00 otherwise. For example __vcmplts4(0x1234aba5, 0x1234aba6) returns 0x000000ff.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vhaddu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned average computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. then computes unsigned avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vhaddu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned average.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes unsigned avarege of corresponding parts. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmaxs2 (unsigned int a, unsigned int b)

Performs per-halfword signed maximum computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes signed maximum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmaxs4 (unsigned int a, unsigned int b)

Computes per-byte signed maximum.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes signed maximum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmaxu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned maximum computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes unsigned maximum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmaxu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned maximum.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes unsigned maximum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmins2 (unsigned int a, unsigned int b)

Performs per-halfword signed minimum computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes signed minimum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vmins4 (unsigned int a, unsigned int b)

Computes per-byte signed minimum.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes signed minimum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vminu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum computation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes unsigned minimum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vminu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned minimum.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes unsigned minimum. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vneg2 (unsigned int a)

Computes per-halfword negation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes. For each part function computes negation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vneg4 (unsigned int a)

Performs per-byte negation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte. For each part function computes negation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vnegss2 (unsigned int a)

Computes per-halfword negation with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes. For each part function computes negation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vnegss4 (unsigned int a)

Performs per-byte negation with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte. For each part function computes negation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsads2 (unsigned int a, unsigned int b)

Performs per-halfword sum of absolute difference of signed.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts functions computes absolute difference and sum it up. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsads4 (unsigned int a, unsigned int b)

Computes per-byte sum of abs difference of signed.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts functions computes absolute difference and sum it up. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsadu2 (unsigned int a, unsigned int b)

Computes per-halfword sum of abs diff of unsigned.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute differences, and returns sum of those differences.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsadu4 (unsigned int a, unsigned int b)

Computes per-byte sum af abs difference of unsigned.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute differences, and returns sum of those differences.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vseteq2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

Returns

Returns 1 if a = b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part == 'b' part. If both equalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vseteq4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

Returns

Returns 1 if a = b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part == 'b' part. If both equalities are satisfiad, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetges2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

Returns

Returns 1 if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetges4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 1 if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgeu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum unsigned comparison.

Returns

Returns 1 if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgeu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 1 if $a \ge b$, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

Returns

Returns 1 if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 1 if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgtu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison.

Returns

Returns 1 if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetgtu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 1 if a > b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetles2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum computation.

Returns

Returns 1 if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetles4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 1 if a \leq b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetleu2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

Returns

Returns 1 if a \leq b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetleu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 1 if a <= b, else returns 0.

Description

Splits 4 bytes of each argument into 4 part, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetlts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

Returns

Returns 1 if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetlts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

Returns

Returns 1 if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetltu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison.

Returns

Returns 1 if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetltu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

Returns

Returns 1 if a < b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetne2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

Returns

Returns 1 if a != b, else returns 0.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part != 'b' part. If both conditions are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsetne4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

Returns

Returns 1 if a != b, else returns 0.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part != 'b' part. If both conditions are satisfied, function returns 1.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsub2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed substraction, with wrap-around.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts functions performs substraction. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsub4 (unsigned int a, unsigned int b)

Performs per-byte substraction.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts functions performs substraction. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsubss2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed substraction, with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts functions performs substraction with signed saturation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsubss4 (unsigned int a, unsigned int b)

Performs per-byte substraction with signed saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts functions performs substraction with signed saturation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsubus2 (unsigned int a, unsigned int b)

Performs per-halfword substraction with unsigned saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts functions performs substraction with unsigned saturation. Result is stored as unsigned int and returned.

__DEVICE_FUNCTIONS_DECL__ unsigned int __vsubus4 (unsigned int a, unsigned int b)

Performs per-byte substraction with unsigned saturation.

Returns

Returns computed value.

Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts functions performs substraction with unsigned saturation. Result is stored as unsigned int and returned.

Notice

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, NVIDIA Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. No license is granted by implication of otherwise under any patent rights of NVIDIA Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all other information previously supplied. NVIDIA Corporation products are not authorized as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2007-2015 NVIDIA Corporation. All rights reserved.

