



RykerConnect REV05 USB



BT1




OLED




J1 1:5V 2:GND

LIGHT




SENSOR



USB < N16R8-M > ANT

J6



J8: REMOVE FOR USB