

Simple LCD API

Development Documentation

V1.1.0

Update Records

Date	Description
2023-04-23	First Edition Release
2024-06-20	Update API and documentation

Contents

- 1 Introduction
- 1.1 SimpleSubLcd Class
 - 1.1.1 Get the smile screen control object
 - 1.1.2 Init
 - 1.1.3 Release
 - 1.1.4 Show
 - 1.1.5 Get the version
 - 1.1.6 Update the MCU firmware

1 Introduction

1.1 SimpleSubLcd Class

1.1.1 Get the smile screen control object

```
/**
 * @Function Get the smile screen control object
 *
 * @Parameter context
 *
 * */

public SimpleSubLcd(Context context)
```

1.1.2 Init

```
/**
 * @Function Init LCD
 *
 * @Return ResultCode: please refer the quick guidance document.
 *
 * */

public synchronized int init()
```

1.1.3 Release

```
/**
 * @Function Release LCD
 *
 * */

public synchronized void release()
```

1.1.4 Show

```
/**
 * @Function Show the picture
 *
 * @Parameter
 * 1.picFile: Image path, the format needs to be supported by the module
 *
```

```
* @Return: ResultCode: please refer the quick guidance document.  
*  
* */  
  
public synchronized int show(String picFile)
```

1.1.5 Get the version

```
/**  
 * @Function Get the version  
 *  
 * @Return Version number  
 *  
 * */  
  
public synchronized String getVersion()
```

1.1.6 Update the MCU firmware

```
/**  
 * @Function Update the MCU firmware  
 *  
 * @Parameter  
 * 1.binFile: File path  
 *  
 * @Return ResultCode: please refer the quick guidance document.  
 *  
 * */  
  
Public synchronized int update(String binFile)
```