

Demo SDK for Android

Quick Guidance Manual

V1.1.0

Update Records

Date	Description
2022-10-26	First Edition Release
2023-02-28	Updated model options
2023-04-23	Update API
2024-06-20	Update API and documentation

Contents

- 1 Programming Reference
 - 1.1 AAR Installation Guide
 - 1.2 Initialize the API Class
 - 1.3 API Class Description
- 2 Common Constants
 - 2.1 Led Type
 - 2.2 Led Color
 - 2.3 Wiegand Type
 - 2.4 Wiegand Direction
 - 2.5 Input Type
 - 2.6 Input Status
 - 2.7 GPIO Direction
 - 2.8 GPIO Level
 - 2.9 GPIO Type
 - 2.10 RS232 Type
 - 2.11 RS485 Type
 - 2.12 RSTTL Type
 - 2.13 RS Mode
 - 2.14 Relay Type
 - 2.15 Password Type
 - 2.16 Card Type
 - 2.17 Wallet Operate
 - 2.18 Sensor Type
- 3 Appendix
 - 3.1 Result Code
 - 3.1.1 System error
 - 3.1.2 58mm Thermal Printing Error
 - 3.2 IC Exception
 - 3.3 NFC Exception
 - 3.4 Magnetic Card Exception
 - 3.5 Print Exception
 - 3.6 Can Exception

1 Programming Reference

1.1 AAR Installation Guide

Create a new Android Studio project and copy the AAR package to the libs directory, and Configure the file “app/build.gradle”

```
dependencies{  
    implementation files('libs/xxxxxxx.aar')  
}
```

1.2 Initialize the API Class

SDKUtil.getInstance(this).initSDK()

1.3 API Class Description

This part is only used to describe the SDK demo code, please refer to the API documentation for details.

2 Common Constants

Package: com.common.apiutil.pos

2.1 Led Type

Type	Description
LedType.COLOR_LED_1	Colored light 1
LedType.COLOR_LED_2	Colored light 2
LedType.COLOR_LED_3	Colored light 3
LedType.COLOR_LED_4	Colored light 4
LedType.FILL_LIGHT_1	Fill light 1
LedType.FILL_LIGHT_2	Fill light 2
LedType.LASER_LED_1	Laser light 1

2.2 Led Color

Type	Description
LedColor.WHITE_LED	White light
LedColor.RED_LED	Red light
LedColor.GREEN_LED	Green light
LedColor.BLUE_LED	Blue light
LedColor.YELLOW_LED	Yellow light
LedColor.ORANGE_LED	Orange light

2.3 Wiegand Type

Type	Description
WiegandType.WG_26	Send the 26 bit data
WiegandType.WG_34	Send the 34 bit data
WiegandType.WG_SPECIAL	Send customizations

2.4 Wiegand Direction

Type	Description
WiegandDirection.INPUT	Wiegand input

Type	Description
WiegandDirection.OUTPUT	Wiegand output

2.5 Input Type

Type	Description
InputType.WIEGAND_INPUT	Wiegand input
InputType.DOOR_INPUT	Door magnetic input

2.6 Input Status

Type	Description
InputStatus.SWITCH_OPEN_INPUT1	Open: 1, Close: 2
InputStatus.SWITCH_OPEN_INPUT2	Open: 2, Close: 1

2.7 GPIO Direction

Type	Description
GPIONDirection.INPUT	GPIO Input
GPIONDirection.OUTPUT	GPIO Output

2.8 GPIO Level

Type	Description
GPIOLevel.LOW_LEVEL	GPIO Low Level
GPIOLevel.HIGH_LEVEL	GPIO High Level

2.9 GPIO Type

Type	Description
GPIONType.GPIO41	GPIO41
GPIONType.GPIO144	GPIO144
GPIONType.GPIO145	GPIO145
GPIONType.GPIO152	GPIO152

2.10 RS232 Type

Type	Description
------	-------------

Type	Description
RS232Type.Type.RS232_1	First: RS232
RS232Type.Type.RS232_2	Second: RS232

2.11 RS485 Type

Type	Description
RS485Type.Type.RS485_1	First: RS485
RS485Type.Type.RS485_2	Second: RS485

2.12 RSTTL Type

Type	Description
RS485Type.Type.RSTTL_1	First: RSTTL
RS485Type.Type.RSTTL_2	Second: RSTTL

2.13 RS Mode

Type	Description
RSMODE.SEND_MODE	RS Send Mode
RSMODE.RECV_MODE	RS Receive Mode

2.14 Relay Type

Type	Description
RelayType.RELAY_1	Relay1
RelayType.RELAY_2	Relay2
RelayType.RELAY_3	Relay3

2.15 Password Type

Type	Description
PasswordType.KEYA	KEYA
PasswordType.KEYB	KEYB

2.16 Card Type

Type	Description
------	-------------

Type	Description
CardType.MifareClassic	M1 Card
CardType.CPU	CPU Card

2.17 Wallet Operate

Type	Description
WalletOperate.ADD	Add
WalletOperate.SUB	Sub

2.18 Sensor Type

Type	Description
SensorType.INFRARED_SENSOR	Infrared sensor
SensorType.TAMPER_SENSOR	Tamper sensor
SensorType.PHYSICALKEY_SENSOR	Physical key sensor
SensorType.MAGNETICSENSITIVECIRCUIT_SENSOR	Magnetic sensitive circuit sensor
SensorType.LIGHT_SENSOR	Light sensor
SensorType.SUMP_TAMPER_SENSOR	Sump tamper sensor
SensorType.WAVE_SENSOR	Wave sensor
SensorType.DOOR_SENSOR	Door sensor
SensorType.DOOR_LOCK_SENSOR	Door lock sensor
SensorType.MAGNETICINDUCTIONCIRCUIT_SENSOR_1	Magnetic induction circuit sensor 1
SensorType.MAGNETICINDUCTIONCIRCUIT_SENSOR_2	Magnetic induction circuit sensor 2
SensorType.RGBCAMERA_TEMPERATURESENSOR	RGB camera temperature sensor
SensorType.RIGHTCAMERA_TEMPERATURESENSOR	Right camera temperature sensor
SensorType.LEFTCAMERA_TEMPERATURESENSOR	Left camera temperature sensor

3 Appendix

3.1 ResultCode

3.1.1 System error

Return	Description
SUCCESS	The operation succeeded
FAIL	The operation failed
ERR_SYS_UNEXPECT	Unknown error
ERR_SYS_NOT_SUPPORT	Not support
ERR_SYS_INVALID	Illegal parameter
ERR_SYS_NO_DEV	Device not found
ERR_SYS_NO_INIT	The device or resource is not initialized
ERR_SYS_ALREADY_INIT	The device or resource has been initialized
ERR_SYS_NO_PERMISSION	No permissioned access
ERR_SYS_LOW_POWER	The device has a low battery
ERR_SYS_ALREADY_OPEN	The device is opened
ERR_SYS_ALREADY_CLOSE	The device is closed
ERR_SYS_OVER_FLOW	Insufficient cache
ERR_SYS_TIMEOUT	The operation timed out

3.1.2 58mm thermal printing error

Return	Description	Value
ERR_PRN_NO_PAPER	The printer is out of paper	0x10
ERR_PRN_OVER_TEMP	The printer is overheating	0x11
ERR_PRN_NO_BLACK_BLOCK	Black block not found	0x12
ERR_PRN_FONT	Printing font error	0x13
ERR_PRN_LOW_POWER	The printer has a low battery	0x14
ERR_PRN_BROKEN	The printer movement is disassembled	0x15

Return	Description	Value
ERR_PRN_NOT_AUTH	Failed to print the manufacturer's code authentication	0x16
ERR_PRN_BOX_OPEN	The lid of the printer is not closed	0x17
ERR_PRN_CUT_WRONG	Abnormal paper cutting	0x18

3.2 IC Exception

Exception	Description
NullPointerException	The input parameter is empty
InvalidParameterException	Parameter error
CommonException	All exceptions

3.3 NFC Exception

Exception	Description
WrongParamException	Parameter error
ReadWalletMoneyWrongException	Read Wallet error exception
NotInitWalletException	Wallet does not initialize exceptions
NoClassObjectsException	The required class was not found

3.4 Magnetic Card Exception

Exception	Description
DeviceNotOpenException	Thrown when the head is not turned on
InternalErrorException	Internal error
TimeoutException	Thrown when the timeout is not swiped
DeviceAlreadyOpenException	Thrown when the magnetic card is already turned on
DeviceNotFoundException	Generated when the magnetic card cannot be found

3.5 Print Exception

Exception	Description
CommonException	All exceptions
NoPaperException	The printer is out of paper abnormally

Exception	Description
OverHeatException	The printer is overheating
GateOpenException	The printer paper magazine is open abnormally
PaperCutException	Abnormal paper cutting
TimeoutException	Time out
FontErrorException	Unsupported font exception
LowPowerException	Low power

3.6 CAN Exception

Exception	Description
com.common.apiutil.CommonException	The parameter is exceptional, the ID is not hexadecimal and starts with 0, or the frame format is not standard frame or extended frame, or the frame type is not data frame or remote frame.
com.common.apiutil.can.WrongParamException	Parameter error, ID not hexadecimal.