MGE USB Devices HID Description for NUT

référence: 34003616 ZA reference n°

indice : AA index

page : 1/70

			ı	1		
АА	6/12/2001	Edition originale / First Issue	D.Lallement		Jl.Philippe	
			Nom Name	Visa	Nom Name	Visa
Ind	date	te Modification	Réalisé par Prepared by		Approuvé par Approved by	

USB/HID UPS Devices



Intellectual Property Provision and Limitation of Liability

ref: 34003616 ZA index: AA page 2/70

INFORMATION AND SPECIFICATION ARE PROVIDED "AS ARE" WITH NO WARRANTIES WHATSOEVER INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY INFORMATION, PROPOSAL, SPECIFICATION, OR SAMPLE.

INFORMATION AND SPECIFICATION PROVIDED HEREIN ARE AND SHALL REMAIN MGE UPS SYSTEMS SOLE PROPERTY. A LICENSE IS HEREBY GRANTED TO REPRODUCE AND DISTRIBUTE INFORMATION AND SPECIFICATIONS PROVIDED FOR NUT OPEN SOURCE PROJECT USE ONLY. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY OTHER INTELLECTUAL PROPERTY RIGHTS IS GRANTED OR INTENDED HEREBY.

AUTHORS OF THE INFORMATION AND SPECIFICATION PROVIDED DISCLAIM ALL LIABILITY, INCLUDING LIABILITY FOR INFRINGEMENT OF PROPRIETARY RIGHTS, RELATING TO IMPLEMENTATION OF INFORMATION IN THIS SPECIFICATION. AUTHORS ALSO DO NOT WARRANT OR REPRESENT THAT SUCH IMPLEMENTATION(S) WILL NOT INFRINGE SUCH RIGHTS.

All product names are trademarks, registered trademarks, or service marks of their respective owners.

Contributors

Company	Contact	E-mail alias	
MGE UPS SYSTEMS	Luc Descotils	luc.descotils@mgeups.com	
MGE UPS SYSTEMS	Dominique L. Lallement (Editor)	dominique.lallement@mgeups.com	
MGE UPS SYSTEMS	Jerome Lecuivre	jerome.lecuivre@mgeups.com	
MGE UPS SYSTEMS	Jean-Luc Philippe	jean-luc.philippe@mgeups.com	
Silicomp Ingénierie	Arnaud Quette	arnaud.quette@silicomp.fr	

Table of Contents

1.	INTRODUCTION	4
2.	USB ENABLED RANGE OVERVIEW	5
2.1	Generic UPS	5
2.2	UPS Range Identification	6
3.	PULSAR ELLIPSE	7
3.1	The Ellipse Collection tree	7
3.2	The Ellipse HID report descriptor	8
4.	PULSAR ELLIPSE PREMIUM	12
4.1	The Ellipse Premium Collection tree	12
4.2	The Ellipse Premium HID report descriptor	13
5.	PULSAR EVOLUTION 500/800/1100 RANGE	18
5.1	The Evolution 500/800/1100 Collection tree	19
5.2	The Evolution 500/800/1100 HID report descriptor	20
6.	PULSAR EVOLUTION 1500/2200/3000 RANGE	30
6.1	The Evolution 1500/2200/3000 Collection tree	31
6.2	The Evolution 1500/2200/3000 HID report descriptor	32
7.	PULSAR EXTREME C RANGE	44
7.1	The Extreme C Collection tree	45
7.2	The Extreme C HID report descriptor	46
8.	PULSAR ESPRIT RANGE	58
8.1	The Esprit Collection tree	59
8.2	The Esprit HID report descriptor	60
List	t of Figures	
Figure	e 1: Generic UPS	5
Figure	e 2: Pulsar Ellipse UPS	7
Figure	e 3: Pulsar Ellipse Premium UPS	12
Figure	e 4: Pulsar Evolution 500/800/1100 UPS	18
Figure	e 5: Pulsar Evolution 500/800/1100 UPS	30
Figure	e 6: Pulsar Extreme C UPS	44
Figure	e 7: Pulsar Esprit UPS	58

1. Introduction

This document defines the communication of various MGE UPS Power Device (**UPS**) within the Universal Serial Bus (**USB**) protocol as a Human Interface Device (**HID**). It provides information to guide OS, BIOS and Power management software designers in using the MGE UPS implementation of logical structures for Power Devices Class. It is assumed that the reader is familiar with the USB and HID Specification and HID Usage Tables and HID Power Device Class usages and reports (See **Related Documents** table).

ref: 34003616 ZA index: AA page 4/70

- ?? Section 2, presents an overview of MGE UPS USB enabled ranges.
- ?? Section 3 to 8 presents models, collection trees and HID Report descriptors of the various ranges of UPS
- ?? Section 9, presents common on/off sequences for various UPS ranges

Related Documents

Title	Location	Description	
Universal Serial Bus HID Usage Tables for Power devices. Version 1.0	Also referred to as the Power Device Class ; posted at www.usb.org	This document defines the communication and Usage Tables of HID Power Devices.	
Universal Serial Bus Device Class Definition for Human Interface Devices (HID) Version 1.1	Also referred to as the HID Class Specification; posted at www.usb.org	This document describes the Human Interface Device (HID) class for use with Universal Serial Bus (USB).	
Universal Serial Bus HID Usage Tables, Revision 1.1	Also referred to as the HID Usage Tables Document; posted at www.usb.org	Many usages are defined within the USB Specification. This document is the most current and complete list of defined usages.	
Universal Serial Bus Revision 2.0 Specification	Also referred to as the USB Specification; posted at www.usb.org	This document defines an industry standard Universal Serial Bus.	

Terms and Abbreviations

AC	Alternating Current.
DC	Direct Current.
HID	Human Interface Device. For definitions of the following HID terms, see the HID Specification and HID Usage Tables: COLLECTION, FEATURE, HID DESCRIPTOR, INPUT, ITEM, LOGICAL MAXIMUM, LOGICAL MINIMUM, OUTPUT, REPORT COUNT, REPORT, REPORTSIZE, UNIT, UNITEXPONENT, USAGE PAGE, USAGE
MGE	MGE UPS SYSTEMS
UPS	Uninterruptible Power Supply.
USB	Universal Serial Bus. For definitions of the following USB terms, see the USB Specification. DEVICE DESCRIPTOR

2. USB Enabled Range Overview

2.1 Generic UPS

The generic UPS model implemented for MGE Devices is compliant with Power Device Class. In particular, collections hierarchy and usages trees, engineering physical units implementation, semantic of usage follow the recommendations defined in this specification. The following figure presents an example of a generic and complete model of UPS

ref: 34003616 ZA index: AA page 5/70




Figure 1: Generic UPS

Actual implementation of Power Device Class populates collection and items depending availability of hardware and software function and availability of data in the control part of the UPS. For instance, an UPS may or may not includes Outlet System, it may or may not includes a Bypass (Backup AC). In addition, small legacy UPS have few memory and processor resources, so few collections and items are made available trough USB communication. In any case mandatory collections and items according to the Power Device Class specification are present

To identify multiple instances of some collections (like Input, Output, Flow, Outlet ..), each collection is indexed by an ID. To facilitate UPS management application, MGE assign common values to ID's.

FlowId = 1	Mains AC	
FlowId $= 2$	Backup AC (for manual bypass)	
FlowId $= 3$	Backup DC emergency power supply.	
FlowId $= 4$	Main AC output.	
InputId = 1	Mains AC input.	
InputId $= 2$	AC Input for automatic transfer	
InputId $= 3$	DC input.	
InputId = 4	AC input for manual bypass	
	FlowId = 2 FlowId = 3 FlowId = 4 InputId = 1 InputId = 2 InputId = 3	

For Outlet: OutletID corresponds to identification drawn near the corresponding outlet (a gang or an individual)

For all modules and parts that appears only a time, the 1 value will be used. (E.G. BatterySystemID = 1, BatteryID = 1, PowerConverter D = 1, PowerConverter output: OutputID = 1).

To facilitate recognition of collections some collection are Vendor defined [e.g. 0xa1, 0x81, // COLLECTION (VendorDefined)]. The second byte of the code [i.e. 0x81] gives ID value [i.e. 1].

2.2 UPS Range Identification

For all products in standard USB Device Descriptor : IdVendor = 0x0463

For "Pulsar Ellipse Premium", "Pulsar Evolution", "Pulsar Extreme C" and "Pulsar Esprit" ranges:

iManufacturer = index to string: "MGE UPS SYSTEMS"

Each range is identify by IDProduct and iProduct

For each model in a range (except Pulsar Ellipse) is identify by a MGE vendor specific item (iModel) located inside the PowerSummary collection.

ref: 34003616 ZA index: AA page 6/70

For "Pulsar Ellipse":

iManufacturer string is "MGE"

iModel item is not present, then model in the Range is identified in Flow(4)/ConfigApparentPower item

Name	IDProduct	iProduct index to string:	iModel index to string	Range Description
Pulsar Ellipse	0xFFFF	"ELLIPSE"	Not Present	300, 500 and 800 VA UPS for Home/Office PC and workstation protection
Pulsar Ellipse Premium	0xFFFF	"ellipse"	"PR500","PR650" "PR800","PR1200"	500, 650, 800, 1200 VA UPS for workstation and small server protection
Pulsar Evolution 500/800/1100	0x0001	"Evolution"	"500","800","1100"	500, 800, 1100 VA UPS for PC Server and storage protection
Pulsar Evolution 1500/2200/3000	0xFFFF	"Evolution"	"1500","2200","3000"	1500, 2200, 3000 VA UPS for PC Server and storage protection
Pulsar Extreme C	0xFFFF	"EXTREME"	"1500","2000" "2500", "3000"	1500, 2000, 2500, 3000 VA UPS for Unix Server & Storage Protection
Pulsar Esprit	0xFFFF	"ESPRIT"	"1.4","3.1","4.5","6","9"	1.4 / 3.1 / 4.5 / 6 / 9 kVA UPS for WEB Server Protection

Complete information about Pulsar ranges is posted at: www.mgeups.com

On Product area: Product and Application descriptions

On Download area: Documentation (Data Sheet, Quick Start and User Manual)

On Download area: Free Power Management Software packages

Pulsar Extreme, Comet Extreme, Galaxy 3000 and Galaxy PW with USBI option card are USB enabled. Their HID descriptors will be available in a later version of the present document.

3. Pulsar Ellipse

Intended for PC and Mac users, **Pulsar** *Ellipse* protects home and office configurations ranging from standalone PCs to workgroup servers. (USB or RS232 port, local outlets, Stand by)

ref: 34003616 ZA index: AA page 7/70






Figure 2: Pulsar Ellipse UPS

3.1 The Ellipse Collection tree

Collection UPS

Collection PowerConverter

Collection Output

Collection Flow (4:AC Output)

Collection PowerSummary

Collection OutletSystem

Collection Outlet (1:Non Switchable)

Collection Outlet (2:Switchable)

3.2 The Ellipse HID report descriptor

```
char ReportDescriptor[532] = {
```

```
0xa1, 0x00,
                      // COLLECTION (Physical)
0x09, 0x25,
                      // USAGE (PowerSummaryID)
                      //
                          USAGE (FlowID)
                         USAGE (CommunicationLost)
REPORT_ID (1)
0x09, 0x73,
                      //
0x85, 0x01,
                      //
```

```
ref: 34003616 ZA index: AA

// COLLECTION (Physical)
// USAGE (OutletSystemID)
// REPORT_ID (11)
// REPORT_SIZE (8)
// REPORT_COUNT (1)
// UNIT (None)
// LOGICAL_MINIMUM (0)
// LOGICAL_MINIMUM (0)
// LOGICAL_MAXIMUM (255)
// FEATURE (Cnst, Var, Abs)
// USAGE (Outlet)
// COLLECTION (VendorDefined)
// SAGE (Outlet)
// FEATURE (Cnst, Var, Abs)
// USAGE (FlowID)
// FEATURE (Cnst, Var, Abs)
// USAGE (PresentStatus)
// COLLECTION (Logical)
// USAGE (Switchable)
// REPORT_ID (12)
// LOGICAL_MAXIMUM (1)
// FEATURE (Cnst, Var, Abs)
// USAGE (Outlet)
// LOGICAL_MAXIMUM (1)
// FEATURE (Cnst, Var, Abs)
// END_COLLECTION
// USAGE (Outlet)
// COLLECTION (VendorDefined)
// USAGE (Outlet)
// COLLECTION (VendorDefined)
// USAGE (Outlet)
// REPORT_ID (11)
// REPORT_ID (13)
// FEATURE (Cnst, Var, Abs, Vol)
// USAGE (PresentStatus)
// COLLECTION (Logical)
// USAGE (PresentStatus)
// COLLECTION (Logical)
// USAGE (PresentStatus)
// COLLECTION (Logical)
// USAGE (Switchable)
// USAGE (Switchable)
// REPORT_ID (3)
// REPORT_ID (3)
// REPORT_ID (3)
// REPORT_SIZE (1)
// INPUT (Cnst, Var, Abs, Vol)
// USAGE (Switchon/Off)
// FFATURE (Cnst, Var, Abs, Vol)
// USAGE (Switchon/Off)
// FFATURE (Cnst, Var, Abs, Vol)
// USAGE (Switchon/Off)
// FFATURE (Cnst, Var, Abs, Vol)
// USAGE (Switchon/Off)
// FFATURE (Cnst, Var, Abs, Vol)
// USAGE (Switchon/Off)
// REPORT_ID (3)
// REPORT_ID (3)
// REPORT_SIZE (7)
// INPUT (Cnst, Var, Abs, Vol)
// USAGE (Undefined)
// FFATURE (Cnst, Var, Abs)
// ENDORT_SIZE (8)
// REPORT_SIZE (8)
            0xa1, 0x00,
            0x09, 0x19,
            0x85, 0x0b,
            0x75, 0x08,
            0x95, 0x01,
            0x65, 0x00,
            0x55, 0x00,
            0x15, 0x00,
            0x26, 0xff, 0x00,
            0xb1, 0x03,
            0x09, 0x20,
            0xa1, 0x81,
            0x09, 0x21,
            0xb1, 0x03,
            0x09, 0x1f,
            0xb1, 0x03,
            0x09, 0x02,
            0xa1, 0x02,
            0x09, 0x6c,
            0x85, 0x0c,
            0x25, 0x01,
            0xb1, 0x03,
            0xc0,
            0xc0,
            0x09, 0x20,
            0xa1, 0x82,
            0x09, 0x21,
            0x85, 0x0b,
            0x26, 0xff, 0x00,
            0xb1, 0x03,
            0x09, 0x1f,
            0x85, 0x0d,
            0xb1, 0x83,
            0x09, 0x02,
            0xa1, 0x02,
            0x09, 0x6c,
            0x25, 0x01,
            0xb1, 0x83,
            0x09, 0x6b,
            0x85, 0x03,
            0x75, 0x01,
            0x81, 0x83,
            0x09, 0x6b,
            0xb1, 0x83,
            0x09, 0x00,
            0x75, 0x07,
            0x81, 0x03,
            0x09, 0x00,
            0xb1, 0x03,
            0xc0.
            0x0b, 0x29, 0x00, 0x85, 0x00, //
System:RemainingCapacityLimit)
                                                                                                              // REPORT_ID (20)
// REPORT_SIZE (8)
// REPORT_COUNT (1)
// UNIT (None)
// LOGICAL_MAXIMUM (100)
// FEATURE (Data, Var, Abs, Vol)
// END_COLLECTION
            0x85, 0x14,
            0x75, 0x08,
            0x95, 0x01,
                                                                                                              //
            0x65, 0x00,
                                                                                                             //
            0x25, 0x64,
            0xb1, 0x82,
                                                                                                            //
                                                                                                             //
            0 \times c0.
                                                                                                              // END COLLECTION
            0xc0,
            0xc0
                                                                                                             // END_COLLECTION
};
```

4. Pulsar Ellipse Premium

Pulsar *ellipse premium* is the UPS is intend to maximize the availability of PCs, workstations and small servers used by home office users and small/medium businesses. (Line Interactive, USB or Serial port, Local outlets, Programmable outlets)






Figure 3: Pulsar Ellipse Premium UPS

4.1 The Ellipse Premium Collection tree

Collection UPS

Collection PowerConverter

Collection Output

Collection Flow (4:AC Output)

Collection PowerSummary

Collection OutletSystem

Collection Outlet (1:Non Switchable)

Collection Outlet (2:Switchable)

4.2 The Ellipse Premium HID report descriptor

```
char ReportDescriptor[568] = {
  0x05, 0x84,
                    // USAGE_PAGE (Power Device)
                   // USAGE (UPS)
  0x09, 0x04,
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

//

//

//

0x75, 0x08,

0x25, 0x64,

0xb1, 0x03,

REPORT_SIZE (8)

LOGICAL_MAXIMUM (100)

FEATURE (Cnst, Var, Abs)

// FEATURE (Cnst,Var,Abs)

// END_COLLECTION

// USAGE_PAGE (Power Device)

// USAGE (DelayBeforeShutdown)

// REPORT_ID (15)

// REPORT_SIZE (24)

// REPORT_COUNT (1)

// UNIT (SI Lin:Time)

// LOGICAL_MINIMUM (-1)

// LOGICAL_MAXIMUM (65534)

// FEATURE (Data,Var,Abs,Vol)

// USAGE (DelayBeforeStartup)

// REPORT_ID (17)

// UNIT_EXPONENT (1)

// FEATURE (Data,Var,Abs,Vol)

// END_COLLECTION 0x95, 0x01, 0x66, 0x01, 0x10, 0x15, 0xff, 0x27, 0xfe, 0xff, 0x00, 0x00, // 0xb1, 0x82, 0x09, 0x56,0x85, 0x11, 0x55, 0x01, // END_COLLECTION

0x75, 0x18,

0x75, 0x07,

0xb1, 0x82, 0xc0,0x09, 0x18,// USAGE (OutletSystem) 0xa1, 0x00, 0x09, 0x19, 0x85, 0x0b, 0x75, 0x08,0x95, 0x01,

0x65, 0x00,0x55, 0x00,0x15, 0x00, 0x26, 0xff, 0x00, 0xb1, 0x03, 0x09, 0x20,

USAGE (OutletSystem)

// COLLECTION (Physical)

// SAGE (OutletSystemID)

// REPORT_ID (11)

// REPORT_SIZE (8)

// UNIT (None)

// UNIT (None)

// LOGICAL_MINIMUM (0)

00, // LOGICAL_MINIMUM (255)

// FEATURE (Cnst,Var,Abs)

// USAGE (Outlet)

// USAGE (OutletID)

// FEATURE (Cnst,Var,Abs)

// USAGE (PlowID)

// FEATURE (Cnst,Var,Abs)

// USAGE (PresentStatus)

// COLLECTION (Logical)

// USAGE (Switchable)

// REPORT_ID (12)

// LOGICAL_MAXIMUM (1)

// FEATURE (Cnst,Var,Abs)

// END_COLLECTION

// USAGE (Outlet)

// COLLECTION (VendorDefined)

// USAGE (Outlet)

// COLLECTION (VendorDefined)

// USAGE (Outlet)

// COLLECTION (VendorDefined)

// USAGE (Outlet)

// REPORT_ID (11)

// LOGICAL_MAXIMUM (255)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (PresentStatus)

// COLLECTION (Logical)

// USAGE (PresentStatus)

// COLLECTION (Logical)

// USAGE (PresentStatus)

// COLLECTION (Logical)

// USAGE (Switchable)

// LOGICAL_MAXIMUM (1)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (Switchon/Off)

// REPORT_SIZE (1)

// INPUT (Cnst,Var,Abs,Vol)

// USAGE (Switchon/Off)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (Undefined)

// REPORT_SIZE (7)

Copyright © 2001, MGE UPS SYSTEMS

All rights reserved. 0xa1, 0x81, 0x09, 0x21, 0xb1, 0x03, 0x09, 0x1f, 0xb1, 0x03, 0x09, 0x02,0xa1, 0x02, 0x09, 0x6c, 0x85, 0x0c,

0x25, 0x01,0xb1, 0x03, 0xc0,0xc0,0x09, 0x20, 0xa1, 0x82,

0x09, 0x21, 0x85, 0x0b, 0x26, 0xff, 0x00, 0xb1, 0x03, 0x09, 0x1f, 0x85, 0x0d,

0xb1, 0x83, 0x09, 0x02, 0xa1, 0x02, 0x09, 0x6c, 0x25, 0x01, 0xb1, 0x83, 0x09, 0x6b,

0x85, 0x03,0x75, 0x01,0x81, 0x83, 0x09, 0x6b, 0xb1, 0x83, 0x09, 0x00,

All rights reserved.

MGE USB Devices ID Description for NUT

ref: 34003616 ZA index: AA page 17/70

```
// INPUT (Cnst,Var,Abs)
// USAGE (Undefined)
// FEATURE (Cnst,Var,Abs)
// END_COLLECTION
// USAGE (Battery
      0x81, 0x03,
      0x09, 0x00,
      0xb1, 0x03,
      0xc0,
      0x0b, 0x29, 0x00, 0x85, 0x00,
System:RemainingCapacityLimit)
                                                        // REPORT_ID (20)
// REPORT_SIZE (8)
// REPORT_COUNT (1)
// UNIT (None)
// LOGICAL_MAXIMUM (100)
// FEATURE (Data, Var, Abs, Vol)
      0x85, 0x14,
      0x75, 0x08,
      0x95, 0x01,
      0x65, 0x00,
      0x25, 0x64,
                                                     // FEATURE (Data
// END_COLLECTION
// END_COLLECTION
// END_COLLECTION
      0xb1, 0x82,
      0xc0,
      0xc0,
      0xc0
};
```

5. Pulsar Evolution 500/800/1100 Range

Pulsar *Evolution* is intended for networking equipment, rack-optimized servers, traditional rack and tower servers and network storage systems. (Line Interactive, 2 Switchable Outlets, USB and RS232 ports)






Figure 4: Pulsar Evolution 500/800/1100 UPS

5.1 The Evolution 500/800/1100 Collection tree

Collection UPS

Collection PowerSummary

Collection BatterySystem

Collection Input

Collection Battery

Collection Charger

Collection Output

Collection Flow (1:Main AC)

Collection Flow (3:Backup DC)

Collection Flow (4:AC Output)

Collection PowerConverter

Collection Input (1)

Collection Input (3)

Collection Output

Collection OutletSystem

Collection Outlet (1:Non Switchable)

Collection Outlet (2:Switchable)

Collection Outlet (3:Switchable)

5.2 The Evolution 500/800/1100 HID report descriptor

```
char ReportDescriptor[1300] = {
  0x05, 0x84,
                       // USAGE_PAGE (Power Device)
 0x09, 0x04,
                       // USAGE (UPS)
                      // COLLECTION (Physical)
  0xa1, 0x00,
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

```
// USAGE (Input)
// COLLECTION (Physical)
0x09, 0x1a,
0xa1, 0x00,
                                                    // COLLECTION (Physical)

// USAGE (InputID)

// REPORT_ID (17)

// LOGICAL_MAXIMUM (255)

// FEATURE (Cnst,Var,Abs)

// USAGE (FlowID)

// END_COLLECTION

// USAGE (Output)

// COLLECTION (Physical)

// USAGE (OutputID)

// USAGE (OutputID)

// USAGE (FlowID)

// FEATURE (Cnst,Var,Abs)

// USAGE (FlowID)

// FEATURE (Cnst,Var,Abs)

// USAGE (FlowID)

// FEATURE (Cnst,Var,Abs)

// END_COLLECTION
0x09, 0x1b,
0x85, 0x11,
0x26, 0xff, 0x00,
0xb1, 0x03,
0x09, 0x1f,
0xb1, 0x03,
0xc0,
0x09, 0x1c,
0xa1, 0x00,
0x09, 0x1d,
0xb1, 0x03,
0x09, 0x1f,
0xb1, 0x03,
                                                             END_COLLECTION
0xc0.
                                                     //
0xc0,
                                                     // END_COLLECTION
0x09, 0x1e,
                                                     // USAGE (Flow)
0xa1, 0x81,
                                                     // COLLECTION (VendorDefined)
                                                    // USAGE (FlowID)

// REPORT_ID (19)

// FEATURE (Cnst,Var,Abs)

// USAGE (ConfigFrequency)

// UNIT (SI Lin:Hertz)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (ConfigVoltage)

// REPORT_SIZE (16)

// LOGICAL_MAXIMUM (65535)

// UNIT (SI Lin:Volts)

// UNIT_EXPONENT (7)
                                                            USAGE (FlowID)
0x09, 0x1f,
0x85, 0x13,
0xb1, 0x03,
0x09, 0x42,
0x66, 0x01, 0xf0,
0xb1, 0x83,
0x09, 0x40,
0x75, 0x10,
0x27, 0xff, 0xff, 0x00, 0x00, //
0x67, 0x21, 0xd1, 0xf0, 0x00, //
0x55, 0x07,
0xb1, 0x83,
                                                      //
                                                                 FEATURE (Cnst, Var, Abs, Vol)
                                                            END_COLLECTION
0xc0,
                                                      //
                                                             USAGE (Flow)
0x09, 0x1e,
                                                      //
0xa1, 0x83,
                                                     //
                                                             COLLECTION (VendorDefined)
                                                            USAGE (FlowID)

REPORT_ID (19)

REPORT_SIZE (8)

LOGICAL_MAXIMUM (255)

UNIT (None)

UNIT_EXPONENT (0)

FEATURE (Cnst, Var, Abs)
0x09, 0x1f,
                                                     //
0x85, 0x13,
                                                     //
0x75, 0x08,
                                                     //
0x26, 0xff, 0x00,
                                                     //
0x65, 0x00,
                                                     //
0x55, 0x00,
                                                     //
0xb1, 0x03,
                                                     //
                                                     // END_COLLECTION
0xc0,
                                                     // USAGE (Flow)
0x09, 0x1e,
                                                           COLLECTION (VendorDefined)

USAGE (FlowID)

REPORT_ID (20)

FEATURE (Cnst,Var,Abs)

USAGE (ConfigFrequency)

UNIT (SI Lin:Hertz)

UNIT_EXPONENT (0)

FEATURE (Cnst,Var,Abs,Vol)

USAGE (ConfigActivePower)

REPORT_SIZE (16)

LOGICAL_MAXIMUM (65535)

UNIT (SI Lin:Power)

UNIT_EXPONENT (7)

FEATURE (Cnst,Var,Abs,Vol)

USAGE (ConfigApparentPower)

FEATURE (Cnst,Var,Abs,Vol)

USAGE (ConfigCurrent)

UNIT (SI Lin:Amps)

UNIT_EXPONENT (-2)
                                                     //
                                                            COLLECTION (VendorDefined)
0xa1, 0x84,
0x09, 0x1f,
                                                     //
0x85, 0x14,
                                                     //
0xb1, 0x03,
                                                     //
0x09, 0x42,
                                                     //
0x66, 0x01, 0xf0,
                                                     //
0x55, 0x00,
                                                     //
0xb1, 0x83,
                                                     //
0x09, 0x44,
                                                     //
0x75, 0x10,
                                                     //
0x27, 0xff, 0xff, 0x00, 0x00, //
0x66, 0x21, 0xd1,
                                                      //
0x55, 0x07,
                                                      //
0xb1, 0x83,
                                                      //
0x09, 0x43,
                                                      //
0xb1, 0x83,
                                                      //
0x09.0x41.
                                                      //
0x67, 0x01, 0x00, 0x10, 0x00, //
                                                              UNIT_EXPONENT (-2)
0x55, 0x0e,
                                                      //
0xb1, 0x83,
                                                      //
                                                               FEATURE (Cnst, Var, Abs, Vol)
0x09, 0x40,
                                                      //
                                                                  USAGE (ConfigVoltage)
```

```
REPORT_ID (21)
UNIT (SI Lin:Volts)
UNIT_EXPONENT (7)
FEATURE (Data,Var,Abs,Vol)
0x85, 0x15,
                               //
0x67, 0x21, 0xd1, 0xf0, 0x00, //
0x55, 0x07,
                              //
0xb1, 0x82,
0xc0,
0x09, 0x16,
0xa1, 0x00,
0x09, 0x17,
0x85, 0x17,
0x75, 0x08,
0x26, 0xff, 0x00,
0x65, 0x00,
0x55, 0x00,
0xb1, 0x03,
0x06, 0xff, 0xff,
0x09, 0x41,
0xb1, 0x03,
0x05, 0x84,
0x09, 0x1a,
0xa1, 0x81,
0x09, 0x1b,
0x85, 0x19,
0xb1, 0x03,
0x09, 0x1f,
0xb1, 0x03,
0x09, 0x32,
0x66, 0x01, 0xf0,
0xb1, 0x83,
0x09, 0x30,
0x75, 0x10,
0x27, 0xff, 0xff, 0x00, 0x00, //
0x67, 0x21, 0xd1, 0xf0, 0x00, //
0x55, 0x07,
0xb1, 0x83,
0x06, 0xff, 0xff,
0x09, 0x43,
0x85, 0x18,
0x75, 0x08,
0x25, 0x01,
0x65, 0x00,
0x55, 0x00,
0xb1, 0x82,
0x05, 0x84,
0x09, 0x02,
0xa1, 0x00,
0x09, 0x6e,
0x85, 0x03,
0xb1, 0x83,
0x09, 0x6e,
0x81, 0x83,
0x09, 0x6f,
0xb1, 0x83,
0x09, 0x6f,
0x81, 0x83,
0 \times c0.
0 \times c0.
0x09, 0x1a,
0xa1, 0x83,
0x09, 0x1b,
0x85, 0x1a,
0x26, 0xff, 0x00,
0xb1, 0x03,
0x09, 0x1f,
                                      FEATURE (Cnst, Var, Abs)
0xb1, 0x03,
                              //
```

//

0x09, 0x21,

```
on for NUT

ref: 34003616 ZA index: AA page 2

// USAGE (DelayBeforeStartup)

// REPORT_ID (54)

// UNIT_EXPONENT (0)

// FEATURE (Data, Var, Abs, Vol)

// USAGE (Ox5d)

// REPORT_ID (56)

// REPORT_ID (56)

// REPORT_SIZE (16)

// LOGICAL_MINIMUM (0)

// UNIT_EXPONENT (0)

// EATURE (Data, Var, Abs, Vol)

// USAGE (0x5e)

// REPORT_ID (57)

// FEATURE (Data, Var, Abs, Vol)

// USAGE (RemainingCapacityLimit)

// REPORT_ID (55)

// REPORT_ID (55)

// REPORT_SIZE (8)

// LOGICAL_MAXIMUM (255)

// UNIT (None)

// UNIT_EXPONENT (0)

// FEATURE (Data, Var, Abs, Vol)

// USAGE (PresentStatus)

// UNIT_EXPONENT (0)

// FEATURE (Data, Var, Abs, Vol)

// USAGE (PresentStatus)

// COLLECTION (Physical)

// USAGE (Switchable)

// REPORT_ID (8)

// LOGICAL_MAXIMUM (1)

// FEATURE (Cnst, Var, Abs, Vol)

// USAGE (Switchon/off)

// INPUT (Cnst, Var, Abs, Vol)

// USAGE (Switchon/off)

// INPUT (Cnst, Var, Abs, Vol)

// USAGE (Switchon/off)

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION
0x09, 0x56,
0x85, 0x36,
0x55, 0x00,
0xb1, 0x82,
0x06, 0xff, 0xff,
0x09, 0x5d,
0x85, 0x38,
0x75, 0x10,
0x15, 0x00,
0x55, 0x00,
0xb1, 0x82,
0x09, 0x5e,
0x85, 0x39,
0xb1, 0x82,
0x05, 0x85,
0x09, 0x29,
0x85, 0x37,
0x75, 0x08,
0x26, 0xff, 0x00,
0x65, 0x00,
0x55, 0x00,
0xb1, 0x82,
0x05, 0x84,
0x09, 0x02,
0xa1, 0x00,
0x09, 0x6c,
0x85, 0x08,
0x25, 0x01,
0xb1, 0x83,
0x09, 0x6c,
0x81, 0x83,
0x09, 0x6b,
0xb1, 0x83,
0x09, 0x6b,
0x81, 0x83,
0xc0,
0xc0,
0xc0,
                                                                                    // END_COLLECTION
0xc0
```

};

ref: 34003616 ZA index: AA page 30/70

6. Pulsar Evolution 1500/2200/3000 Range

Pulsar *Evolution* is intended for networking equipment, rack-optimized servers, traditional rack and tower servers and network storage systems. (Line Interactive, 1U rack only @ 1,500VA, 2 Switchable Outlets, USB and RS232 ports)






Figure 5: Pulsar Evolution 500/800/1100 UPS

6.1 The Evolution 1500/2200/3000 Collection tree

Collection UPS

Collection BatterySystem

Collection Battery

Collection Charger

Collection Input

Collection Output

Collection Flow (1:Main AC)

Collection Flow (3:Backup DC)

Collection Flow (4:AC Output)

Collection PowerConverter

Collection Input (1)

Collection Input (3)

Collection Output

Collection OutletSystem

Collection Outlet (1:Non Switchable)

Collection Outlet (2:Switchable)

Collection Outlet (3:Switchable)

Collection PowerSummary

6.2 The Evolution 1500/2200/3000 HID report descriptor

```
char ReportDescriptor[1620] = {
 0x05, 0x84,
                      // USAGE_PAGE (Power Device)
  0x09, 0x04,
                     // USAGE (UPS)
                    // COLLECTION (Application)
  0xa1, 0x01,
```

```
DE USB Devices ID Description for NUT

| 0.955, 0.001, 0.001, 0.002, 0.006, 0.001, 0.001, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.000, 0.0
       // END_COLLECTION
              0xc0,
```

```
0x67, 0x21, 0xd1, 0xf0, 0x00, // UNIT (SI Lin:Volts)
0x55, 0x07, // UNIT_EXPONENT (7)
0xb1, 0x82, // FEATURE (Data, Var, Abs, Vol)

        0xb1, 0x82,
        // EATURE (Data, Var, Abs, Vol)

        0xc0,
        // END_COLLECTION

        0x09, 0x1e,
        // USAGE (Flow)

        0xa1, 0x83,
        // COLLECTION (VendorDefined)

        0x85, 0x02,
        // REPORT_ID (2)

        0x99, 0x1f,
        // REPORT_SIZE (8)

        0x95, 0x01,
        // REPORT_SIZE (8)

        0x95, 0x01,
        // REPORT_COUNT (1)

        0x26, 0xff, 0x00,
        // UNIT (None)

        0x55, 0x00,
        // UNIT (None)

        0x55, 0x00,
        // UNIT (SPONENT (0)

        0x55, 0x00,
        // UNIT (SPONENT (0)

        0x55, 0x00,
        // UNIT (SPONENT (1)

        0x60,
        // UNIT (SPONENT (1)

        0x61,
        // UNIT (SPONENT (1)

        0x60,
        // UNIT (SPONENT (1)

        0x61,
        // USAGE (Flow)

        0x60,
        // UNIT (SPONENT (1)

        0x60,
        // EACTION

        0x81, 0x84,
        // COLLECTION (VendorDefined)

        0x95, 0x01,
        // REPORT_COUNT (1)

        0x26, 0xff, 0x00,
        // UNIT (SPONENT (1)

        0x26, 0xff, 0x00,
        // UNIT (SPONENT (1)

        0x27, 0xff, 0xff, 0x00,
        // UNIT (SPONENT (1)

    0xc0,
                                                                                                                                   // END_COLLECTION
    0x09, 0x1e,
                                                                                                                                // USAGE (Flow)
                                                                                                                                                       FEATURE (Data, Var, Abs, Vol)
                                                                                                                                     //
    0xb1, 0x82,
    0xc0,
                                                                                                                                    // END_COLLECTION
    0x09, 0x18,
                                                                                                                                    // USAGE (OutletSystem)
                                                                                                                                    // COLLECTION (Physical)
    0xa1, 0x00,
                                                                                                                                                     REPORT_ID (3)
USAGE (OutletSystemID)
    0x85, 0x03,
                                                                                                                                    //
    0x09, 0x19,
                                                                                                                                    //
                                                                                                                                                     REPORT_SIZE (8)
REPORT_COUNT (1)
    0x75, 0x08,
                                                                                                                                     //
     0x95, 0x01,
                                                                                                                                     //
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

USAGE (PresentStatus)

//

0x09, 0x02,

```
MGE USB Devices ID Description for NUT
                                                                                                  ref: 34003616 ZA index: AA page 36/70
                                                                      // COLLECTION (Logical)

// REPORT_ID (4)

// USAGE (Switchable)

// REPORT_SIZE (1)

// REPORT_COUNT (1)

// LOGICAL_MAXIMUM (1)

// UNIT (None)

// FEATURE (Cnst,Var,Abs)

// REPORT_COUNT (7)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (11)

// USAGE (SwitchOn/Off)

// REPORT_COUNT (1)

// INPUT (Cnst,Var,Abs,Vol)

// USAGE (SwitchOn/Off)

// REPORT_COUNT (1)

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION

// USAGE (Outlet)

// COLLECTION (VendorDefined)

// REPORT_ID (3)

// USAGE (FlowID)

// USAGE (OutletID)

// REPORT_SIZE (8)

// REPORT_COUNT (2)

// LOGICAL_MAXIMUM (255)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (36)

// USAGE (Battery

// REPORT_COUNT (1)
        0xa1, 0x02,
                                                                            // COLLECTION (Logical)
        0x85, 0x04,
        0x09, 0x6c,
        0x75, 0x01,
        0x95, 0x01,
        0x25, 0x01,
        0x65, 0x00,
        0xb1, 0x03,
        0x95, 0x07,
        0xb1, 0x03,
        0x85, 0x0b,
        0x09, 0x6b,
        0x95, 0x01,
        0x81, 0x83,
        0x09, 0x6b,
        0x95, 0x01,
        0xb1, 0x83,
        0xc0,
        0xc0,
        0x09, 0x20,
        0xa1, 0x83,
        0x85, 0x03,
        0x09, 0x1f,
        0x09, 0x21,
        0x75, 0x08,
        0x95, 0x02,
        0x26, 0xff, 0x00,
        0xb1, 0x03,
        0x85, 0x24,
                                                                                 REPORT_COUNT (1)
LOGICAL_MAXIMUM (100)
FEATURE (Data, Var, Abs, Vol)
REPORT_ID (37)
USAGE (DelayBeforeShutdown)
REPORT_SIZE (24)
REPORT_COUNT (1)
LOGICAL_MINIMUM (-1)
LOGICAL_MAXIMUM (65535)
UNIT (SI Lin:Time)
FEATURE (Data, Var, Abs, Vol)
REPORT_ID (38)
USAGE (DelayBeforeStartup)
REPORT_COUNT (1)
UNIT_EXPONENT (1)
FEATURE (Data, Var, Abs, Vol)
REPORT_ID (39)
USAGE (Vendor defined MGE 1:0x5d)
REPORT_SIZE (16)
REPORT_SIZE (16)
REPORT_COUNT (1)
LOGICAL_MINIMUM (0)
UNIT_EXPONENT (0)
FEATURE (Data, Var, Abs, Vol)
REPORT_ID (40)
USAGE (Vendor defined MGE 1:0x5e)
REPORT_ID (40)
USAGE (Vendor defined MGE 1:0x5e)
REPORT_COUNT (1)
FEATURE (Data, Var, Abs, Vol)
USAGE (Vendor defined MGE 1:0x5e)
REPORT_COUNT (1)
FEATURE (Data, Var, Abs, Vol)
USAGE (PresentStatus)
COLLECTION (Logical)
REPORT_ID (4)
USAGE (Switchable)
        0x0b, 0x29, 0x00, 0x85, 0x00, //
System: Remaining Capacity Limit)
        0x95, 0x01,
                                                                           //
        0x25, 0x64,
                                                                           //
        0xb1, 0x82,
                                                                           //
        0x85, 0x25,
                                                                           //
        0x09, 0x57,
                                                                           //
        0x75, 0x18,
                                                                           //
        0x95, 0x01,
                                                                           //
        0x15, 0xff,
                                                                           //
        0x27, 0xff, 0xff, 0x00, 0x00, //
        0x66, 0x01, 0x10,
                                                                           //
        0xb1, 0x82,
                                                                           //
        0x85, 0x26,
                                                                           //
        0x09, 0x56,
                                                                           //
        0x95, 0x01,
                                                                           //
        0x55, 0x01,
                                                                           //
        0xb1, 0x82,
                                                                           //
        0x85, 0x27,
                                                                           //
        0x0b, 0x5d, 0x00, 0xff, 0xff, //
        0x75, 0x10,
                                                                           //
        0x95, 0x01,
                                                                           //
                                                                           //
        0x15, 0x00,
        0x55, 0x00,
                                                                           //
        0xb1, 0x82,
                                                                           //
        0x85, 0x28,
                                                                           //
        0x0b, 0x5e, 0x00, 0xff, 0xff, //
        0x95, 0x01,
                                                                           //
                                                                           //
        0xb1, 0x82,
                                                                           //
        0x09, 0x02,
                                                                           //
        0xa1, 0x02,
                                                                                            REPORT_ID (4)
USAGE (Switchable)
        0x85, 0x04,
                                                                           //
        0x09, 0x6c,
                                                                           //
                                                                                            REPORT_SIZE (1)
        0x75, 0x01,
                                                                           //
        0x95, 0x01,
                                                                           //
                                                                                                REPORT_COUNT (1)
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

```
MGE USB Devices ID Description for NUT
                                                                                                                                               ref: 34003616 ZA index: AA page 37/70
                                                                                                        // LOGICAL_MAXIMUM (1)

// UNIT (None)

// FEATURE (Cnst,Var,Abs)

// REPORT_COUNT (7)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (11)

// USAGE (SwitchOn/Off)

// REPORT_COUNT (1)

// INPUT (Cnst,Var,Abs,Vol)

// USAGE (SwitchOn/Off)

// REPORT_COUNT (1)

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION
            0x25, 0x01,
            0x65, 0x00,
            0xb1, 0x03,
            0x95, 0x07,
            0xb1, 0x03,
            0x85, 0x0b,
            0x09, 0x6b,
            0x95, 0x01,
            0x81, 0x83,
            0x09, 0x6b,
            0x95, 0x01,
            0xb1, 0x83,
                                                                     // END_COLLECTION
// END_COLLECTION
// END_COLLECTION
// END_COLLECTION
// USAGE (PowerConverter)
// COLLECTION (Physical)
// REPORT_ID (4)

xff, // USAGE (Vendor defined MGE 1:0x41)
// REPORT_SIZE (8)
// REPORT_SIZE (8)
// REPORT_GOUNT (1)
// LOGICAL_MAXIMUM (255)
// FEATURE (Cnst,Var,Abs)
// REPORT_ID (5)
// USAGE (PowerConverterID)
// REPORT_COUNT (1)
// FEATURE (Cnst,Var,Abs)
// USAGE (Input)
// COLLECTION (VendorDefined)
// REPORT_ID (5)
// USAGE (FlowID)
// USAGE (InputID)
// REPORT_COUNT (2)
// FEATURE (Cnst,Var,Abs)
// REPORT_ID (41)
// REPORT_SIZE (1)
// REPORT_SIZE (1)
// REPORT_SIZE (1)
// REPORT_COUNT (1)
// LOGICAL_MAXIMUM (1)
// FEATURE (Cnst,Var,Abs)
// REPORT_COUNT (7)
// FEATURE (Cnst,Var,Abs)
// REPORT_COUNT (1)
// LOGICAL_MAXIMUM (65535)
// REPORT_SIZE (16)
// REPORT_COUNT (1)
// USAGE (Vendor defined MGE 1:0x43)
// REPORT_SIZE (16)
// REPORT_COUNT (1)
// LOGICAL_MAXIMOM (65535)
// REPORT_COUNT (1)
// USAGE (Frequency)
// REPORT_SIZE (8)
// REPORT_S
            0xc0.
            0xc0,
            0xc0.
            0x09, 0x16,
            0xa1, 0x00,
            0x85, 0x04,
            0x0b, 0x41, 0x00, 0xff, 0xff, //
            0x75, 0x08,
            0x95, 0x01,
            0x26, 0xff, 0x00,
            0xb1, 0x03,
            0x85, 0x05,
            0x09, 0x17,
            0x95, 0x01,
            0xb1, 0x03,
            0x09, 0x1a,
            0xa1, 0x81,
            0x85, 0x05,
            0x09, 0x1f,
            0x09, 0x1b,
            0x95, 0x02,
            0xb1, 0x03,
            0x85, 0x29,
            0x0b, 0x43, 0x00, 0xff, 0xff, //
            0x75, 0x01,
            0x95, 0x01,
            0x25, 0x01,
            0xb1, 0x82,
            0x95, 0x07,
            0xb1, 0x03,
            0x85, 0x11,
            0x09, 0x30,
            0x75, 0x10,
            0x95, 0x01,
            0x27, 0xff, 0xff, 0x00, 0x00, //
            0x67, 0x21, 0xd1, 0xf0, 0x00, //
            0x55, 0x07,
            0xb1, 0x83,
            0x09, 0x32,
            0x75, 0x08,
            0x95, 0x01,
            0x26, 0xff, 0x00,
            0x66, 0x01, 0xf0,
            0x55, 0x00,
            0xb1, 0x83,
            0x09.0x02.
            0xa1, 0x02,
            0x85, 0x0b,
            0x09, 0x6e,
            0x09, 0x6f,
            0x09, 0x61,
            0x09, 0x62,
                                                                                                               //
                                                                                                                                             USAGE (InternalFailure)
```

```
ref: 34003616 ZA index: AA page 38/7

// REPORT_SIZE (1)

// REPORT_COUNT (4)

// LOGICAL_MAXIMUM (1)

// UNIT (None)

// USAGE (Boost)

// USAGE (Boost)

// USAGE (Boost)

// USAGE (Buck)

// USAGE (Good)

// EPORT_COUNT (4)

// FEATURE (Cnst,Var,Abs,Vol)

// END_COLLECTION

// END_COLLECTION

// USAGE (Input)

// COLLECTION (VendorDefined)

// REPORT_ID (5)

// USAGE (InputID)

// REPORT_SIZE (8)

// REPORT_SIZE (8)

// REPORT_SIZE (1)

// LOGICAL_MAXIMUM (255)

// FEATURE (Cnst,Var,Abs)

// REPORT_SIZE (1)

// LOGICAL_MAXIMUM (1)

// REPORT_GOUNT (1)

// LOGICAL_MAXIMUM (1)

// FEATURE (Chst,Var,Abs,Vol)

// REPORT_COUNT (1)

// FEATURE (Chst,Var,Abs,Vol)

// REPORT_COUNT (1)

// REPORT_COUNT (2)

// REPORT_SIZE (8)

// REPORT_SIZE (6)

// REPOR
MGE USB Devices ID Description for NUT
                                                                                                                                               ref: 34003616 ZA index: AA page 38/70
            0x75, 0x01,
            0x95, 0x04,
            0x25, 0x01,
            0x65, 0x00,
            0x81, 0x83,
            0x09, 0x6e,
            0x09, 0x6f,
            0x09, 0x61,
            0x09, 0x62,
            0x95, 0x04,
            0xb1, 0x83,
            0xc0,
            0xc0.
            0x09, 0x1a,
            0xa1, 0x83,
            0x85, 0x05,
            0x09, 0x1f,
            0x09, 0x1b,
            0x75, 0x08,
            0x95, 0x02,
            0x26, 0xff, 0x00,
            0xb1, 0x03,
            0x85, 0x2a,
            0x0b, 0x46, 0x00, 0xff, 0xff, //
            0x75, 0x01,
            0x95, 0x01,
            0x25, 0x01,
            0xb1, 0x82,
            0x95, 0x07,
            0xb1, 0x03,
            0x85, 0x2b,
            0x0b, 0x47, 0x00, 0xff, 0xff, //
            0x95, 0x01,
            0xb1, 0x82,
            0x95, 0x07,
            0xb1, 0x03,
            0x09, 0x02,
            0xa1, 0x02,
            0x85, 0x0b,
            0x09, 0x61,
            0x09, 0x6d,
            0x95, 0x02,
            0x81, 0x83,
            0x09, 0x61,
            0x09, 0x6d,
            0x95, 0x02,
            0xb1, 0x83,
            0xc0,
            0xc0,
            0x09, 0x1c,
            0xa1, 0x00,
            0x85, 0x05,
            0x09, 0x1f,
            0x09, 0x1d,
            0x75, 0x08,
            0x95, 0x02,
            0x26, 0xff, 0x00,
            0xb1, 0x03,
            0x85, 0x12,
            0x09, 0x33,
            0x75, 0x10,
            0x95, 0x01,
            0x27, 0xff, 0xff, 0x00, 0x00, //
            0x66, 0x21, 0xd1,
```

MGE USB Devices ID Description for NUT ref: 34003616 ZA index: AA page 39/70 // UNIT_EXPONENT (7) // FEATURE (Cnst,Var,Abs,Vol) 0x55, 0x07,

All rights reserved.

MGE USB Devices ID Description for NUT ref: 34003616 ZA index: AA page 40/70 0xb1, 0x82, // FEATURE (Data, Var, Abs, Vol) REPORT_ID (47) 0x85, 0x2f, // USAGE (HighVoltageTransfer) 0x09, 0x54,// 0x95, 0x01, REPORT_COUNT (1) // 0xb1, 0x82, FEATURE (Data, Var, Abs, Vol) REPORT_ID (48) USAGE (Vendor defined MGE 1:0x50) REPORT_COUNT (1) FEATURE (Data, Var, Abs, Vol) REPORT_ID (49) USAGE (LowVoltageTransfer) REPORT_COUNT (1) FEATURE (Data, Var, Abs, Vol) REPORT_ID (50) USAGE (Vendor defined MGE 1:0x4c) REPORT_SIZE (8) REPORT_COUNT (1) LOGICAL_MAXIMUM (255) UNIT (None) UNIT_EXPONENT (0) FEATURE (Data, Var, Abs, Vol) END_COLLECTION FEATURE (Data, Var, Abs, Vol) // 0x85, 0x30, // 0x0b, 0x50, 0x00, 0xff, 0xff, // 0x95, 0x01, // 0xb1, 0x82, // 0x85, 0x31, // 0x09, 0x53, // 0x95, 0x01, // 0xb1, 0x82, // // 0x85, 0x32, 0x0b, 0x4c, 0x00, 0xff, 0xff, // 0x75, 0x08,// // 0x95, 0x01,// 0x26, 0xff, 0x00, // 0x65, 0x00,// 0x55, 0x00,// 0xb1, 0x82, END_COLLECTION // 0xc0,// END_COLLECTION 0xc0, 0x09, 0x24,// USAGE (PowerSummary) 0xa1, 0x00, // COLLECTION (Physical) REPORT_ID (6) REPORT_ID (6) USAGE (FlowID) USAGE (PowerSummaryID) REPORT_SIZE (8) REPORT_COUNT (2) LOGICAL_MAXIMUM (255) FEATURE (Cnst,Var,Abs) USAGE (Battery System:CapacityGranularity1) REPORT_COUNT (1) LOGICAL_MAXIMUM (100) FEATURE (Cnst,Var,Abs) USAGE (Battery System:CapacityMode) REPORT_COUNT (1) LOGICAL_MAXIMUM (255) FEATURE (Cnst,Var,Abs) USAGE (Battery System:DesignCapacity) REPORT_COUNT (1) LOGICAL_MAXIMUM (100) FEATURE (Cnst,Var,Abs) USAGE (Battery System:Rechargeable) 0x85, 0x06, // // 0x09, 0x1f, 0x09, 0x25,// 0x75, 0x08,// 0x95, 0x02,// 0x26, 0xff, 0x00, // 0xb1, 0x03, // 0x0b, 0x8d, 0x00, 0x85, 0x00, // 0x95, 0x01, // 0x25, 0x64,// 0xb1, 0x03, // 0x0b, 0x2c, 0x00, 0x85, 0x00, // 0x95, 0x01,// 0x26, 0xff, 0x00, // 0xb1, 0x03, // 0x0b, 0x83, 0x00, 0x85, 0x00, // 0x95, 0x01, // 0x25, 0x64, // USAGE (Undefined) 0x09, 0xff, // USAGE (Undefined) REPORT_COUNT (6) LOGICAL_MAXIMUM (255) FEATURE (Cnst,Var,Abs) 0x09, 0xfd, // 0x95, 0x06, // // 0x26, 0xff, 0x00, // 0xb1, 0x03,REPORT_ID (8) USAGE (ConfigVoltage) REPORT_COUNT (1) // 0x85, 0x08,0x09, 0x40,// 0x95, 0x01, // UNIT (SI Lin:Volts) UNIT_EXPONENT (7) 0x67, 0x21, 0xd1, 0xf0, 0x00, // 0x55, 0x07,// 0xb1, 0x03, // FEATURE (Cnst, Var, Abs)

MGE USB Devices ID Description for NUT ref: 34003616 ZA index: AA page 42/70 USAGE (InternalFailure) USAGE (Battery System:NeedReplacement) USAGE (Overload) USAGE (OverTemperature) 0x09, 0x62,// 0x0b, 0x4b, 0x00, 0x85, 0x00, // 0x09, 0x65, // USAGE (OverTemperature) 0x09, 0x67,// // USAGE (OverTemperature) // USAGE (ShutdownImminent) // REPORT_COUNT (11) // FEATURE (Cnst,Var,Abs,Vol) // REPORT_COUNT (6) // FEATURE (Cnst,Var,Abs) // REPORT_ID (51) // USAGE (Switchable) // REPORT_COUNT (1) // INPUT (Data,Var,Abs,Vol) // REPORT_COUNT (7) // INPUT (Cnst,Var,Abs) // USAGE (Switchable) 0x09, 0x69, 0x95, 0x0b, 0xb1, 0x83, 0x95, 0x06, 0xb1, 0x03, 0x85, 0x33, 0x09, 0x6c, 0x95, 0x01, 0x81, 0x82, 0x95, 0x07,INPUT (Cnst, Var, Abs) USAGE (Switchable) 0x81, 0x03, INPUT (Cnst,Var,Abs) USAGE (Switchable) REPORT_COUNT (1) FEATURE (Data,Var,Abs,Vol) REPORT_COUNT (7) FEATURE (Cnst,Var,Abs) END_COLLECTION REPORT_ID (52) USAGE (Undefined) REPORT_SIZE (8) REPORT_COUNT (1) LOGICAL_MINIMUM (1) LOGICAL_MAXIMUM (255) INPUT (Data,Var,Abs,Vol) USAGE (Undefined) REPORT_COUNT (1) FEATURE (Data,Var,Abs,Vol) REPORT_ID (53) USAGE (DelayBeforeShutdown) REPORT_SIZE (24) REPORT_COUNT (1) LOGICAL_MINIMUM (-1) LOGICAL_MINIMUM (-5535) UNIT (SI Lin:Time) FEATURE (Data,Var,Abs,Vol) REPORT_ID (54) USAGE (DelayBeforeStartup) REPORT_ID (54) // 0x09, 0x6c, // 0x95, 0x01,FEATURE (Data, Var, Abs, Vol) // 0xb1, 0x82, // 0x95, 0x07,// 0xb1, 0x03, // 0xc0, // 0x85, 0x34,// 0x09, 0x5a, // 0x75, 0x08,// 0x95, 0x01,// 0x15, 0x01, 0x26, 0xff, 0x00, // 0x81, 0x82, // 0x09, 0x5a, // 0x95, 0x01, 0xb1, 0x82, // 0x85, 0x35, // 0x09, 0x57,// 0x75, 0x18, // 0x95, 0x01, // 0x15, 0xff, // 0x27, 0xff, 0xff, 0x00, 0x00, // 0x66, 0x01, 0x10, // 0xb1, 0x82, // 0x85, 0x36, // USAGE (DelayBeforeStartup) 0x09, 0x56,// REPORT_COUNT (1) 0x95, 0x01, // UNIT_EXPONENT (1) FEATURE (Data, Var, Abs, Vol) 0x55, 0x01, // 0xb1, 0x82, // REPORT_ID (55) 0x85, 0x37, // USAGE (Vendor defined MGE 1:0x4d) REPORT_SIZE (8) 0x0b, 0x4d, 0x00, 0xff, 0xff, // 0x75, 0x08,// REPORT_COUNT (1) 0x95, 0x01, // LOGICAL_MINIMUM (0) 0x15, 0x00,// LOGICAL_MAXIMUM (100) UNIT_EXPONENT (0) 0x25, 0x64,// 0x55, 0x00, // 0x65, 0x00, UNIT (None) // FEATURE (Data, Var, Abs, Vol) 0xb1, 0x82, // REPORT_ID (56) 0x85, 0x38, // USAGE (Vendor defined MGE 1:0x5f) REPORT_COUNT (1) 0x0b, 0x5f, 0x00, 0xff, 0xff, // 0x95, 0x01, // FEATURE (Data, Var, Abs, Vol) 0xb1, 0x82, // REPORT_ID (57) 0x85, 0x39,// USAGE (Vendor defined MGE 1:0x48) REPORT_SIZE (1) 0x0b, 0x48, 0x00, 0xff, 0xff, // 0x75, 0x01,// 0x95, 0x01,// REPORT_COUNT (1) 0x25, 0x01,// LOGICAL_MAXIMUM (1)

FEATURE (Data, Var, Abs, Vol)

REPORT_COUNT (7)

//

//

0xb1, 0x82,

0x95, 0x07,

MGE USB Devices ID Description for NUT

ref: 34003616 ZA index: AA page 43/70

7. Pulsar Extreme C Range

Intended for Unix Server and storage protection users, **Pulsar** *Extreme C* protects information systems, industry, telecommunication and medical configurations (True On Line, Hot Swappable batteries, 2 Switchable Outlets, USB and RS232 ports)

ref: 34003616 ZA index: AA page 44/70






Figure 6: Pulsar Extreme C UPS

7.1 The Extreme C Collection tree

Collection UPS

Collection PowerSummary

Collection PowerConverter

Collection Input (1)

Collection Input (3)

Collection Output

Collection BatterySystem

Collection Input

Collection Charger

Collection Output

Collection Battery

Collection Flow (1:Main AC)

Collection Flow (3:Backup DC)

Collection Flow (4:AC Output)

Collection OutletSystem

Collection Outlet (1:Non Switchable)

Collection Outlet (2:Switchable)

Collection Outlet (3:Switchable)

7.2 The Extreme C HID report descriptor

```
char ReportDescriptor[1535] = {
  0x05, 0x84,
                    // USAGE_PAGE (Power Device)
  0x09, 0x04,
                    // USAGE (UPS)
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

USAGE (ACPresent) // USAGE (Charging) // USAGE (Charging) // USAGE (ElowRemainingCapacityLimi // REPORT_SIZE (1) // REPORT_SIZE (1) // LOGICAL_MINIMUM (0) // LOGICAL_MINIMUM (1) // LOGICAL_MINIMUM (1) // USAGE (Power Device) // USAGE (Undefined) // REPORT_COUNT (1) // INPUT (Cnst.Var.Abs.Vol) // USAGE_PAGE (Power Device) // USAGE_PAGE (Battery System) // USAGE_PAGE (Battery System) // USAGE_PAGE (Power Device) // USAGE (NeedReplacement) // USAGE (ShutdownImminent) // USAGE (Good) // USAGE (Good) // USAGE (Overload) // USAGE (Overload) // USAGE (Overload) // USAGE (InternalFailure) // REPORT_COUNT (5) // INPUT (Cnst.Var.Abs.Vol) // USAGE (Undefined) // REPORT_SIZE (5) // INPUT (Cnst.Var.Abs) // REPORT_SIZE (5) // USAGE (Charging) // USAGE (Charging) // USAGE (Charging) // USAGE (BelowRemainingCapacityLimit) // REPORT_SIZE (1) // REPORT_COUNT (4) // REPORT_COUNT (1) // REPORT_SIZE (5) // PATURE (Cnst.Var.Abs,Vol) USAGE (Switchable) INPUT (Cnst.Var.Abs) USAGE (Switchable) INPUT (Cnst.Var.Abs) USAGE (Switchable) FEATURE (Cnst. MGE USB Devices ID Description for NUT ref: 34003616 ZA index: AA page 48/70 0x09, 0xd0, // USAGE (ACPresent) 0x09, 0x44,0x09, 0x45,0x09, 0x42, 0x75, 0x01,0x95, 0x04,0x15, 0x00, 0x25, 0x01, 0x81, 0x83, 0x05, 0x84, 0x09, 0x73, 0x95, 0x01, 0x81, 0x83, 0x05, 0x85,0x09, 0x4b,0x81, 0x83, 0x05, 0x84,0x09, 0x61, 0x09, 0x69,0x09, 0x65,0x09, 0x67,0x09, 0x62,0x95, 0x05,0x81, 0x83, 0x09, 0x00,0x95, 0x01,0x75, 0x05,0x81, 0x03, 0x85, 0x0f, 0x05, 0x85, 0x09, 0xd0, 0x09, 0x44, 0x09, 0x45,0x09, 0x42,0x75, 0x01,0x95, 0x04,0xb1, 0x83, 0x05, 0x84,0x09, 0x73,0x95, 0x01,0xb1, 0x83, 0x05, 0x85, 0x09, 0x4b, 0xb1, 0x83, 0x05, 0x84,0x09, 0x61, 0x09, 0x69,0x09, 0x65,0x09, 0x67,0x09, 0x62,0x95, 0x05,0xb1, 0x83, 0x09, 0x00, 0x95, 0x01, 0x75, 0x05, 0xb1, 0x03, 0x85, 0x0b, 0x75, 0x01,0x09, 0x6c, INPUT (Cnst, Var, Abs) USAGE (Switchable) 0x81, 0x03,0x09, 0x6c, // FEATURE (Cnst, Var, Abs) 0xb1, 0x03, // USAGE (Undefined) 0x09, 0x00,// 0x75, 0x07,// REPORT_SIZE (7)

```
USAGE (Undefined)
FEATURE (Cnst, Var, Abs)
0x09, 0x00,
0xb1, 0x03,
                                                                                                    //
                                                                                                   // FEATURE (Cnst
// END_COLLECTION
0xc0,
0xc0.
                                                                                                 // END_COLLECTION
0x09, 0x16,
                                                                                               // USAGE (PowerConverter)
                                                         // COLLECTION (Physical)

// REPORT_ID (1)

// USAGE (PowerConverterID)

// REPORT_SIZE (8)

// LOGICAL_MAXIMUM (255)

// FEATURE (Cnst,Var,Abs)

// USAGE_PAGE (Vendor defined MGE 1)

// REPORT_ID (25)

// USAGE (0x42)

// INPUT (Cnst,Var,Abs,Vol)

// USAGE (0x42)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (0x42)

// FEATURE (Cnst,Var,Abs,Vol)

// REPORT_ID (9)

// USAGE (0x41)

// FEATURE (Cnst,Var,Abs)

// USAGE_PAGE (Power Device)

// USAGE (Input)

// COLLECTION (VendorDefined)

// REPORT_ID (1)

// USAGE (InputID)

// USAGE (InputID)
0xa1, 0x00,
                                                                                              // COLLECTION (Physical)
0x85, 0x01,
0x09, 0x17,
0x75, 0x08,
0x26, 0xff, 0x00,
0xb1, 0x03,
0x06, 0xff, 0xff,
0x85, 0x19,
0x09, 0x42,
0x81, 0x83,
0x09, 0x42,
0xb1, 0x83,
0x85, 0x09,
0x09, 0x41,
0xb1, 0x03,
0x05, 0x84,
0x09, 0x1a,
                                                          // COLLECTION (VendorDefined)

// REPORT_ID (1)

// USAGE (InputID)

// USAGE (InputID)

// REPORT_SIZE (8)

// REPORT_SIZE (8)

// REPORT_COUNT (2)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (6)

// USAGE (Voltage)

// REPORT_SIZE (16)

// REPORT_COUNT (1)

0x00, 0x00, // LOGICAL_MAXIMUM (65535)

0xf0, 0x00, // UNIT (SI Lin:Volts)

// UNIT_EXPONENT (7)

// FEATURE (Cnst,Var,Abs,Vol)

// USAGE (Frequency)

// REPORT_SIZE (8)

// LOGICAL_MAXIMUM (255)

// UNIT (SI Lin:Hertz)

// UNIT 
0xa1, 0x81,
0x85, 0x01,
0x09, 0x1b,
0x09, 0x1f,
0x75, 0x08,
0x95, 0x02,
0xb1, 0x03,
0x85, 0x06,
0x09, 0x30,
0x75, 0x10,
0x95, 0x01,
0x27, 0xff, 0xff, 0x00, 0x00, //
0x67, 0x21, 0xd1, 0xf0, 0x00, //
0x55, 0x07,
0xb1, 0x83,
0x09, 0x32,
0x75, 0x08,
0x26, 0xff, 0x00,
0x66, 0x01, 0xf0,
0x55, 0x00,
0xb1, 0x83,
0x06, 0xff, 0xff,
0x85, 0x1a,
0x09, 0x43,
0x75, 0x01,
0x25, 0x01,
0x65, 0x00,
0xb1, 0x82,
0x09, 0x00,
0x75, 0x07,
0xb1, 0x03,
0x05, 0x84,
0x09, 0x02,
0xa1, 0x02,
                                                                                                                           REPORT_ID (16)
USAGE (Used)
USAGE (Good)
USAGE (InternalFailure)
REPORT_SIZE (1)
REPORT_COUNT (3)
0x85, 0x10,
                                                                                                 //
0x09, 0x6d,
                                                                                                 //
0x09, 0x61,
                                                                                                   //
0x09, 0x62,
                                                                                                   //
0x75, 0x01,
                                                                                                   //
0x95, 0x03,
                                                                                                   //
0x25, 0x01,
                                                                                                    //
                                                                                                                                   LOGICAL_MAXIMUM (1)
```

MGE USB Devices ID Description for NUT ref: 34003616 ZA index: AA page 51/70 // LOGICAL_MAXIMUM (255) 0x26, 0xff, 0x00, FEATURE (Cnst,Var,Abs) // USAGE_PAGE (Vendor defined // REPORT_ID (27) // USAGE (0x46) // REPORT_SIZE (1) // REPORT_COUNT (1) // LOGICAL_MAXIMUM (1) // FEATURE (Data,Var,Abs,Vol) // USAGE (Undefined) // REPORT_SIZE (7) // FEATURE (Cnst,Var,Abs) // REPORT_ID (30) // USAGE (0x47) // REPORT_SIZE (1) // FEATURE (Data,Var,Abs,Vol) // USAGE (Undefined) // REPORT_SIZE (7) // FEATURE (Cnst,Var,Abs,Vol) // USAGE (Undefined) // REPORT_SIZE (7) // FEATURE (Cnst,Var,Abs) // USAGE_PAGE (Power Device) // USAGE (PresentStatus) // COLLECTION (Logical) // REPORT_ID (16) // USAGE (Usage) FEATURE (Cnst, Var, Abs) 0xb1, 0x03, // USAGE_PAGE (Vendor defined MGE 1) 0x06, 0xff, 0xff, 0x85, 0x1b, 0x09, 0x46, 0x75, 0x01,0x95, 0x01, 0x25, 0x01, 0xb1, 0x82, 0x09, 0x00, 0x75, 0x07,0xb1, 0x03, 0x85, 0x1e, 0x09, 0x47,0x75, 0x01,0xb1, 0x82, 0x09, 0x00,0x75, 0x07,0xb1, 0x03, 0x05, 0x84,// USAGE (PresentStatus) // COLLECTION (Logical) // REPORT_ID (16) // USAGE (Used) // USAGE (Good) // REPORT_SIZE (1) // REPORT_COUNT (2) // INPUT (Cnst,Var,Abs,Vol) // USAGE (Good) // END_COLLECTION // END_COLLECTION // END_COLLECTION // END_COLLECTION // USAGE (Output) // COLLECTION (Physical) // REPORT_ID (2) // USAGE (OutputID) // REPORT_SIZE (8) // REPORT_SIZE (8) // REPORT_COUNT (2) // LOGICAL_MAXIMUM (255) // FEATURE (Cnst,Var,Abs) // REPORT_ID (7) // USAGE (Voltage) // REPORT_SIZE (16) // REPORT_SIZE (16) // REPORT_COUNT (1) // USAGE (Frequency) // REPORT_SIZE (8) // UNIT (SI Lin:Volts) // UNIT_EXPONENT (7) // FEATURE (Cnst,Var,Abs,Vol) // USAGE (Frequency) // REPORT_SIZE (8) // LOGICAL_MAXIMUM (255) // UNIT (SI Lin:Hertz) // UNIT (SI Lin:Hertz) // UNIT_EXPONENT (0) // FEATURE (Cnst,Var,Abs,Vol) // USAGE (ApparentPower) // REPORT_SIZE (16) // LOGICAL_MAXIMUM (65535) UNIT (SI Lin:Power) // UNAGE (ApparentPower) // REPORT_SIZE (16) // LOGICAL_MAXIMUM (65535) UNIT (SI Lin:Power) // UNAGE (Current) // UNAGE (Current) // UNAGE (Current) // UNAGE UPS SYSTEMS All rights reserved. 0x09, 0x02,0xa1, 0x02, 0x85, 0x10, 0x09, 0x6d, 0x09, 0x61, 0x75, 0x01,0x95, 0x02,0x81, 0x83, 0x09, 0x6d, 0x09, 0x61, 0xb1, 0x83, FEATURE (Cnst, Var, Abs, Vol) 0xc0,0xc0, 0x09, 0x1c, 0xa1, 0x00, 0x85, 0x02,0x09, 0x1d, 0x09, 0x1f, 0x75, 0x08,0x95, 0x02,0x26, 0xff, 0x00, 0xb1, 0x03, 0x85, 0x07, 0x09, 0x30, 0x75, 0x10, 0x95, 0x01,0x27, 0xff, 0xff, 0x00, 0x00, // 0x67, 0x21, 0xd1, 0xf0, 0x00, // 0x55, 0x07,0xb1, 0x83, 0x09, 0x32, 0x75, 0x08, 0x26, 0xff, 0x00, 0x66, 0x01, 0xf0, 0x55, 0x00, 0xb1, 0x83, 0x09, 0x33,0x75, 0x10,0x27, 0xff, 0xff, 0x00, 0x00, // 0x66, 0x21, 0xd1, 0x55, 0x07,0xb1, 0x83, 0x09, 0x31,0x67, 0x01, 0x00, 0x10, 0x00, //

```
// UNIT_EXPONENT (7)
// FEATURE (Cnst,Var,Abs,Vol)
   0x55, 0x07,
                                                                     // FEATURE (Cnst, Var, Abs, Vol)
// REPORT_ID (42)
// USAGE (ConfigFrequency)
// REPORT_SIZE (8)
// LOGICAL_MAXIMUM (255)
// UNIT (SI Lin:Hertz)
// UNIT_EXPONENT (0)
// FEATURE (Cnst, Var, Abs, Vol)
// REPORT_ID (3)
// USAGE (FlowID)
// REPORT_SIZE (8)
// LOGICAL_MAXIMUM (255)
// UNIT (None)
// FEATURE (Cnst, Var, Abs)
// END_COLLECTION
// USAGE (Flow)
// COLLECTION (VendorDefined)
// REPORT_ID (3)
// USAGE (FlowID)
// EATURE (Cnst, Var, Abs)
// END_COLLECTION
   0xb1, 0x83,
                                                                                                                        //
   0x85, 0x2a,
   0x09, 0x42,
   0x75, 0x08,
  --, vall, Ux00,
0x66, 0x01, 0xf0,
0x55, 0x00,
0xb1, 0x83.
   0x26, 0xff, 0x00,
   0x85, 0x03,
   0x09, 0x1f,
   0x75, 0x08,
   0x26, 0xff, 0x00,
   0x65, 0x00,
   0xb1, 0x03,
   0xc0.
   0x09, 0x1e,
   0xa1, 0x83,
   0x85, 0x03,
   0x09, 0x1f,
   0xb1, 0x03,
                                                                                                                 // END_COLLECTION
// USAGE (Flow)
   0xc0,
   0x09, 0x1e,

      0x09, 0x1e,
      // COLLECTION (VendorDefined)

      0xal, 0x84,
      // COLLECTION (VendorDefined)

      0x85, 0x03,
      // REPORT_ID (3)

      0x09, 0x1f,
      // USAGE (FlowID)

      0xb1, 0x03,
      // FEATURE (Cnst,Var,Abs)

      0x85, 0x2c,
      // REPORT_ID (44)

      0x09, 0x40,
      // USAGE (ConfigVoltage)

      0x75, 0x10,
      // REPORT_SIZE (16)

      0x27, 0xff, 0xff, 0x00, 0x00,
      // LOGICAL_MAXIMUM (65535)

      0x67, 0x21, 0xd1, 0xf0, 0x00,
      // UNIT_EXPONENT (7)

      0x55, 0x07,
      // UNIT_EXPONENT (7)

      0x81, 0x82,
      // REPORT_ID (45)

      0x09, 0x42,
      // USAGE (ConfigFrequency)

      0x75, 0x08,
      // REPORT_SIZE (8)

      0x26, 0xff, 0x00,
      // LOGICAL_MAXIMUM (255)

      0x55, 0x00,
      // UNIT_EXPONENT (0)

      0x55, 0x00,
      // UNIT_EXPONENT (0)

      0x55, 0x2e,
      // REPORT_ID (46)

      0x09, 0x41,
      // USAGE (ConfigCurrent)

      0x75, 0x10,
      // USAGE (ConfigCurrent)

      0x75, 0x10,
      // REPORT_SIZE (16)

      0x27, 0xff, 0xff, 0x00, 0x00,
      // LOGICAL_MAXIMUM (65535)

      0x67, 0x01, 0x00, 0x10, 0x00,
      // USAGE (ConfigCurrent)

      0x75, 0x10
                                                                                                                   //
                                                                                                                                     COLLECTION (VendorDefined)
   0xa1, 0x84,
UNIT (None)
UNIT_EXPONENT (0)
FEATURE (Data, Var
   0x55, 0x00,
                                                                                                                      //
   0xb1, 0x82,
                                                                                                                        //
                                                                                                                                                  FEATURE (Data, Var, Abs, Vol)
```

```
// END_COLLECTION
```

MGE USB Devices ID Description for NUT

ref: 34003616 ZA index: AA page 57/70

```
ref: 34003616 ZA index: AA pag

// COLLECTION (Logical)

// REPORT_ID (18)

// USAGE (Switchable)

// LOGICAL_MAXIMUM (1)

// UNIT (None)

// FEATURE (Cnst, Var, Abs)

// USAGE (Undefined)

// REPORT_SIZE (5)

// FEATURE (Cnst, Var, Abs)

// REPORT_SIZE (5)

// FEATURE (Cnst, Var, Abs)

// REPORT_ID (19)

// USAGE (Switchon/Off)

// REPORT_SIZE (1)

// INPUT (Cnst, Var, Abs, Vol)

// USAGE (Switchon/Off)

// FEATURE (Cnst, Var, Abs, Vol)

// USAGE (Undefined)

// FEATURE (Cnst, Var, Abs)

// USAGE (Undefined)

// REPORT_SIZE (6)

// INPUT (Cnst, Var, Abs)

// EATURE (Cnst, Var, Abs)

// EATURE (Cnst, Var, Abs)

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION
           0xa1, 0x02,
           0x85, 0x12,
           0x09, 0x6c,
          0x75, 0x01,
          0x25, 0x01,
          0x65, 0x00,
          0xb1, 0x03,
          0x09, 0x00,
          0x75, 0x05,
          0xb1, 0x03,
          0x85, 0x13,
          0x09, 0x6b,
          0x75, 0x01,
          0x81, 0x83,
          0x09, 0x6b,
          0xb1, 0x83,
          0x09, 0x00,
          0x75, 0x06,
          0x81, 0x03,
          0x09, 0x00,
          0xb1, 0x03,
           0xc0,
           0xc0,
           0xc0,
           0xc0
};
```

8. Pulsar Esprit Range

Pulsar *Esprit* is a standby technology UPS intended for very long back-up time (up to 16 hours) for computer & Industrial equipment protection. (USB and RS232 ports)

ref: 34003616 ZA index: AA page 58/70






Figure 7: Pulsar Esprit UPS

8.1 The Esprit Collection tree

Collection UPS

Collection Flow (1:Main AC)

Collection Flow (3:Backup DC)

Collection Flow (4:AC Output)

Collection BatterySystem

Collection Input

Collection Charger

Collection Output

Collection Battery

Collection PowerConverter

Collection Input (1)

Collection Input (3)

Collection Output

Collection OutletSystem

Collection Outlet (1:Switchable)

Collection PowerSummary

8.2 The Esprit HID report descriptor

```
char ReportDescriptor[1340] = {
                                   // USAGE_PAGE (Power Device)
   0x05, 0x84,
   0x09, 0x04,
                                  // USAGE (UPS)
  0xa1, 0x01,
                                  // COLLECTION (Application)
   0x09, 0x1e,
                                 // USAGE (Flow)
   0xa1, 0x81,
                                 // COLLECTION (VendorDefined)
                                  // END_COLLECTION
    0xc0.
                                  // USAGE (Flow)
   0x09, 0x1e,
                                  // COLLECTION (VendorDefined)
   0xa1, 0x84,
                                      REPORT_ID (6)
REPORT_SIZE (8)
REPORT_COUNT (1)
LOGICAL_MINIMUM (0)
LOGICAL_MAXIMUM (127)
UNIT (None)
USAGE (FlowID)
   0x85, 0x06,
                                 //
   0x75, 0x08,
                                  //
                                  //
   0x95, 0x01,
   0x15, 0x00,
                                  //
   0x25, 0x7f,
                                  //
    0x65, 0x00,
                                  //
    0x09, 0x1f,
                                   //
```

```
        SEE USB Devices ID Description for NUT
        ref: 34003616 ZA index: AA

        0xb1, 0x03, 0x85, 0x07, 0x75, 0x10, 0x95, 0x01, 0x95, 0x01, 0x26, 0xf4, 0x01, 0x67, 0x21, 0xd1, 0xf0, 0x00, 0x67, 0x21, 0xd1, 0xf0, 0x00, 0x65, 0x07, 0x21, 0xd1, 0xf0, 0x00, 0x65, 0x07, 0x09, 0x40, 0x65, 0x08, 0x65, 0x01, 0x60, 0x
                                                                                                                                      // END_COLLECTION
    0xc0,
                                                                                                                                      //
                                                                                                                                                          USAGE (BatterySystem)
    0x09, 0x10,
                                                                                                                                                      COLLECTION (Physical)

REPORT_ID (11)

REPORT_SIZE (8)

REPORT_COUNT (1)

LOGICAL_MINIMUM (0)

LOGICAL_MAXIMUM (127)

UNIT (None)

UNIT_EXPONENT (0)

USAGE (BatterySystemID)

FEATURE (Cnst, Var, Abs)

USAGE (Input)

COLLECTION (Physical)

REPORT_ID (12)

REPORT_COUNT (1)

USAGE (InputID)

FEATURE (Cnst, Var, Abs)

REPORT_COUNT (1)

USAGE (InputID)

FEATURE (Cnst, Var, Abs)

REPORT_ID (13)

REPORT_COUNT (1)

USAGE (FlowID)

FEATURE (Cnst, Var, Abs)

END_COLLECTION
                                                                                                                                      //
    0xa1, 0x00,
                                                                                                                                                            COLLECTION (Physical)
                                                                                                                                      //
    0x85, 0x0b,
                                                                                                                                      //
    0x75, 0x08,
                                                                                                                                      //
    0x95, 0x01,
                                                                                                                                       //
    0x15, 0x00,
                                                                                                                                       //
    0x25, 0x7f,
    0x65, 0x00,
                                                                                                                                       //
    0x55, 0x00,
                                                                                                                                       //
    0x09, 0x11,
                                                                                                                                       //
    0xb1, 0x03,
                                                                                                                                       //
                                                                                                                                      //
    0x09, 0x1a,
    0xa1, 0x00,
                                                                                                                                      //
    0x85, 0x0c,
                                                                                                                                     //
    0x95, 0x01,
                                                                                                                                     //
                                                                                                                                     //
    0x09, 0x1b,
                                                                                                                                    //
    0xb1, 0x03,
    0x85, 0x0d,
                                                                                                                                    //
    0x95, 0x01,
                                                                                                                                     //
    0x09, 0x1f,
                                                                                                                                     //
    0xb1, 0x03,
                                                                                                                                     //
                                                                                                                                    // FEATURE (CHSC,VAF,AI)
// END_COLLECTION
// USAGE (Charger)
// COLLECTION (Physical)
// REPORT_ID (14)
// REPORT_COUNT (1)
    0xc0,
    0x09, 0x14,
    0xa1, 0x00,
    0x85, 0x0e,
    0x95, 0x01,
                                                                                                                                                         USAGE (ChargerID)
FEATURE (Cnst, Var, Abs)
USAGE (PresentStatus)
COLLECTION (Logical)
    0x09, 0x15,
                                                                                                                                      //
                                                                                                                                       //
    0xb1, 0x03,
    0x09, 0x02,
                                                                                                                                        //
    0xa1, 0x02,
                                                                                                                                         //
                                                                                                                                                                        REPORT_ID (15)
    0x85, 0x0f,
                                                                                                                                         //
    0x75, 0x01,
                                                                                                                                          //
                                                                                                                                                                                   REPORT_SIZE (1)
```

```
ref: 34003616 ZA index: AA page

// REPORT_COUNT (8)

// LOGICAL_MINIMUM (0)

// USAGE (Undefined)

// USAGE (InternalFailure)

// USAGE (Undefined)

// END_COLLECTION

// USAGE (Output)

// COLLECTION (Physical)

REPORT_ID (16)

REPORT_SIZE (8)

REPORT_SIZE (8)

REPORT_SIZE (8)

REPORT_COUNT (1)

USAGE (OutputID)

// EATURE (Cnst, Var, Abs)

REPORT_ID (17)

// REPORT_COUNT (1)

USAGE (FlowID)

// EATURE (Cnst, Var, Abs)

END_COLLECTION

// USAGE (Battery)
MGE USB Devices ID Description for NUT
                                                                                                                        ref: 34003616 ZA index: AA page 62/70
          0x95, 0x08,
          0x15, 0x00,
          0x25, 0x01,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x61,
          0x09, 0x62,
          0x09, 0x00,
          0x09, 0x00,
          0xb1, 0x83,
          0x95, 0x08,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x00,
          0x09, 0x61,
          0x09, 0x62,
          0x09, 0x00,
          0x09, 0x00,
          0x81, 0x83,
          0xc0,
          0xc0,
          0x09, 0x1c,
          0xa1, 0x00,
          0x85, 0x10,
          0x75, 0x08,
          0x95, 0x01,
          0x15, 0x00,
          0x25, 0x7f,
          0x09, 0x1d,
          0xb1, 0x03,
          0x85, 0x11,
          0x95, 0x01,
          0x09, 0x1f,
                                                                                                    USAGE (FlowID)
FEATURE (Cnst,Var,Abs)
END_COLLECTION
USAGE (Battery)
COLLECTION (Physical)
REPORT_ID (18)
REPORT_SIZE (8)
REPORT_COUNT (1)
LOGICAL_MINIMUM (0)
LOGICAL_MAXIMUM (127)
USAGE (BatteryID)
FEATURE (Cnst,Var,Abs)
REPORT_ID (19)
REPORT_SIZE (24)
REPORT_SIZE (24)
REPORT_COUNT (1)
LOGICAL_MINIMUM (86400)
LOGICAL_MINIMUM (3932100)
UNIT (SI Lin:Time)
UNIT_EXPONENT (0)
USAGE (Vendor defined MGE 1:0x45)
FEATURE (Data,Var,Abs)
COLLECTION (Logical)
REPORT_ID (20)
REPORT_SIZE (1)
REPORT_COUNT (8)
LOGICAL_MINIMUM (0)
LOGICAL_MAXIMUM (1)
UNIT (None)
UNIT_EXPONENT (0)
          0xb1, 0x03,
                                                                                           //
          0xc0,
                                                                                           //
          0x09, 0x12,
                                                                                           //
          0xa1, 0x00,
          0x85, 0x12,
                                                                                           //
          0x75, 0x08,
                                                                                           //
          0x95, 0x01,
                                                                                           //
          0x15, 0x00,
                                                                                           //
          0x25, 0x7f,
                                                                                           //
          0x09, 0x13,
                                                                                           //
          0xb1, 0x03,
                                                                                           //
          0x85, 0x13,
                                                                                           //
          0x75, 0x18,
                                                                                           //
          0x95, 0x01,
                                                                                           //
          0x17, 0x80, 0x51, 0x01, 0x00, //
          0x27, 0xc4, 0xff, 0x3b, 0x00, //
          0x66, 0x01, 0x10,
                                                                                            //
          0x55, 0x00,
                                                                                            //
          0x0b, 0x45, 0x00, 0xff, 0xff, //
          0xb1, 0x02,
                                                                                            //
          0xa1, 0x02,
                                                                                            //
                                                                                           //
          0x85, 0x14,
          0x75, 0x01,
                                                                                           //
                                                                                           //
          0x95, 0x08,
          0x15, 0x00,
                                                                                           //
          0x25, 0x01,
                                                                                           //
          0x65, 0x00,
                                                                                            //
                                                                                                                     UNIT (None)
          0x55, 0x00,
                                                                                            //
                                                                                                                        UNIT_EXPONENT (0)
```

```
ref: 34003616 ZA index: AA page

// USAGE (Undefined)

// USAGE (Good)

// USAGE (Present)

// FEATURE (Cnst,Var,Abs,Vol)

// REPORT_COUNT (8)

// USAGE (Undefined)

// USAGE (Present)

// USAGE (Present)

// END_COLLECTION

// END_COLLECTION

// END_COLLECTION

// USAGE (PowerConverter)

// COLLECTION (Physical)

// REPORT ID (21)
MGE USB Devices ID Description for NUT
                                                                                                                                                                      ref: 34003616 ZA index: AA page 63/70
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x61,
              0x09, 0x60,
              0xb1, 0x83,
              0x95, 0x08,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x00,
              0x09, 0x61,
              0x09, 0x60,
              0x81, 0x83,
              0xc0,
                                                                                                                     END_COLLECTION

// END_COLLECTION

// USAGE (PowerConverter)

// COLLECTION (Physical)

// REPORT_ID (21)

// REPORT_SIZE (8)

// REPORT_COUNT (1)

// LOGICAL_MINIMUM (0)

// LOGICAL_MAXIMUM (127)

// USAGE (PowerConverterID)

// FEATURE (Cnst,Var,Abs)

// USAGE (Input)

// COLLECTION (VendorDefined)

// REPORT_ID (22)

// REPORT_COUNT (1)

// USAGE (InputID)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (23)

// REPORT_COUNT (1)

// USAGE (FlowID)

// FEATURE (Cnst,Var,Abs)

// REPORT_SIZE (16)

// REPORT_SIZE (16)

// REPORT_SIZE (16)

// LOGICAL_MINIMUM (0)

// LOGICAL_MAXIMUM (500)

// UNIT (SI Lin:Volts)

// UNAGE (Voltage)

// FEATURE (Cnst,Var,Abs,Vol)

// REPORT_ID (25)

// REPORT_ID (26)

// REPORT_COUNT (1)

// USAGE (LowVoltageTransfer)

// FEATURE (Cnst,Var,Abs)

// REPORT_ID (26)

// REPORT_ID (26)

// REPORT_ID (27)

// REPORT_ID (27)

// REPORT_SIZE (16)

// REPORT_SIZ
              0xc0,
              0xc0,
              0x09, 0x16,
              0xa1, 0x00,
              0x85, 0x15,
              0x75, 0x08,
              0x95, 0x01,
              0x15, 0x00,
              0x25, 0x7f,
              0x09, 0x17,
              0xb1, 0x03,
              0x09, 0x1a,
              0xa1, 0x81,
              0x85, 0x16,
              0x95, 0x01,
              0x09, 0x1b,
              0xb1, 0x03,
              0x85, 0x17,
              0x95, 0x01,
              0x09, 0x1f,
              0xb1, 0x03,
              0x85, 0x18,
              0x75, 0x10,
              0x95, 0x01,
              0x15, 0x00,
              0x26, 0xf4, 0x01,
              0x67, 0x21, 0xd1, 0xf0, 0x00, //
              0x55, 0x07,
              0x09, 0x30,
              0xb1, 0x83,
              0x85, 0x19,
              0x95, 0x01,
              0x09, 0x53,
              0xb1, 0x03,
              0x85, 0x1a,
              0x95, 0x01,
              0x09.0x54.
              0xb1, 0x03,
              0x85, 0x1b,
              0x75, 0x10,
                                                                                                                                              LOGICAL_MINIMUM (0)
LOGICAL_MAXIMUM (6500)
              0x95, 0x01,
              0x15, 0x00,
                                                                                                                           //
              0x26, 0x64, 0x19,
              0x66, 0x01, 0xf0,
                                                                                                                               //
                                                                                                                                                               UNIT (SI Lin:Hertz)
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

```
MGE USB Devices ID Description for NUT
                        ref: 34003616 ZA index: AA page 65/70
```

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

Copyright © 2001, MGE UPS SYSTEMS All rights reserved.

USAGE (Charging)

//

0x09, 0x44,

MGE USB Devices ID Description for NUT

ref: 34003616 ZA index: AA page 70/70

```
};
```

- End of Document -