

NRC7292 Evaluation Kit User Guide

(WPS-PBC)

Ultra-low power & Long-range Wi-Fi

Ver 1.1 Jun 02, 2022

NEWRACOM, Inc.

NRC7292 Evaluation Kit User Guide (WPS-PBC) Ultra-low power & Long-range Wi-Fi

© 2022 NEWRACOM, Inc.

All right reserved. No part of this document may be reproduced in any form without written permission from Newracom.

Newracom reserves the right to change in its products or product specification to improve function or design at any time without notice.

Office

Newracom, Inc. 25361 Commercentre Drive, Lake Forest, CA 92630 USA http://www.newracom.com

Contents

1	WPS (Wi-Fi Protected Setup)	5	
2	WPS-PBC operation on NRC7292 EVK (Host-mode)		
2.1	Build Configuration	6	
2.2	Command for WPS-PBC	6	
2.3	Configurartion file for wpa_supplicant and hostapd	6	
2.4	WPS-PBC Procedure	7	
3	WPS-PBC operation on NRC7292 EVK (Standalone-mode)	10	
3.1	WPS-PBC Procedure	10	
4	Revision history	11	

List of Figures

Figure 1. Configuration for WPS-PBC of hostapd on AP	6
Figure 2. Results of WPS-PBC on AP	
Figure 3. Results of WPS-PBC on STA	
Figure 4. Network Configuration after WPS-PBC on STA	9
Figure 5. Restart WPS-PBC by hostapd cli (wps pbc)	9
Figure 6. Timeout of WPS-PBC on AP	
Figure 7. Results of WPS-PBC on SAM STA	10

1 WPS (Wi-Fi Protected Setup)

Wi-Fi Protected Setup™ (WPS) is a standard published by the Wi-Fi Alliance with the aim of simplifying the configuration process to establish a secure wireless network. WPS allows devices to be easily added to a network while providing a secure connection. AP and STA that supports WPS uses a personal identification number (PIN) and push button connection (PBC) to connect devices. NRC7292 EVK supports WPS-PBC and how to operate will be explained in next chapter.

2 WPS-PBC operation on NRC7292 EVK (Host-mode)

In this chapter, we describe how to build wpa_supplicant and hostapd to support WPS-PBC and how to operate WPS-PBC on both NRC7292 EVK HM(host-mode) STA and AP in detail

2.1 Build Configuration

During WPS operation, WPA Supplicant acts as the Enrollee and therefore it should include WPS config, **CONFIG_WPS=y**, when building SW. Hostapd also should be built with WPS config, **'CONFIG_WPS=y and CONFIG_WPS_UPNP=y (if you want to use external Registrar)'** to support WPS as a role of Registrar

2.2 Command for WPS-PBC

To operate WPS-PBC, both wpa_cli (CLI app. for wpa_supplicant) and hostapd_cli (CLI app. for hostapd) provide 'wpa_pbc' command, which can emulate WPS physical button. Once wpa_pbc is run, AP advertises its WPS information through beacon. The default advertisement time is 2 minutes, so AP stops advertising once connection is established or there is no connection established within 2 minutes. STA run with WPS-PBC can hear AP's adverting and do WPS-PBC process to connect to AP. This process will be described in Clause 2.4 in detail.

2.3 Configurartion file for wpa_supplicant and hostapd

Figure 1 shows some parameters that should be set in configuration file on hostapd (AP) to support WPS. (Refer to ap halow pbc.conf in /nrc pkg/script/conf/US/)

Hostapd uses those parameters while operating as a role of WPS Registrar

```
eap_server=1

# WPS configuration (AP configured, do not allow external WPS Registrars)
wps_state=2
ap_setup_locked=1

# If UUID is not configured, it will be generated based on local MAC address.
#uuid=87654321-9abc-def0-1234-56789abc0000
#wps_pin_requests=/var/run/hostapd.pin-req
device_name=NEWRATEK_WPS_PBC
manufacturer=NEWRATEK
model_name=NRC7292
model_number=1234
serial_number=4321
device_type=6-0050F204-1
os_version=01020300
config_methods=label_display_push_button_keypad
```

Figure 1. Configuration for WPS-PBC of hostapd on AP

On STA side, there is no need to set parameters because STA earns AP's network configuration automatically during WPS procedures. AP's network information earned during WPS-PBC is stored in configuration file in wpa supplicant on STA.

2.4 WPS-PBC Procedure

WPS-PBC can be executed using start.py (in nrc_pkg) on both STA and AP where WPS-PBC is defined as 'security_mode type 4'. (e.g ./start.py 1 4 US) Figure 2 ~ Figure 6 show the whole process of WPS-PBC.

1. (AP) Start AP and WPS Registrar, and then waiting for STA's (Enrollee) connection

```
pi@raspberrypi:~/nrc_pkg/script $ ./start.py 1 4 US
Model
                                        7292
                                         AP
 STA Type
Security Mode :
Country Selected :
                                        WPA-PBC
                                        US
Download FW
                                        uni_s1g.bin
 TX Power
cal_use
                                    : 1
NRC AP setting for HaLow.
    *] Set Max CPU Clock on RPi
 1400000
 1400000
 1400000
 [0] Clear
 wpa_supplicant: no process found
 wireshark-gtk: no process found
[1] Copy
total 640
total 640
drwxr-xr-x 2 pi pi 4096 Sep 15 14:44 .
drwxr-xr-x 4 pi pi 4096 Sep 15 14:43 .
-rwxr-xr-x 1 pi pi 271 Sep 15 14:43 copy
-rwxr-xr-x 1 pi pi 562 Sep 15 14:43 nrc7292_bd.dat
-rwxr-xr-x 1 pi pi 316608 Sep 15 14:43 nrc7292_cspi.bin
-rwxr-xr-x 1 root root 316608 Sep 16 13:31 uni_s1g.bin
-rwxr-xr-x 1 root root 316608 Sep 16 13:31 /lib/firmware/uni_s1g.bin
-rw-r--r-- 1 root root 271464 Jan 28 2021 /lib/firmware/uni_s1g.sniffer.bin
                                     : wlan0
: 192.168.200.1
: 24
  AP INTERFACE
AP STATIC IP
   NET MASK NUM
Config for AP is done!

IP and DHCP config done
[2] Loading module
sudo insmod /home/pi/nrc_pkg/sw/driver/nrc.ko hifspeed=20000000 spi_bus_num=0 spi_cs_num=0 spi_gpio_irq=5 spi_g
pio_poll=-1 fw_name=uni_s1g.bin power_save=0 ndp_preq=1 auto_ba=1 disable_cqm=0
[3] Set tx power

Tx power: 17

Calibration_use: ON

OK
Board Data use
                                                                      : off
[4] Set aggregation number
                   : BK
                                                                      updated aggregation
                                                                                                                                                                           : 0
: 0
                                                   State
                                                                      : OFF
: ON
                                                                                                      Value
                                                                                                                                                        Size
                     : BE
                                                                                                     Value
                                                                      : OFF
                    : VI
                                                   State
                                                                                                      Value
                    : VO
                                                                      : OFF
                                                                                                      Value
[5] Set guard interval
 guard interval : long
[6] Set cal_use
Calibration_use : on
         Start DHCPCD and DNSMASQ
[*] Start Differ and Dispuss
[6] Start hostagd on wland
Configuration file: /home/pi/nrc_pkg/script/conf/US/ap_halow_pbc.conf
wland: interface state UNINITIALIZED->COUNTRY_UPDATE
Using interface wland with hwaddr 00:01:02:03:04:05 and ssid "halow wps_te
WPS: Converting display to virtual_display for WPS 2.0 compliance
WPS: Converting push_button to virtual_push_button for WPS 2.0 compliance
wps_interface_state_COUNTRY_UPDATE->ENABLED
wlan0: AP-ENABLED
wlan0: WPS-PBC-ACTIVE
```

Figure 2. Results of WPS-PBC on AP

2. (STA) Start STA and WPS Enrollee, and then try to get AP's configuration during WPS-PBC process and connect to AP using it.

```
pi@raspberrypi:~/nrc_pkg/script $ ./start.py 0 4 US
 Model
 STA Type
Security Mode : WP/
Country Selected : US
Download FW : uni
                                            : WPA-PBC
                                           : uni s1g.bin
 TX Power
 Power Save Type : Always On
 NRC STA setting for HaLow...
[*] Set Max CPU Clock on RPi
 1200000
 1200000
 1200000
Done
[0] Clear
hostapd: no process found
wireshark-gtk: no process found
total 640

drwxrwxrwx 2 pi pi 4096 Sep 15 14:39 .

drwxrwxrwx 4 pi pi 4096 Sep 15 14:39 .

-rwxrwxrwx 1 pi pi 271 Sep 15 14:39 copy

-rwxrwxrwx 1 pi pi 562 Sep 15 14:39 nrc7292_bd.dat

-rwxrwxrwx 1 pi pi 316608 Sep 15 14:42 nrc7292_cspi.bin

-rwxrwxrwx 1 pi pi 316608 Sep 16 13:34 uni_s1g.bin

-rwxr-xr-x 1 root root 316608 Sep 16 13:34 /lib/firmware/uni_s1g.bin
                                            : wlan0
  STA INTERFACE
USE DHCP Client
Config for STA is done!

IP and DHCP config done
[2] Loading module
sudo insmod /home/pi/nrc_pkg/sw/driver/nrc.ko hifspeed=20000000 spi_bus_num=0 spi_cs_num=0 spi_gpio_irq=5 spi_g
pio_poll=-1 fw_name=uni_sig.bin_power_save=0 ndp_preq=1 disable_cqm=0
[3] Set tx power

Tx power: 17

Calibration_use: OFF
 [4] Set aggregation number
                                   ----- updated aggregation
                                                            State : OFF Value : 8
State : ON Value : 8
                       : BE
                                                                                                                                                                                     Size
                        · VT
                                                            State
 [5] Set guard interval
 guard interval : long
 [6] Set cal use
  *] Start DHCPCD and DNSMASQ
  wpa_supplicant: no process found
[6] Start wpa_supplicant on wlan0
Successfully initialized wpa_supplicant
 Selected interface 'wlan0'
wlan0: WPS-PBC-ACTIVE
OK
[7] Connect and DHCP
Waiting for IP
Wland: SME: Trying to authenticate with 00:01:02:03:04:05 (SSID='halow_wps_test' freq=5805 MHz)
wland: Trying to associate with 00:01:02:03:04:05 (SSID='halow_wps_test' freq=5805 MHz)
wland: Associated with 00:01:02:03:04:05
wland: CTRL-EVENT-SUBNET-STATUS-UPDATE status=0
wland: CTRL-EVENT-EAP-STATED EAP authentication started
wland: CTRL-EVENT-EAP-STATED EAP authentication started
wland: CTRL-EVENT-EAP-PROPOSED-METHOD vendor=14122 method=1
  wlan0: CTRL-EVENT-EAP-METHOD EAP vendor 14122 method 1 (WSC) selected
                 WPS-CRED-RECEIVED
wlan0: WPS-SUCCESS

wlan0: CTRL EVENT EAP FAILURE

EAP authentication failed

wlan0: CTRL-EVENT-DISCONNECTED bssid=00:01:02:03:04:05 reason=3 locally_generated=1

wlan0: CTRL-EVENT-REGDOM-CHANGE init=CORE type=WORLD

wlan0: CTRL-EVENT-REGDOM-CHANGE init=USER type=WORLD

wlan0: SME: Trying to authenticate with 00:01:02:03:04:05 (SSID='halow_wps_test' freq=5805 MHz)

wlan0: Trying to associate with 00:01:02:03:04:05 (SSID='halow_wps_test' freq=5805 MHz)

wlan0: Associated with 00:01:02:03:04:05

wlan0: CTRL-EVENT-SUBNET-STATUS-UPDATE status=0

wlan0: CTRL-EVENT-SUBNET-STATUS-UPDATE status=0

wlan0: WPA: Key negotiation completed with 00:01:02:03:04:05 [PTK=CCMP]

wlan0: CTRL-EVENT-CONNECTED - Connection to 00:01:02:03:04:05 completed [id=1 id_str=]

Waiting for IP
  wlang: WPS-SUCCESS
Waiting for IP
inet 192.168.200.38 netmask 255.255.255.0 broadcast 192.168.200.255
 IP assigned. HaLow STA ready
```

Figure 3. Results of WPS-PBC on STA

3. (STA) Once STA earns AP's network configuration after WPS-PBC, it is saved in configuration file of wpa_supplicant. STA can use it whenever (re)connecting to AP. Figure 4 shows network configuration of AP in sta_halow_pbc.conf (in nrc_pkg/script/US/)

```
network={
    ssid="halow_wps_test"
    psk="12345678"
    proto=RSN
    key_mgmt=WPA-PSK
    pairwise=CCMP-256 CCMP
    group=CCMP-256 CCMP TKIP
    auth_alg=OPEN
    pbss=2
}
```

Figure 4. Network Configuration after WPS-PBC on STA

4. (AP) After a connection during WPS-PBC or timeout (2-mininutes) of WPS-PBC, AP can restart WPS-PBC again using hostapd_cli like 'sudo hostapd_cli wps_pbc'

```
pi@raspberrypi:~/nrc_pkg/script $ sudo hostapd_cli wps_pbc
Selected interface 'wlan0'
wlan0: WPS-PBC-ACTIVE
OK
```

Figure 5. Restart WPS-PBC by hostapd cli (wps pbc)

5. (AP) If there is no WPS connection within 2-minutes, AP stop WPS process

```
pi@raspberrypi:~/nrc_pkg/script $ wlan0: WPS-TIMEOUT
```

Figure 6. Timeout of WPS-PBC on AP

3 WPS-PBC operation on NRC7292 EVK (Standalone-mode)

Standalone-mode STA on NRC7292EVK also supports WPS-PBC via CLI. However, Standalone-mode AP (aka. SoftAP) does NOT support WPS-PBC so you can test WPS-PBC operation with SAM STA and HM AP.

3.1 WPS-PBC Procedure

On Standalone-mode FW, WPS-PBC can be run via target CLI, 'wpa wps_pbc'. Figure 7 shows the whole procedures of WPS-PBC on STA. Please note that it takes more than 10 seconds to complete WPS-PBC because WPS uses Diffie Helman algorithm to make public key, plus target CPU's performance (CM0 or CM3) is much lower than Host-mode CPU on RPi.

```
[4] 8066766 nrc7292_standalone_xip>wpa wps_pbc
 IPA: Control interfawpa: ce responseFlush scan
 'OK' (2)
OKscn:
  0 start0 start
[5] 14817264 nrc7292_standalone_xip>scn: 0 done
Unsupported channel(0). Change it to default (2442)
wim: 0 ch:5805, type:0, width:0
phy: 0 NRF TX GAIN CONTROL DONE(11)...
 vim: 0 AID: 2
 vim: 0 BSSID: 00:01:02:03:04:05
wim: 0 update short beacon interval in STA: 0
bmt: 0 set to default (100)
bmt: 0 start (bi:100, threshold:1500)
s1g: 0 update beacon interval(1000)
s1g: 0 listen_interval: 100 beacon_interval: 1000
s1g: 0 update short beacon interval(intv: 100)
s1g: 0 listen_interval: 100 short beacon_interval: 100
wpa_ps: 0 set key (mgmt:512, authorized:0)
wim: 0 AID: 2
vim: 0 BSSID: 00:00:00:00:00:00
wim: 0 update short beacon interval in STA: 0
omt: 0 stop
STA is disconnected! Clear AP-related retent Info
wpa_ps: 0 set key (mgmt:512, authorized:0)
wpa: Flush scan
scn: 0 start
scn: 0 done
wpa: Flush scan
 cn: 0 start
scn: 0 done
wpa: Flush scan
scn: 0 start
scn: 0 done
wim: 0 dond
wim: 0 ch:5805, type:0, width:0
phy: 0 NRF TX GAIN CONTROL DONE(11)...
s1g: 0 (STA-assoc) akm type: 2
wim: 0 AID: 2
wim: 0 BSSID: 00:01:02:03:04:05
wim: 0 update short beacon interval in STA: 0
bmt: 0 set to default (100)
wim: 0 set to default (100)
bmt: 0 start (bi:100, threshold:1500)
wim: 0 install key [PTK idx:0 aid:2 CCMP 00:01:02:03:04:05]
wim: 0 install key [GTK idx:1 aid:2 CCMP ff:ff:ff:ff:ff:ff]
wpa_ps: 0 set key (mgmt:2, authorized:1)
s1g: 0 update beacon interval(1000)
s1g: 0 listen_interval: 100 beacon_interval: 1000
 ilg: 0 update short beacon interval(intv: 100)
       0 listen_interval: 100 short beacon_interval: 100
```

Figure 7. Results of WPS-PBC on SAM STA

4 Revision history

Revision No	Date	Comments
Ver 1.0	9/16/2021	Initial version
Ver 1.1	6/2/2022	Remove build configuration in Standalone-mode section