

FT64F0AX

IR_Send Application note



目录

1.	IR 介绍	. 3			
2.	IR SEND 相关寄存器的设置	. 3			
3.	应用范例	. 4			
联系信息17					



FT64F0Ax IR_Send 应用

1. IR 介绍

一个通用的红外遥控系统由发射和接收两大部分组成,如图 1 所示:




图 1-1

发射部分主要包括键盘矩阵、编码调制、红外发射管;接收部分包括光、电信号的转换以及放大、 解调、解码电路。

举例来说,通常我们家电遥控器信号的发射,就是将相应按键所对应的控制指令和系统码(由 0 和 1 组成的序列),调制在 32~56kHz 范围内的载波上(目的为: 抗干扰及低功率),然后经放大(接三极管)、驱动红外发射管(透明的头)将信号发射出去。

2. IR Send 相关寄存器的设置

本例使用两个定时器,一个是产生38kHz载波频率,另一个定时器是做时基,定时时长是560µS,红外信号的高低电平是560µS的整数倍。

定时器 2 为 16 位, 配置成 13µs 中断产生 38K 信号

定时器 4 为 8 位、配置成 560us 中断一次。

本讲解以 IC FT64F0A5 TSSOP20 为示范,每 2.5 秒钟会发出一次信号,信号的码为 IRData[4] = {0x55,0xAA,0x01,0xFE}

- 3 -



3. 应用范例

```
/* 文件名: ASM 64F0Ax IR Send.ASM
* 功能:
      FT64F0Ax IR Send 功能演示
* IC:
      FT64F0A5 TSSOP20
* 内部:
      16M/4T
* 说明:
      当按键按下后,发送自己所想要发送的红外码,按键不松开时发送连发码,
      此程序所发红外码为 0x55, 0xaa, 0x01, 0xfe
      FT64F0A5 TSSOP20
              (PA4)20|-----NC
* NC-----|1(PA5)
* NC-----|2(PA6)
              (PA3)19|----NC
* NC-----|3(PA7)
              (PA2)18|----NC
              (PA1)17|----NC
* NC-----|4(PC0)
* key-----|5(PC1)
              (PA0)16|----NC
* NC-----|6(PB7)
              (PB0)15|----NC
* GND-----|7(GND)
              (PB1)14|----NC
* NC-----|8(PB6)
              (PB2)13|----NC
* VDD-----|9(VDD)
              (PB3)12|----ir data
* NC-----|10(PB5)
              (PB4)11|----NC
*/
#INCLUDE <FT64F0AX.INC>:
;RAM DEFINE
TEMP
              EQU
                      0X40
  TEMP1
              EQU
                      0X41
  TEMP2
              EQU
                      0X42
  W TMP
              EQU
                      0X43
  S TMP
                      0X44
              EQU
  READPIN
              EQU
                      0X45
  IRDATTEMP
              EQU
                      0X46
  buff
              EQU
                      0X47
  #define
                      buff,1
              f key
              EQU
                      0X48
  key_short_count
  count
              EQU
                      0X49
  countbyte
              EQU
                      0X4A
  f 2ms
              EQU
                      0X4B
CONSTANT DEFINE
```



	INTCON_DEF	EQU	B'01000000'	;使能外设中断			
	OSCCON_DEF	EQU	B'01110001'	;16MHz,1:1			
	WDIA DEE	FOLL	Bioggood	ᇩᇈ			
	WPUA_DEF	EQU	B'00000000'	;弱上拉的开关,0-关,1-开			
	WPUB_DEF	EQU	B'00000000'				
	WPUC_DEF	EQU	B'00000000'				
	WPDA_DEF	EQU	B'00000000'	;弱下拉的开关,0-关,1-开			
	WPDB DEF	EQU	B'00000000'	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			
	WPDC DEF	EQU	B'00000000'				
	WI DO_DEI	LQU	В 00000000				
	TRISA_DEF	EQU	B'00000000'	;输入输出设置, 0-输出, 1-输入			
	TRISB_DEF	EQU	B'00000000'	;PB3-OUT			
	TRISC_DEF	EQU	B'00000000'				
	DODOS DEF	FOLL	Diadadada	. 海市 法犯 異 見 上			
	PSRC0_DEF	EQU	B'11111111'	;源电流设置最大			
	PSRC1_DEF	EQU	B'11111111'				
	PSRC2_DEF	EQU	B'00001111'				
	PSINKO DEF	EQU	B'11111111'	;灌电流设置最大			
	PSINK1 DEF	EQU	B'11111111'				
	PSINK2 DEF	EQU	B'00000011'				
	FOINKZ_DEI	LQU	В 00000011				
	ANSELA_DEF	EQU	B'00000000'	;设置对应的 IO 为数字 IO			
	PCKEN_DEF	EQU	B'00000010'	;使能 Timer1 时钟模块			
	CKOCON_DEF	EQU	B'00100000'				
	;Timer1 倍频时钟占空比调节位 4ns 延迟						
	TCKSRC_DEF	EQU	B'00000001'	;Timer1 时钟源为 HIRC			
	TIM1CR1 DEF	FOU	B'10000101'				
	;允许自动装载,使能						
	,几斤白幼衣戟, 反形	月双面,227日	ᄭᄁᄓᅩᄭᅑ				
	TIM1IER_DEF	EQU	B'00000001'	;允许更新中断			
	TIM1ARRH_DEF	EQU	0x80	;自动装载周期高 8 位 80H			
	TIM1ARRL_DEF	EQU	0x83	;自动装载周期低 8 位 83H			
	EPS0 DEF	EQU	B'00000000'	;外部中断管脚选择为 PA3			
	EPS1 DEF	EQU	B'00000000'	7. B. 1 3. B. 1 (217)			
	ITYPE0 DEF			;中断触发类型为双边沿			
	-			,正则烟久大生乃从咫归			
	ITYPE1_DEF						
	_		B'00001000'	·			
;==	==========	=======	=========	==========			

- 5 - 2021-09-07



;USER DEFINE

#DEFINE ir_data PORTB,3
#DEFINE key PORTA,5

#DEFINE IOCA3 3

;PROGRAM START

ORG 0x0000
LJUMP RESTART
ORG 0x0004
STR W_TMP
SWAPR STATUS,W
STR S TMP

LJUMP INT PROGRAM

;SYSTEM START

RESTART:

BANKSEL PORTA LCALL INITIAL

LCALL TIMER1_INITIAL

BANKSEL INTCON

BSR INTCON,GIE ;使能全局中断

BANKSEL TIM1IER

BSR TIM1IER,T1UIE ;允许 TIM1 中断

MAIN:

CLRWDT

BANKSEL buff
BTSS f_2ms,0
LJUMP MAIN
BANKSEL buff
BCR f_2ms,0
LCALL scanky_key
LJUMP MAIN

;INT PROGRAM

INT PROGRAM:

BANKSEL TIM1SR1

BTSC TIM1SR1,T1UIF LJUMP TIM1Interrupt

BANKSEL EPIF0



BTSC EPIF0,IOCA3
LJUMP GPIOInterrupt
LJUMP INT RET

TIM1Interrupt:

BANKSEL TIM1SR1

BSR TIM1SR1,T1UIF

BANKSEL f_2ms BSR f_2ms,0 LJUMP INT_RET

GPIOInterrupt:

BANKSEL PORTA LDR PORTA,W **BANKSEL READPIN** STR **READPIN BANKSEL** EPIF0 **LDWI** 0X00 **STR** EPIF0 **LDWI** 0X00 **STR** EPIE0 **LJUMP** INT RET

INT RET:

SWAPR S_TMP,0
STR STATUS
SWAPR W_TMP,1
SWAPR W_TMP,0

RETI

;SYSTEM INITIAL

INITIAL:

BANKSEL OSCCON

LDWI OSCCON_DEF

STR OSCCON

BANKSEL INTCON

LDWI INTCON DEF

STR INTCON

BANKSEL PORTA LDWI 0X00



STR PORTA
STR PORTB
STR PORTC

BANKSEL TRISA
LDWI TRISA_DEF
STR TRISA
LDWI TRISB_DEF
STR TRISB
LDWI TRISC_DEF
STR TRISC

BANKSEL WPUA
LDWI WPUA_DEF
STR WPUB
LDWI WPUB_DEF
STR WPUB
LDWI WPUC_DEF
STR WPUC

BANKSEL WPDA
LDWI WPDA_DEF
STR WPDA
LDWI WPDB_DEF
STR WPDB
LDWI WPDC_DEF

STR WPDC_DE

BANKSEL PSRC0
LDWI PSRC0_DEF
STR PSRC0
LDWI PSRC1_DEF
STR PSRC1
LDWI PSRC2_DEF
STR PSRC2

BANKSEL PSINK0

LDWI PSINK0_DEF

STR PSINK0

LDWI PSINK1_DEF

STR PSINK1

LDWI PSINK2_DEF

STR PSINK2

- 8 - 2021-09-07



BANKSEL ANSELA

LDWI ANSELA DEF

STR ANSELA

;*************Clear SRAM**************

BANKSEL PORTA LDWI 0X00 STR FSR0H

CLEAR RAM BANKO:

LDWI 20H STR FSR0L

CLEAR RAM BANKO LOOP:

CLRR INDF0
INCR FSR0L,F
LDWI 80H
XORWR FSR0L,W
BTSS STATUS,Z

LJUMP CLEAR_RAM_BANK0_LOOP

CLEAR RAM BANK1:

LDWI 0A0H
STR FSR0L
CLEAR RAM BANK1 LOOP:

CLRR INDF0
INCR FSR0L,F
LDWI 00H
XORWR FSR0L,W

BTSS STATUS,Z

INCR FSR0H,F

CLEAR_RAM_LOOP:

LJUMP

LDWI 10

SUBWR FSR0H,W BTSS STATUS,0

LJUMP CLEAR RAM BANKO

RET

CLEAR_RAM_BANK1_LOOP

;函数名: TIMER1_INITIAL

功能: TIMER1 初始化,设置 TIMER1 定时时长 2.056ms

TIMER1_INITIAL:

BANKSEL PCKEN

LDWI PCKEN_DEF

STR PCKEN

BANKSEL CKOCON

LDWI CKOCON DEF

- 9 - 2021**-**09**-**07



STR CKOCON

BANKSEL TCKSRC

LDWI TCKSRC_DEF

STR TCKSRC

BANKSEL TIM1CR1

LDWI TIM1CR1_DEF

STR TIM1CR1

LDWI TIM1IER_DEF

STR TIM1IER

BANKSEL TIM1ARRH

LDWI TIM1ARRH_DEF

STR TIM1ARRH

LDWI TIM1ARRL_DEF

STR TIM1ARRL

RET

;函数名: PA INT INITIAL

;功能: PA 口电平变化中断初始化

PA_INT_INITIAL:

BANKSEL TRISA

BSR TRISA,3

BANKSEL PORTA LDR PORTA,W BANKSEL READPIN

STR READPIN

BANKSEL EPIE0

BSR EPIE0,IOCA3
BSR EPIF0,IOCA3

BANKSEL EPS0

LDWI EPS0_DEF

STR EPS0

LDWI EPS1 DEF

STR EPS1

BANKSEL ITYPE0

LDWI ITYPE0 DEF



STR ITYPE0

LDWI ITYPE1_DEF

STR ITYPE1

BANKSEL EPIE0

LDWI EPIE0_DEF

STR EPIE0

RET

;DELAY 8US 16MHz/4T

DELAY_8US:

LDWI 0x08 STR TEMP

DELAY_8USLOOP:

CLRWDT

DECRSZ TEMP,F

LJUMP DELAY 8USLOOP

RET

;DELAY_18US 16MHz/4T

DELAY_18US:

LDWI 0x11 STR TEMP

DELAY_18USLOOP:

CLRWDT

DECRSZ TEMP,F

LJUMP DELAY 18USLOOP

RET

;函数名: IR_Start

;功能: 红外发送的引导码 9ms 发送 4.5ms 停止

IR_Start:

CLRR count

IR Start working:

LDWI 0XA2 ;9ms 高电平

SUBWR count,0 BTSC STATUS,0

LJUMP IR_Start_no_work



INCR count,1 **BSR** ir data **LCALL DELAY 8US BCR** ir data **LCALL DELAY 18US BSR** ir_data **LCALL** DELAY_8US **BCR** ir data **LCALL DELAY 18US LJUMP** IR_Start_working IR_Start_no_work: **CLRR** count IR_Start_LOOP: **LDWI** 0X50 **SUBWR** count,0 **BTSC** STATUS,0 **RET INCR** count,1 **BCR** ir data **LCALL** DELAY_8US **BCR** ir data **LCALL** DELAY_18US **BCR** ir data **LCALL** DELAY_8US **BCR** ir data **LCALL** DELAY_18US **LJUMP** IR_Start_LOOP

;函数名: IR_Stop

;功能: 红外发送的连发码 9ms 发送 2.25ms 停止

IR Stop:

CLRR count

IR_Stop_working:

0XA2 ;9ms 高电平 **LDWI**

SUBWR count,0 **BTSC** STATUS,0

LJUMP IR_Stop_no_work

INCR count,1 **BSR** ir data **LCALL DELAY 8US BCR** ir data

LCALL DELAY_18US

BSR ir data ;4.5ms 低电平



LCALL DELAY_8US

BCR ir data

LCALL DELAY_18US
LJUMP IR Stop working

IR_Stop_no_work:

CLRR count

IR Stop LOOP:

LDWI 0X28 ;2.25ms 低电平

SUBWR count,0 BTSC STATUS,0

RET

INCR count,1 BCR ir_data

LCALL DELAY 8US

BCR ir_data

LCALL DELAY_18US

BCR ir_data

LCALL DELAY_8US

BCR ir_data

LCALL DELAY_18US
LJUMP IR Stop LOOP

;函数名: IR_Send_Byte ;功能: 红外发送一个字节

IR_Send_Byte:

CLRR countbyte

IR Send Byte LOOP:

LDWI 0X08

SUBWR countbyte,0 BTSC STATUS,0

RET

INCR countbyte,1
BTSS IRDATTEMP,0

LJUMP \$+3

LCALL IR Send data1

LJUMP \$+2

LCALL IR_Send_data0

BCR STATUS,0 RRR IRDATTEMP,1

LJUMP IR Send Byte LOOP

;函数名: IR Send data0

- 13 - 2021-09-07



;功能: 红外发送数据 0

IR Send data0:

CLRR count IR_Send_data0_working:

LDWI 0X11 ;0.56ms 高电平

SUBWR count,0 BTSC STATUS,0

LJUMP IR Send data0 no work

INCR count,1
BSR ir_data
LCALL DELAY_8US
BCR ir_data

LCALL DELAY 18US

LJUMP IR_Send_data0_working

IR_Send_data0_no_work:

CLRR count

IR_Send_data0_LOOP:

LDWI 0X11 ;0.56ms 低电平

SUBWR count,0 BTSC STATUS,0

RET

INCR count,1
BCR ir_data

LCALL DELAY_8US

BCR ir data

LCALL DELAY_18US

LJUMP IR Send data0 LOOP

;函数名: IR_Send_data1 ;功能: 红外发送数据 1

IR Send data1:

CLRR count IR_Send_data1_working:

LDWI 0X11 ;0.56ms 高电平

SUBWR count,0 BTSC STATUS,0

LJUMP IR_Send_data1_no_work

INCR count,1
BSR ir_data
LCALL DELAY_8US
BCR ir_data

LCALL DELAY_18US



LJUMP IR_Send_data1_working

IR Send data1 no work:

CLRR count

IR Send data1 LOOP:

LDWI 0X37 ;1.69ms 低电平

SUBWR count,0 BTSC STATUS,0

RET

INCR count,1 BCR ir_data

LCALL DELAY_8US

BCR ir data

LCALL DELAY_18US

LJUMP IR Send data1 LOOP

;函数名: scanky_key

;功能: 当按键按下时候发送所需要发送的红外数字,长按发送连发码

scanky_key:

BTSS key

LJUMP scanky_key_down LJUMP scanky_key_up

scanky_key_down:

BTSC f_key

LJUMP scanky_key_long INCR key_short_count,1

LDWI 0X0A

SUBWR key short count,0

BTSS STATUS,0

RET

CLRR key_short_count

BSR f_key
LCALL IR_Start
LDWI 0X55

STR IRDATTEMP LCALL IR Send Byte

LDWI 0XAA

STR IRDATTEMP LCALL IR_Send_Byte

LDWI 0X01

STR IRDATTEMP LCALL IR_Send_Byte

LDWI 0XFE

STR IRDATTEMP



LCALL IR_Send_Byte LCALL IR_Send_data0

RET

scanky_key_long:

LCALL IR_Stop

RET

scanky_key_up:

CLRR key_short_count

BCR f key

RET

;函数名: sleep_mode ;功能: 无操作进入睡眠

sleep_mode:

BTSS key

RET

BTSC f key

RET

LCALL PA_INT_INITIAL

SLEEP NOP RET

END



联系信息

Fremont Micro Devices (SZ) Corporation

#5-8, 10/F, Changhong Building Ke-Ji Nan 12 Road, Nanshan District, Shenzhen, Guangdong, PRC 518057

Tel: (+86 755) 8611 7811 Fax: (+86 755) 8611 7810

Fremont Micro Devices (HK) Corporation

#16, 16/F, Block B, Veristrong Industrial Centre, 34–36 Au Pui Wan Street, Fotan, Shatin, Hong Kong SAR

Tel: (+852) 2781 1186 Fax: (+852) 2781 1144

http://www.fremontmicro.com/

- 17 -

2021-09-07

^{*} Information furnished is believed to be accurate and reliable. However, Fremont Micro Devices (SZ) Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents of other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent rights of Fremont Micro Devices (SZ) Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all information previously supplied. Fremont Micro Devices (SZ) Corporation products are not authorized for use as critical components in life support devices or systems without express written approval of Fremont Micro Devices (SZ) Corporation. The FMD logo is a registered trademark of Fremont Micro Devices (SZ) Corporation. All other names are the property of their respective owners.