	Checklis	t Template			
Company Name	Checklist Name	Date Created	Revision Number		
One Touch Automation	Execute Rough-in	5/14/2024			
Che	cklist Frequency (Daily/Week	ly/Monthly/Project or Phas	e Based)		
	Phase	Based			
		Description			
	5.1.0010				
Who	's Involved	When is the o	hecklist needed?		
Name	Department or Function	Example: Phase comple		ed. etc.	
-ech	Production		ne Rough-In phase		
PM	Job Assigned PM		<u>-</u>		
	What are	the items?			
	Item				
	JOB PREP		Completed By	Date	
Review contract for scope of w	ork		1		
Ensure you have appropriate d	ocumentation in hand before start of	phase. (wire chart, tv elevations,			
loor plans, camera placements					
Sather necessary wiring for Ro	-				
	ough-in boxes, carlon tube, stapes, st	tud guards, tape, markers, etc)			
Pull Rough-in equipment from S					
Check out any product from Sta	aging in Tracknicity				
	START / IN PROGRESS		Completed By	Date	
	speaker rings, James speakers				
Plan main trunk line and drill to	· · · · · · · · · · · · · · · · · · ·				
Place boxes and label wires pri					
	to mechanical. (Review runs along				
Tack wires 6" from wall box and 6" from top plate (like electricans do with their romex)					
	k from face of stud, install stud guard				
vali Boxes - Once landed in th Irywall	e LV boxes, carefully coil and push to	back of box in preparation for			
•	ns documentation to determine what	height boxes are to be set			
	adding horitzontal supports to top and	•			
	stallations to allow mount to secure to				
	END OF DAY		Completed By	Date	
Post project notes from the day					
Add photos for notes in thread					
Jpdate Project ToDo list for the					
•	•				
GENI	ERAL GUIDELINES - STRUCTURE	O WIRING			
	s should be ran 18" out of box to give	room to trim out wires and to have			
extra.	111		N/A		
All Lutron keypad locations should have 12" of wire coming out of the box			N/A		
Il Home Runs should be labeled with proper wire tag (wire use, location and wire #) (i.e. WAP-101-1)		N/A			
All RG-6 coax ran to 4x4 plywood sheet hole where Comcast can install their splitter			N/A N/A		
	I Cat6, Audio, Control Wiring should be ran to DEB48 Panel. I wiring to be ran according to wire checklist unless substitution/alteration is approved by the project				
an wining to be rain according to ead.	wife checklist unless substitution/alt	cration is approved by the project	N/A		
or security, All wiring should b	e ran to Structured Wiring Panel. Lea		7		
ocation for trim out. Leave at le	east 3' extra wire at panel location for	trim out.			
Label Each Wire with Device Location and Type (i.e. Master Bed Glass Break) at Panel Location.			N/A		
ttic trunklines should be tacked up and off the attic joists. This prevents potential trip hazards in the			IN/A		
Attic trunklines should be tacke	d up and off the attic joists. This prev	vents potential trip hazards in the			

	ENERAL CUIDE	LINES - WALLBO	v			
_				ortant to measure		
If the outlet is marked low on the wall, match the electrician's wall box height. It is important to measure the closest box and match it (not just one - who knows if the electrician measured the same each time)					N/A	٨
In Bedrooms - Typical Wall Mounted TV Outlets are placed at 72" to the top of box.					N/A	١
In Rooms where the typical locatio	n for watching wi	Il be on the couch,	48" - 60" depen	ding on the room.	N/A	١
Above Fireplace - Typically 24" above Top of Mantel.					N/A	
If box is on an interior wall - use ba	ickless boxes.				N/A	١
If box is on an exterior wall - use b	acked boxes.				N/A	١
	CABLE PACKA	GE OVERVIEWS				
PACKAGE NAME	KAGE NAME CABLING INCLUDED					
сомво	RG-6	CAT6				
	QTY: 1	QTY: 1				
DAVP	RG-6	CAT6	CAT6	MMF SIMESE		
27.00	QTY: 1	QTY: 1	QTY: 1	QTY: 1		
FUTURE PROOF TV OUTLET	RG-6	CAT6	CAT6	CAT6A SHIELDED	MMF SIMESE	
713131113311133111	QTY: 1	QTY: 1	QTY: 1	QTY: 1	QTY: 1	
PROJECTOR PRE-WIRE*	CAT6	CAT6	CAT6A SHIELDED		CARLON TUBE	
	QTY: 1	QTY: 1	QTY: 1	QTY: 1	QTY: 1	ATT 14/
*NOTE: CAT6 GRAY Can be used to a also utilize the Cat6 for a HDMI Extend		of a TV. Some ISP u	se the ethernet co	onnection to distribute	video to their boxes	- ATT. We can
	16/4 WHITE	16/2 WHITE				
WHA 16ga*	QTY: 1	QTY: 1				
*NOTE: Run 16/4 to closest speaker to	homerun, then rur	n 16/2 jumper from sj	peaker to speaker	r		
			·			
14/11A 44 mat	14/4 WHITE	14/2 WHITE				
WHA 14ga*	QTY: 1	QTY: 1				
*NOTE: Run 14/4 to closest speaker to	homerun, then rur	n 14/2 jumper from sp	peaker to speaker	r		
SURROUND W/ PASSIVE SUB*	14/2 BLACK	14/4 BLACK				
	QTY: 5-8	QTY: 1				
*NOTE: Homerun 14/2 Black from DE	3 to each speaker.	If dual subwoofers a	re installed, run a	14/4 Black with a 14/	'2 going from first sul	bwoofer to next
subwoofer.						
	14/2 BLACK	RG-6 BC				
SURROUND W/ POWER SUB*	QTY: 5-7	QTY: 1-2				
*NOTE: Homorum 14/2 Block from DEI			re installed run e	DC 6 Block to sook i	lagation	
*NOTE: Homerun 14/2 Black from DEB	о со саст ъреакег.	n duai subwooieis a	re motalieu, fuil a	TIG-U DIACK (U EACH I	ocalion	
	CAT6					
DATA	QTY: 1	1				
	Q I I. I					
	CAT6	Г				
DUAL DATA	QTY: 2	1				
	Q(11. Z	1				
	CAT6	Ī				
PHONE	QTY: 1	i				
	Q(1 1 . 1	1				
	CAT6	Ī				
WAP	QTY: 1	1				
	Q(1 1 . 1	1				
	CAT6	Ī				
TOUCH PANEL	QTY: 1	İ				
	Q(1 .					

	-		9	= =====================================	-
	CAT6				
IP CAMERA	QTY: 1				
	CAT6	18/4			
DOORBELL/DOORSTATION	QTY: 1	QTY: 1			
	QTT.T	QII.I			
	DO 6	CATC	0145 0114505		
DEMARK	RG-6	CAT6	SMF SIMESE		
*NOTE: Dun out the side of house who	QTY: 1	QTY: 1	QTY: 1	the Fleetrical Crounding De	d to around their food
*NOTE: Run out the side of house whe Place in Weatherproof Box to protect to					a to ground their reed.
			-		
SECURITY - KEYPADS /	22/4				
WIRELESS RECEIVERS	QTY: 1				
*NOTE: Top of Box at 60". If you we ca		ox, zig zag wiring a	above light switches so l	keypad can be mounted cer	ntered. Keypads are
installed 60" Above Finished Floor to t					,,
SECURITY - DOOR CONTACTS	22/4				
SECURITY - DOOR CONTACTS	QTY: 1				
*NOTE: The wiring should be drilled ou	it of Jamb side of do	oor with 3/4" hole. V	When you leave pre-wire	, the wire should be stubbe	d out so it is ready for the
door to be installed.					
SECURITY - WINDOW	22/4				
CONTACTS	QTY: 1				
*NOTE: Drill either side of 2x4 holding	the side of the wind	ow - 6" above botto	om of window seal. We t	pically use surface mount	contacts to avoid voiding
the window warranty.					
	22/4				
SECURITY - GLASS BREAKS	22/4				
	QTY: 1				
*NOTE: GB's must be centered in wind surface mount glass break. Use Blue E		a 2x4 to get it cent	ered, do it. If there is a f	loor joist in the way, use a i	nail and we will install a
grace					
SECURITY MOTION	22/4				
SECURITY - MOTION DETECTORS	QTY: 1				
*NOTE: Nail Motion Detector Wiring ou		n nail with wire ma	ake sure there is enough	slack inside wall in case th	e wire is damaged by the
drywaller so we can pull it out and use		p nan war wie, me	and dare there is chough	older molde wan in ease th	e wire is durinaged by the
	22/4				
SECURITY - WATER SENSORS	QTY: 1				
*NOTE: Sump pits, Ejector pits, mecha					
NOTE: Sump pits, Ejector pits, meene	inical rooms				
OFOURITY ONOUE	10/4				
SECURITY - SMOKE DETECTORS	18/4				
*NOTE: Run Red 18/6 Fire Wire. Home	QTY: 1	o Dotootor in line	and then as from smake	to smake until you come to	the last one. Once at last
one, home run the end of line too. Mu					
entrances. Install a blue box for the de	tector.			· · · · · · · · · · · · · · · · · · ·	
SECURITY - HEAT	18/4				
DETECTORS	QTY: 1				
*NOTE: Run Red 18/4 Fire Wire. Home	e run the wire for the	e detector. Install a	blue box for the detecto	or.	
	22/4				
SECURITY - GAS DETECTORS	QTY: 1				
*NOTE: Place Poy 12" from soiling to		Roy			
*NOTE: Place Box 12" from ceiling to t	op oi box. Ose Blue	DUX			
	0044				
SECURITY - SIREN/SPEAKERS	22/4				
	QTY: 1				
*NOTE: 1G ring installed at outlet heigh	tht typically in hedre	nom hallwavs	·		

	-	=	=

		_	_	_		
SECURITY - CELL RADIO	CAT6	16/4		_	-	
	QTY: 1	QTY: 1				
*NOTE: Generally installed in the 2nd	Floor closet or Attic	;	-			
GARAGE DOOR CONTROL	CAT6	22/4				
	QTY: 1	QTY: 1				
*NOTE: CAT6 runs to operator (motor) and 22/4 in same box), 22/4 runs to the d	oor for contact. At o	pperator, install Blue	e box and land CAT6	5. If sidemount operator, land conti	ol .
	Who o	does the proce	ess transfer to	next?		
Name		Department or Function		Milestone		
Project Manager		Project	Project Manager		Rough-In Complete	