	Checklis	t Template		
Company Name	Checklist Name	Date Created	Revision N	lumber
One Touch Automation	Execute Rough-in	5/14/2024	V2	
Che	cklist Frequency (Daily/Week	ly/Monthly/Project or Phas	e Based)	
	Phase	Based		
		Description		
	5.1.0010			
Who	's Involved	When is the o	hecklist needed?	
Name	Department or Function	Example: Phase comple		ed. etc.
-ech	Production		he Rough-In phase	,
PM	Job Assigned PM		<u>-</u>	
	What are	the items?		
	Item			
	JOB PREP		Completed By	Date
Review contract for scope of w	ork		1	
Ensure you have appropriate d	ocumentation in hand before start of	phase. (wire chart, tv elevations,		
loor plans, camera placements				
Sather necessary wiring for Ro	-			
	ough-in boxes, carlon tube, stapes, st	tud guards, tape, markers, etc)		
Pull Rough-in equipment from S				
Check out any product from Sta	aging in Tracknicity			
	START / IN PROGRESS		Completed By	Date
	speaker rings, James speakers			
Plan main trunk line and drill to	· · · · · · · · · · · · · · · · · · ·			
Place boxes and label wires pri				
	to mechanical. (Review runs along			
ack wires 6" from wall box and				
	k from face of stud, install stud guard			
vali Boxes - Once landed in th Irywall	e LV boxes, carefully coil and push to	back of box in preparation for		
•	ns documentation to determine what	height boxes are to be set		
	adding horitzontal supports to top and	•		
	stallations to allow mount to secure to			
	END OF DAY		Completed By	Date
Post project notes from the day				
Add photos for notes in thread				
Jpdate Project ToDo list for the				
•	•			
GENI	ERAL GUIDELINES - STRUCTURE	O WIRING		
All wiring at Wall plate locations				
extra.			N/A	
All Lutron keypad locations should have 12" of wire coming out of the box All Home Runs should be labeled with proper wire tag (wire use, location and wire #) (i.e. WAP-101-1)			N/A	
All RG-6 coax ran to 4x4 plywo	N/A			
All Cat6, Audio, Control Wiring All wiring to be ran according to	N/A			
an wining to be rain according to ead.	N/A			
or security, All wiring should b	e ran to Structured Wiring Panel. Lea		7	
ocation for trim out. Leave at le	east 3' extra wire at panel location for	trim out.		
abel Each Wire with Device Lo	N/A	Ν/Δ		
			1 11//3	
Attic trunklines should be tacke	d up and off the attic joists. This prev	vents potential trip hazards in the		

	ENERAL CUIDE	LINES - WALLBO	v			
If the outlet is marked low on the w				ortant to measure		
the closest box and match it (not ju					N/A	
In Bedrooms - Typical Wall Mounte	ed TV Outlets are	placed at 72" to th	e top of box.		N/A	١
In Rooms where the typical locatio	n for watching wi	Il be on the couch,	48" - 60" depen	ding on the room.	N/A	١
Above Fireplace - Typically 24" abo	ove Top of Mante	l.			N/A	
If box is on an interior wall - use ba	ickless boxes.				N/A	١
If box is on an exterior wall - use b	acked boxes.				N/A	١
	CABLE PACKA	GE OVERVIEWS				
PACKAGE NAME	PACKAGE NAME CABLING INCLUDED					
сомво	RG-6	CAT6				
	QTY: 1	QTY: 1				
DAVP	RG-6	CAT6	CAT6	MMF SIMESE		
27.11	QTY: 1	QTY: 1	QTY: 1	QTY: 1		
FUTURE PROOF TV OUTLET	RG-6	CAT6	CAT6	CAT6A SHIELDED	MMF SIMESE	
713131113311133111	QTY: 1	QTY: 1	QTY: 1	QTY: 1	QTY: 1	
PROJECTOR PRE-WIRE*	CAT6	CAT6	CAT6A SHIELDED		CARLON TUBE	
	QTY: 1	QTY: 1	QTY: 1	QTY: 1	QTY: 1	ATT 14/
*NOTE: CAT6 GRAY Can be used to a also utilize the Cat6 for a HDMI Extend		of a TV. Some ISP u	se the ethernet co	onnection to distribute	video to their boxes	- ATT. We can
	16/4 WHITE	16/2 WHITE				
WHA 16ga*	QTY: 1	QTY: 1				
*NOTE: Run 16/4 to closest speaker to	homerun, then rur	n 16/2 jumper from sj	peaker to speaker	r		
			·			
14/11A 44 mat	14/4 WHITE	14/2 WHITE				
WHA 14ga*	QTY: 1	QTY: 1				
*NOTE: Run 14/4 to closest speaker to	homerun, then rur	n 14/2 jumper from sp	peaker to speaker	r		
SURROUND W/ PASSIVE SUB*	14/2 BLACK	14/4 BLACK				
	QTY: 5-8	QTY: 1				
*NOTE: Homerun 14/2 Black from DE	3 to each speaker.	If dual subwoofers a	re installed, run a	14/4 Black with a 14/	'2 going from first sul	bwoofer to next
subwoofer.						
	14/2 BLACK	RG-6 BC				
SURROUND W/ POWER SUB*	QTY: 5-7	QTY: 1-2				
*NOTE: Homorum 14/2 Block from DEI			re installed run e	DC 6 Block to sook i	lagation	
*NOTE: Homerun 14/2 Black from DEB	о со саст ъреакег.	n duai subwooieis a	re motalieu, fuil a	TIG-U DIACK (U EACH I	ocalion	
	CAT6					
DATA	QTY: 1	1				
	Q I I. I					
	CAT6	Г				
DUAL DATA	QTY: 2	1				
	Q(11. Z	1				
	CAT6	Ī				
PHONE	QTY: 1	i				
	Q(1 1 . 1	1				
	CAT6	Ī				
WAP	QTY: 1	1				
	Q(1 1 . 1	1				
	CAT6	Ī				
TOUCH PANEL	QTY: 1	İ				
	Q(1 .					

	-		= = =	=	=
	CAT6				
IP CAMERA	QTY: 1				
	CAT6	18/4			
DOORBELL/DOORSTATION	QTY: 1	QTY: 1			
	QII.I	QIT. I			
	50.0	0.470			
DEMARK	RG-6	CAT6	SMF SIMESE		
***************************************	QTY: 1	QTY: 1	QTY: 1		
*NOTE: Run out the side of house whe Place in Weatherproof Box to protect to					to grouna their teea.
, idea iii ii edailei pi eei Zex te pi eteet ii			9004 00 4		
SECURITY - KEYPADS /	22/4				
WIRELESS RECEIVERS	QTY: 1				
*NOTE: Top of Box at 60". If you we ca		nov zia zaa wirina :	ahove light switches so ke	evnad can be mounted cent	tered Keynads are
installed 60" Above Finished Floor to t			above light switches so ke	ypad can be mounted cent	creu. Reypaus are
	22/4				
SECURITY - DOOR CONTACTS	QTY: 1				
*NOTE: The wiring should be drilled ou		oor with 3/4" hole. V	When you leave pre-wire,	the wire should be stubbed	out so it is ready for the
door to be installed.					,
SECURITY - WINDOW	22/4				
CONTACTS	QTY: 1				
*NOTE: Drill either side of 2x4 holding	the side of the wind	ow - 6" above botto	om of window seal. We ty	pically use surface mount c	ontacts to avoid voiding
the window warranty.					
SECURITY - GLASS BREAKS	22/4				
SECONTT - GEAGG BREAKS	QTY: 1				
*NOTE: GB's must be centered in wind		a 2x4 to get it cent	ered, do it. If there is a flo	oor joist in the way, use a na	ail and we will install a
surface mount glass break. Use Blue E	iox				
SECURITY - MOTION	22/4				
DETECTORS	QTY: 1				
*NOTE: Nail Motion Detector Wiring of drywaller so we can pull it out and use		p nail with wire, ma	ake sure there is enough :	slack inside wall in case the	wire is damaged by the
ary maner se me san pan n san ana ass	the good who.				
	22/4				
SECURITY - WATER SENSORS					
	QTY: 1				
*NOTE: Sump pits, Ejector pits, mecha	inical rooms				
SECURITY - SMOKE	18/4				
DETECTORS	QTY: 1				
*NOTE: Run Red 18/6 Fire Wire. Hom					
one, home run the end of line too. Mu entrances. Install a blue box for the de		nignest Point in ea	ach room at least 3 away	from any HVAC vent, 10 ff	от ваттоот
SECURITY - HEAT	18/4				
DETECTORS	QTY: 1				
*NOTE: Run Red 18/4 Fire Wire. Home	s run the wire for the	e detector. Install a	unue box for the detector		
	2011				
SECURITY - GAS DETECTORS	22/4				
	QTY: 1				
*NOTE: Place Box 12" from ceiling to t	op of box. Use Blue	Вох			
SECUDITY SIDEMISDEAUEDS	22/4				
SECURITY - SIREN/SPEAKERS	QTY: 1				
*NOTE: 1G ring installed at outlet heig		oom hallways			

	-	=	=

_		_					
SECURITY - CELL RADIO	CAT6	16/4			-		
	QTY: 1	QTY: 1					
*NOTE: Generally installed in the 2nd	Floor closet or Attic	;					
GARAGE DOOR CONTROL	CAT6	22/4					
	QTY: 1	QTY: 1					
*NOTE: CAT6 runs to operator (motor), 22/4 runs to the door for contact. At operator, install Blue box and land CAT6. If sidemount operator, land control and 22/4 in same box							
	Who	does the proce	ess transfer to	next?			
Name		Department or Function			Milestone		
Project Manager		Project Manager		F	Rough-In Complete		
				_			