ASSEMBLY OF THRUST BEARING MATERIAL:
PROPELLER BLADE
1/8
1ST STEP
2 ND STEP
WASHERS
SHAFT
FINISHED HUB
PERSPECTIVE REAR VIEW

COCKPIT PATTERN

STABILIZER
MATERIAL: 1-16"X1-16" AND PRINTED PARTS. USE HEAVY PAPER FOR CONTROL HINGES.

ELEVATOR
ELEVATOR
HINGE
STABILIZER

BALANCING
MATERIAL: LEAD SHOT-NOT FURNISHED- ADD A FEW TO NOSE UNTIL MODEL BALANCES WHEN SUSPENDED BY THE FOREFINGERS AT THE CENTER OF THE WING TIPS.

MOTOR SHAFT
STEEL SHAFT, BENT TO SHAPE SUPPLIED WITH KIT.

PERSPECTIVE VIEW OF FRONT
PASTE MOTOR HERE
8 OF THESE EVENLY SPACED

BUILT-UP NOSE BEARING
MATERIAL: 1-16"X1-16" LEFT-OVERS FROM NOSE BLOCK - MAKE SIZE AS ILLUSTRATED.

RUBBER BAND
FITS INTO SLOT
MOTOR ATTACHMENT

MOTOR

INST. PANEL

PILOT

NUMBERS ETC.
MATERIAL: CUT-OUTS FURNISHED WHERE REQUIRED.

BODY 1ST STEP
MATERIAL: 1-16"X1-16" USE STRIP WOOD SUPPLIED AND MAKE TWO SIDES, ONE FOR THE LEFT SIDE ONE FOR THE RIGHT SIDE. CHECK ON SIDE VIEW.

BODY 2ND STEP
MATERIAL: 1-16"X1-16" CEMENT THE TWO SIDES TOGETHER TO FORM THE GENERAL SQUARE PART OF THE FUSELAGE.

BUILT UP NOSE PLUG
SHAFT
WASHERS
INST. PANEL
UPRIGHT
TWO STRAND RUBBER MOTOR
LEAVE THIS SECTION OPEN
FIN
RUDDER
WING
LONGEROS

SIDE VIEW

RUDDER
MATERIAL: 1-16"X1-16" STRIPS AND CURVED PIECES.

RUBBER MOTOR
SIDE VIEW
THIS FORMER LARGE
THIS FORMER SMALLER

TAIL SKID OR WHEEL
MATERIAL: IN MOST CASES MADE FROM LEFT OVERS. CHECK WITH RIB SHEET.

PLAN VIEW

PROPELLER
MATERIAL: CUT BLADES FROM RIB SHEET REMAINING PARTS FROM NOSE BLOCK. SHAFT AND WASHERS ARE SUPPLIED IN THE KIT.

LANDING GEAR
MATERIAL: CONSTRUCTED FROM STRIP WOOD OR CURVED PARTS. CHECK PIECES WITH RIB SHEET.

AILERON
TRAILING EDGE 1-16"X1-8"
AILERON
HINGE
RIGHT WING
BODY
LEFT WING
W2
W4
WING TIP 3-64"
SPAR 1-16"X1-8"
RIB 3-64"
GUN
CROSS PIECE
1-16"X1-8" LEADING EDGE
WING TIP 3-64"
W1
W3

BODY 3RD STEP
MATERIAL: 1-16"X1-16" ALSO SOME CURVED PARTS ARE NOW ADDED TO ROUND OFF THE FUSELAGE.

MOTOR COWL
NOSE BLOCK

BODY SECTIONS

STRIP SHEET
MATERIAL ALL STRIPS ARE CUT TO THE CORRECT SIZES 1-16"X1-16" AND 1-16"X1-8" SELECT THESE PARTS CAREFULLY AS CONSTRUCTION PROCEEDS.

RIB SHEET
MATERIAL BALSA PRINTED SHEET 1-32" WITH ALL RIBS AND IN SOME CASES PARTS FOR WING TIPS-RUDDER-STABILIZER-BODY FORMERS AND ONE OR TWO OTHER PARTS.

COVERING
MATERIAL: TISSUE IS PUT ON BODY IN SECTIONS. COVER WING AND STABILIZER ON ONE SIDE. COVER RUDDER ON BOTH SIDES. USE DILUTED CEMENT OR FLOUR PASTE. WHEN COVERED SPRAY LIGHTLY WITH WATER AND ALLOW TO SHRINK.

NOSE BLOCK

WING

BODY SECTIONS

INST. PANEL

NOSE BLOCK
MATERIAL: LARGE SOLID PIECE ABOUT 3-16" THICK. DRAW NOSE SHAPE WITH COMPASS AND CUT OUT.

COWL PATTERN

GENERAL ASSEMBLY
MATERIAL: COMPLETE AND COVER ALL PARTS, THEN ASSEMBLE.

STUDY PLANS AND PERSPECTIVE SKETCHES BEFORE STARTING ANY OF THE ACTUAL MODEL WORK. PIN PLAN TO A SOFT BOARD AND USE WAXED PAPER OVER PLAN TO PREVENT THE WOOD FROM STICKING TO THE PLAN.

FRONT VIEW

FLYING
AFTER MODEL HAS BEEN BALANCED, CHECK GLIDING QUALITIES AND THEN WIND THE PROPELLER ABOUT 50 TO 75 TURNS FOR ITS FIRST TRIAL FLIGHT.

RIB SECTIONS

COPYRIGHT 1938
J.L. WRIGHT INC. CHICAGO, ILLINOIS
PRINTED IN U.S.A

FD-417

18" 1938 FOKKER Pursuit

FLYING SCALE MODEL Nº 1702

Provided to www.Outerzone.co.uk