

Sensor 1:

Ground -> Ground (Blue Railing on the bread board)

+5 --> Put the nucleo 5 volts on a bread board and put it on the same rail

Tx1 -> Nothing

AN1 -> Share the same connection as PA0 and RX2 (RX2 = Sensor 2) on the bread board.

PW -> Nothing

BW -> Powered by the 5+ volts power railing on the bread board

Sensor 2:

Ground -> Ground (Blue Railing on the bread board)

+5 --> Put the nucleo 5 volts on a bread board and put it on the same rail

Tx1 -> Nothing

RX2 -> Connected to PA0 and AN1 on the same rail

AN2 -> Connected to PA3 on the STM32

PW -> Nothing

BW -> Powered by the 5+ volts power railing on the bread board

