
## MCB LAYOUT & PARTS LIST



عور ال

10-17 10-18 10-20 10-21 10-21 10-22 10-23 10-23 10-25 **Y**C-3 10-6 10-7 10-8 4-0-H (C-14 |C-15 C-12 C-13 C-11 C-10 C-9 7474V 741832 14889 R-PAC 82555 82555 82555 82550 8279C EPROM EPROM EPROM 21114 V 21114 V 74LS04 74LS244V 74LS244V 74LS245V 74LS367V 74LS:04 東5-7 東10 553-4 13-4 \$\$\$\$\$\$ XTAL1 XTAL2 1 C-29 1 C-30 1 C-31 1 ı .26 74LS42V 74LS42V 74LS00V 74LS42V 1N4148 4.7K RESET SWI 4.000 Mhz NOT USED
100 ufd
.01 ufd
.01 ufd
470 pfd
.01 ufd
22 pfd
47 pfd
.01 ufd 470 330 TERMINAL OPTIONAL ohm Mhz SWITCH

All res is 15 pu pull are up resistors 1/4 watt 5% 4.7k

© 5May 82 M. Simon