Creating and Using Platform for an Application

Introduction

This lab guides you through the steps of creating a custom platform for an audio application.

Objectives

After completing this lab, you will be able to:


- Create an SDSoC platform for an custom application
- Use the SDSoC environment to test the platform for an audio filtering Standalone application

Procedure

This lab is separated into steps that consist of general overview statements that provide information on the detailed instructions that follow. Follow these detailed instructions to progress through the lab.

This lab comprises three primary steps: You will create an SDSoC project, test the custom platform, and test the platform for the filter application.

General Flow for this Lab






Create a Custom Platform

Step 1

- 1-1. Launch Vivado, create the platform design, and generate an archive of the project.
- **1-1-1.** Using the Windows Explorer, copy the **zed_audio** directory (for Zed) or **zybo_audio** directory (for Zybo) from the *sourceVab7* directory and place it in the *c:\xup\SDSoCVabsVab7* directory.

This will copy all the necessary directories and files, creating the required directory structure.

Note another file (not shown below), called *zed_audio_sw.pfm* (for Zed) or *zybo_audio_sw.pfm*, (for zybo) is provided. Typically this will have to be hand created. The file describes the SDSoC software component. It defines file names and locations of the library and boot components.



(a) Zed (b) Zybo

Figure 1. The directory structure for creating the SDSoC platform

```
?xml version="1.0" encoding="UTF-8"?>
<xd:repository xd:vendor="xilinx.com" xd:library="xd" xd:name="zybo audio"</p>
xd:version="1.0" xmlns:xd="http://www.xilinx.com/xd" >
    <xd:description>Platform targeting the ZYBO board for an audio applicat
ion. More information at http://www.digilentinc.com/</xd:description>
    <xd:libraryFiles</pre>
      xd:os="standalone"
      xd:libName="xil"
      xd:bspconfig="arm-xilinx-eabi/system.mss"
      xd:includeDir="arm-xilinx-eabi/include"
      xd:ldscript="arm-xilinx-eabi/lscript.ld"
    <xd:bootFiles</pre>
      xd:os="standalone"
      xd:bif="boot/standalone.bif"
      xd:readme="boot/generic.readme"
</xd:repository>
```

Figure 2. The <board> audio sw.pfm file content

- 1-1-2. Open Vivado by selecting Start > All Programs > Xilinx Design Tools > SDSoC 2015.4 > Vivado Design Suite > Vivado 2015.4
- **1-1-3.** In the Vivado's Tcl Console window change the directory to the c:/xup/SDSoC/labs/lab7/zed_audio/vivado/ or c:/xup/SDSoC/labs/lab7/zybo_audio/vivado/ using the **cd** command.




cd c:/xup/SDSoC/labs/lab7/zed_audio/vivado (for Zed) or cd c:/xup/SDSoC/labs/lab7/zybo_audio/vivado (for Zybo)


1-1-4. Execute the following command to generate the platform hardware.

```
source ./zed_audio.tcl (for Zed) or
source ./zybo_audio.tcl (for Zybo)
```

This will create an IPI design and an HDL wrapper, and add an xdc constraints file.



(a) Zed



(b) Zybo

Figure 3. The IPI design

- **1-1-5.** Since the design contains an audio controller IP, which is not part of the standard Vivado installation IP, we need to archive the project so the custom IP is part of the platform.
- 1-1-6. Select File > Archive Project...



1-1-7. Click on the browse button of the *Temporary location* path and set it to **c:\temp** or a shorter path. Change the *Archive name* to **zybo_audio_hw_design**. Change the *Archive location* to **c:/xup/SDSoC/labs/lab7** or some other place than where the project was created.




Figure 4. Archiving the project

1-1-8. Click OK.

This will generate the **zed_audio_hw_design.zip** or **zybo_audio_hw_design.zip** file in the specified directory. Note that although the zip filename is different, the folder inside is still **zed_audio** or **zybo_audio**.

- 1-1-9. Close the Vivado project by selecting File > Close Project.
- 1-2. Unzip the archived project and copy the relevant files/directories.
- 1-2-1. Unzip the zed_audio_hw_design.zip or zybo_audio_hw_design.zip into c:\xup\SDSoc\labs.

This is required since the zip file contains a root folder called zed_audio or zybo_audio.

- **1-2-2.** Using the Windows Explorer, delete all the files and directories under the c:\university\undersit
- **1-2-3.** Copy everything from the extracted directory and place them in the *c:\xup\SDSoCVabs\lab\text{aba}\zybo_audio\vivado* directory.
- **1-2-4.** Keep only the *zybo_audio.ipdefs, zybo_audio.srcs directories*, and the *archive project summary.txt* and *zybo audio.xpr* files, and delete all other files and directories.
- 1-3. Generate the hardware description for the board.
- **1-3-1.** In Vivado, open the zed_audio or zybo_audio project and open the block design.

Note that the block design must be open to execute the following steps to generate the hardware description.



1-3-2. Source the SDSoC platform creation tcl script by executing the following command:

```
source -notrace c:/Xilinx/SDSoC/2015.4/scripts/vivado/sdsoc_pfm.tcl
set pfm [sdsoc::create_pfm zed_audio_hw.pfm]
or
set pfm [sdsoc::create_pfm zybo_audio_hw.pfm]
```

Replace c:/Xilinx/SDSoC/2015.4 with the location of your installation if necessary.

The second command will start the creation of a platform called *zed_audio_hw* or *zybo audio hw*.

1-3-3. Declare a brief platform description:

```
sdsoc::pfm_name $pfm "xilinx.com" "xd" "zed/zybo_audio" "1.0"
sdsoc::pfm description $pfm "Zyng ZedBoard/Zybo with audio codec"
```

1-3-4. Define the main clock which will be used as the default clock along with any other clock domains that SDSoC may use while generating accelerators.

```
sdsoc::pfm_clock $pfm FCLK_CLK0 processing_system7_0 0 true
rst_processing_system7_0_100M
```

Note that FCLK_CLK0 is the clock domain which will be used by default. The processing_system7_0 is the instance name of the processor and rst_processing_system7_0_100M is the instance name of the processor reset block associated to the clock domain. The "0" before the true indicates the clock number, and true indicates that this is the default clock which will be used by SDSoC, unless the user selects a different clock, for example, in the case of a multi-clock design.

1-3-5. Declare the platform AXI bus interfaces by executing the following commands:

```
sdsoc::pfm_axi_port $pfm M02_AXI processing_system7_0_axi_periph
M_AXI_GP
sdsoc::pfm axi port $pfm S AXI ACP processing system7 0 S AXI ACP
```

In this section you define the AXI ports which you want SDSoC to use when connecting accelerators. In our design, M_AXI_GP0 is being used to communicate with the CODEC controller and an AXI GPIO through the processing_system7_0_axi_periph instance (of AXI_Interconnect). Since our FIR filter will connect to the processor using an AXI-Lite interface, the first command will allow it to share M_AXI_GP using the next available port on the AXI Interconnect.

SDSoC expects at least one slave interface so the hardware accelerator can use DDR memory and/or DMA. The second command instructs SDSoC that S_AXI_ACP may be used for that purpose.

If you would like to allow other interfaces to be used by SDSoC then use the appropriate commands from the listed below.

```
sdsoc::pfm_axi_port $pfm M_AXI_GP1 processing_system7_0 M_AXI_GP
sdsoc::pfm_axi_port $pfm S_AXI_HP0 processing_system7_0 S_AXI_HP
sdsoc::pfm_axi_port $pfm S_AXI_HP1 processing_system7_0 S_AXI_HP
sdsoc::pfm_axi_port $pfm S_AXI_HP2 processing_system7_0 S_AXI_HP
sdsoc::pfm_axi_port $pfm S_AXI_HP3 processing_system7_0 S_AXI_HP
```



You may see a warning that can be ignored.

1-3-6. Define the available interrupts by executing the following command:

```
for {set i 0} {$i < 16} {incr i} {
sdsoc::pfm_irq $pfm In$i xlconcat_0
}</pre>
```

The above command makes all sixteen interrupt pins available to SDSoC. If the user defined platform requires some interrupts, they will occupy positions starting at interrupt 0 and in such a case set i 0 should be set to the next available interrupts. e.g. if two 2 interrupts are required by the platform (interrupts 0,1) the SDSoC interrupts will start at 2. *i* should be set to 2 in the above command:

1-3-7. Generate the platform hardware description metadata file by executing the following command:

```
sdsoc::generate_hw_pfm $pfm
```

This will generate the **zed_audio_hw.pfm** or **zybo_audio_hw.pfm** file in the *vivado* directory.

- **1-3-8.** Using the Windows Explorer, copy the *.pfm file to the *c:\xup\SDSoC\labs\lab7\zed_audio* or \zybo_audio directory.
- 1-4. Export the vivado project and generate the software description.
- **1-4-1.** In Vivado, export the hardware by selecting **File > Export > Export Hardware**

The Generate Output Products dialog box will appear.

1-4-2. Click on the **Generate Output Products** button.

This will generate the output products and present another dialog box. Click **OK**.

The **zed_audio.sdk** or **zybo_audio.sdk** directory will be created under the *vivado* directory.

- **1-4-3.** Click **OK** to close the critical warning window if displayed.
- **1-4-4.** Using the Windows Explorer, delete the files and directories shown in the red boxes below.






Figure 5. Directory content

1-4-5. Open SDSoC by selecting Start > All Programs > Xilinx Design Tools > SDSoC 2015.4 > SDSoC 2015.4

The workspace dialog box will open.

1-4-6. Click on the **Browse** button, select the c:\xup\SDSoC\abs\lab7\zybo_audio\vivado\zybo_audio.sdk directory and click **OK**. Click **OK** again.




Figure 6. Selecting the workspace

1-4-7. Select **File > New > Projects** and then expand Xilinx and select *Hardware Platform Specification* and click Next.






Figure 7. Creating the hardware platform specification project

1-4-8. Enter **zed_audio** or **zybo_audio** as the *project name*, click on the browse button of *Target Hardware Specification* and browse to *c:\xup\SDSoC\labs\lab7\zed_audio\vivado\zed_audio.sdk* or *c:\xup\SDSoC\labs\lab7\zybo_audio\vivado\zybo_audio.sdk*, select **zed_audio_wrapper.hdf** or **zybo audio wrapper.hdf**, and click **Finish**.




Figure 8. Creating hardware project in SDSoC



- 1-4-9. Select File > New > Projects, then expand Xilinx and select Board Support Package and click Next.
- **1-4-10.** Click **Finish** with *standalone_bsp_0* as the *Project name*, making sure that *zed_audio* or *zybo_audio* is selected as the *Hardware Platform*.




Figure 9. Creating the board support package for the platform

The Board Support Package Settings will open.

- 1-4-11. Select xilffs library and click **OK**.
- **1-4-12.** Right-click on the standalone_bsp_0 and select **build project**.
- 1-5. Create an Hello World application to generate a linker script.
- **1-5-1.** Select **File > New > Application Project** and then expand Xilinx and select *Hardware Platform Specification* and click **Next**.
- **1-5-2.** Enter **hello_world** in the *Project name* field, select **Use existing BSP** (with standalone_bsp_0 selected) and click **Next**.






Figure 10. Creating hello world application to generate the linker script

- **1-5-3.** Select **Hello World** from the *Available Templates* pane, and click **Finish**.
- **1-5-4.** Click **Yes** to open the *C/C++ perspective*.
- **1-5-5.** Expand the *src* folder under the **hello_world** project in the Project Explorer pan, and double-click on the **lscript.ld** entry.

Notice that the Stack and Heap sizes are assigned 0x2000 by default. Depending on your application, you may need more *Heap* space if the application is going to transfer a large amount of data using sds_alloc.

1-5-6. Change the *Heap size* to **0x4000** and then press *Ctl+S* to save the changes.



- 1-6. Generate the FSBL application so the board can be boot from the SD card.
- **1-6-1.** Select **File > New > Application Project** and then expand Xilinx and select *Hardware Platform Specification* and click Next.
- **1-6-2.** Enter **fsbl** in the *Project name* field.
- 1-6-3. For the Board Support Package, select Create New and click Next.
- **1-6-4.** Select **Zyng FSBL** from the *Available Templates* pane, and click **Finish**.
- **1-6-5.** Right-click on the *fsbl_bsp* entry and select **build project.**
- **1-6-6.** Right-click on the *fsbl* entry and select **build project.**

The fsbl.elf file is required to create a bootable SD image.

1-6-7. Using the Windows Explorer, copy the following files and directories to c:\uniterror c:\uniterror vilinx-eabi or c:\uniterror c:\uniterror c:\uniterror vilinx-eabi or c:\uniterror c:\uniterro

The **system.mss** file and the **include** directory from c:\xup\SDSoC\labs\lab7\zed_audio\vivado\zed_audio.sdk\standalone_bsp_0\

OR

c:\xup\SDSoC\labs\lab7\zybo_audio\vivado\zybo_audio.sdk\standalone_bsp_0\

The linker.ld file from

c:\xup\SDSoC\labs\lab7\zed_audio\vivado\zed_audio.sdk\hello_world\src

OR

c:\xup\SDSoC\labs\lab7\zybo_audio\vivado\zybo_audio.sdk\hello_world\src

Copy the **fsbl.elf** file from c:\xup\SDSoC\labs\lab7\zed_audio\vivado\zed_audio.sdk\fsbl\Debug into c:\xup\SDSoC\labs\lab7\zed_audio\boot.

OR

The **fsbl.elf** file from c:\xup\SDSoC\labs\lab7\zybo_audio\vivado\zybo_audio.sdk\fsbl\Debug into c:\xup\SDSoC\labs\lab7\zybo_audio\boot.

Test the Built Platform

Step 2

- 2-1. In SDSoC change the workspace to c:\xup\SDSoC\labs\lab7. Create a new SDSoC project called *audio_test* using zed_audio or zybo_audio as the platform and Standalone as the OS, and selecting Audio Playback template provided in the *samples* directory.
- **2-1-1.** In SDSoC change the workspace to *c:\xup\SDSoC\labs\lab7* by selecting **File > Switch Workspace > other**.



- 2-1-2. Click OK.
- 2-1-3. Click on the Create SDSoC Project in the Welcome tab or select File > New > SDSoC Project
- **2-1-4.** Enter **audio_test** in the *Project name* field
- **2-1-5.** For the *Platform*, click on the **Other**... button, browse to *c:\xup\SDSoC\labs\lab7* and select either **zed_audio** or **zybo_audio**.
- **2-1-6.** For the OS, select **Standalone**.




Figure 11. Creating an SDSoC project to test the platform

2-1-7. Click Next.

The Templates window will be displayed with Audio Playback as one of the two possible templates. This entry is picked up from the samples directory of the created platform.






Figure 12. Selecting a test template

- **2-1-8.** Select the *Audio Playback* application and click **Finish**.
- 2-1-9. Expand the audio_test entry in the Project Explorer pane and note the two source files (audio.h and audio.c) make up the application.




Figure 13. Test application directory

The audio.c application configures the CODEC, samples the CODEC and writes back into the CODEC illustrating the platform does function.

- **2-1-10.** Right-click on the *audio_test* entry and select **Build Project**.
- 2-2. Connect the board and test the application.
- 2-2-1. Connect an audio patch cable between the PC's headphone output and Line-In connector of the board.
- 2-2-2. Connect a headphone to the Line Out connector (on Zed) or HPH OUT connector (on Zybo) of the board.



- **2-2-3.** Connect the board and power it ON.
- **2-2-4.** Right-click on the *audio_test* folder and select **Run As > Launch on Hardware (SDDebug)** to run the application.
 - This will download the bit file to configure the FPGA, download the *audio_test.elf* application, and run the application.
- **2-2-5.** Play some music on the PC and you should be able to hear the same on your headphone.
- **2-2-6.** When satisfied, power OFF the board.

Test the Platform for the Filter Application

Step 3

- 3-1. Create an fir_test application targeting the custom platform and Standalone OS. Import the provided audio.h, audio.c, and fir_test.c files from the c:\xup\SDSoC\source\lab7 folder.
- 3-1-1. Select File > New > SDSoC Project
- **3-1-2.** Enter **fir_test** as the project name and click on the *Other...* button of the *Target Platform*.
- **3-1-3.** Browse to either c:\xup\SDSoC\labs\lab7\zed_audio or c:\xup\SDSoC\labs\lab7\zybo_audio and click **OK**.
- **3-1-4.** Select **Standalone** as the *Target OS* and click **Next**.
- **3-1-5.** Select *Empty Application* template and click **Finish**.
- **3-1-6.** Expand **fir_test > src**, right-click on the *src* folder and select **Import**...
- 3-1-7. Expand General, select File System and click Next
- **3-1-8.** Browse to *c:\xup\SDSoC\source\lab7*, and import **audio.c**, **audio.h**, **fir_coef.dat** and **fir_test.c** files
- **3-1-9.** Add the **fir** function in the *Hardware Function* panel.
- **3-1-10.** Right-click on the **fir_test** entry in the *Project Explorer* panel, and select **Build Project**.
 - This will take about 15 minutes.
- **3-1-11.** When the build is complete, using the Windows Explorer, copy the **BOOT.BIN** file from *c:\xup\SDSoC\labs\lab7\fir_test\SDDebug\sd_card* into the SD card.
- 3-2. Configure the board for the SD card boot and connect the board. Test the application.



- **3-2-1.** Place the SD card into the board and configure the board for the SD card boot.
- **3-2-2.** Connect an audio patch cable between the PC's headphone output and Line-In connector of the board.
- **3-2-3.** Connect headphones to the Line Out connector (on Zed) or HPH OUT connector (on Zybo) of the board.
- **3-2-4.** Connect the board and power it ON.
- **3-2-5.** Open a terminal window and press *PS_SRST* button on the board.

You should see the impulse response in the terminal window.

- **3-2-6.** Play some music on the PC and you should be able to hear the same on your headphones.
- **3-2-7.** When satisfied, turn OFF the board and exit the SDSoC program.

Conclusion

In this lab, you created a custom platform utilizing an audio CODEC IP in the base design. You then created a test application using the provided test template to test the custom platform. You then created a user application, importing the provided source files, targeted a *fir* function in hardware and then tested the application.

