T68-PR v1.0 & T68-PR v2.0

Number	Name	Description	Number	Name	Description
1	P24V	External +24V Power	35	X_N24V	External Power GND
2	PULS+	Pulse Output Signal (422+)	36	X_PULS-	Pulse Output Signal (422-)
3	DIR+	DIR Output Signal (422+)	37	X_DIR-	DIR Output Signal (422-)
4	SVON	Servo Drive ON Signal	38	X_INPO	Servo Inposition Signal
5	ALM	Servo Alarm Signal	39	X_ALMC	Servo Alarm Clear Signal
6	LGND	Logic GND	40	X_CLR	Servo Residual Pulse Removal Signal
7	ECA+	Encoder A-Phase Input (422+)	41	X_ECA-	Encoder A-Phase Input (422+)
8	ECB+	Encoder B-Phase Input (422+)	42	X_ECB-	Encoder B-Phase Input (422+)
9	ECZ+	Encoder Z-Phase Input (422+)	43	X_ECZ-	Encoder Z-Phase Input (422+)
10	IN2	Universal Input Pin 2	44	X_OUT2	Universal Output Pin 2
11	IN3	Universal Input Pin 3	45	X_OUT3	Universal Output Pin 3
12	IN4	Universal Input Pin 4	46	X_OUT4	Universal Output Pin 4
13	IN5	Universal Input Pin 5	47	X_OUT5	Universal Output Pin 5
14	X_EXPP	MPG EXPP(-) Input	48	X_EXMP	MPG EXMP(+) Input
15	X_MPG-	MPG EXMP/EXPP(-)	49	X_+ELM	Forward Limit Location Emergency Stop
16	NELM	Backward Limit Location Emergency Stop	50	X_ORG	Original Sensor Signal (Universal Input 0)
17	EMGN	External Operation Cutoff (Emergency Stop)	51	X_TRIG	Trigger Generation at the Special Location
18	Y_P24V	External +24V Power	52	Y_N24V	External Power GND
19	Y_PULS+	Pulse Output Signal (422+)	53	Y_PULS-	Pulse Output Signal (422-)
20	Y_DIR+	DIR Output Signal (422+)	54	Y_DIR-	DIR Output Signal (422-)
21	Y_SVON	Servo Drive ON Signal	55	Y_INPO	Servo Inposition Signal
22	Y_ALM	Servo Alarm Signal	56	Y_ALMC	Servo Alarm Clear Signal
23	LGND	Logic GND	57	Y_CLR	Servo Residual Pulse Removal Signal
24	Y_ECA+	Encoder A-Phase Input (422+)	58	Y_ECA-	Encoder A-Phase Input (422+)
25	Y_ECB+	Encoder B-Phase Input (422+)	59	Y_ECB-	Encoder B-Phase Input (422+)
26	Y_ECZ+	Encoder Z-Phase Input (422+)	60	Y_ECZ-	Encoder Z-Phase Input (422+)
27	Y_IN2	Universal Input Pin 2	61	Y_OUT2	Universal Output Pin 2
28	Y_IN3	Universal Input Pin 3	62	Y_OUT3	Universal Output Pin 3
29	Y_IN4	Universal Input Pin 4	63	Y_OUT4	Universal Output Pin 4
30	Y_IN5	Universal Input Pin 5	64	Y_OUT5	Universal Output Pin 5
31	Y_EXPP	MPG EXPP(-) Input	65	Y_EXMP	MPG EXMP(+) Input
32	Y_MPG-	MPG EXMP/EXPP(-)	66	Y_+ELM	Forward Limit Location Emergency Stop
33	Y_-ELM	Backward Limit Location Emergency Stop	67	Y_ORG	Original Sensor Signal (Universal Input 0)
34	Y_STOP	External Operation Cutoff (Emergency Stop)	68	Y_TRIG	Trigger Generation at the Special Location