amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	BUILDING, WASTE MACERATOR PUMPS - 5
APM Object	BLDG.MCRTRPMP
APM EC	AMZ.BLDG.MCRTR.PMP
BBM Handbook Title	Waste Macerator Pumps
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Jun-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	YES	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	YES	**Pricing template Position:**	5	**Related CT Areas:**	CT.SEWAGE.SEWAGEPUMP			**Assets included in this PM:**	WASTE MACERATOR PUMP	**Schedule With:**	-		

Description of System / Technology (According to BBM Handbook)

Waste Macerator Pumps

A Waste Macerator pump converts waste solids and fluids into a fine slurry that is discharged under pressure through small diameter pipe and is expelled into the sewage line or septic tank.

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note - The drainage system to be checked within this maintenance is the pressure pipe system.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Guideline	Inspect for signs of clogging				PM		PM				
2	Documentation	Is the documentation of installed equipment available & complete						PM				
4	Safety	Are disconnecting devices lockable in the safe position (LOTO)						PM				
5	Safety	Test all safety relevant switches						PM				
6	Pump & panel	Measure power consumption of the pumps and compare to design						PM				
7	Pump & panel	Are all cables properly routed						PM				
8	Pump & panel	Are all cables, terminal blocks & devices properly labeled or marked						PM				
9	Pump & panel	Are all metal parts of the unit connected to the protection earth (ground)						PM				
10	Pump & panel	Were any obvious changes made (e.g. rewiring, hanging cables)						PM				
11	Pump & panel	Visual check of cable connections such as pinched insulation in the contact area						PM				
12	Pump & panel	Visual check for the protection against direct contact with live parts						PM				
13	Pump & panel	Ensure all cable connections are correctly torqued according to manufacturers specification						PM				
14	Macerator pump unit	Check pumps, pipes, chambers and attachments for damage, corrosion, correct suspension & leakages				PM		PM				
15	Macerator pump unit	Check the pumps for unusual noise & vibration (bearing and impeller)				PM		PM				
16	Macerator pump unit	Check if the unit is functioning correctly				PM		PM				
17	Macerator pump unit	Check condition of filters and schedule an exchange if required (if applicable)				PM		PM				
18	Macerator pump unit	Check if the level switch is functioning correctly and triggers start of the pump						PM				
19	Macerator pump unit	If more than 1 pump installed, check duty and standby arrangement is functional				PM		PM				
20	Macerator pump unit	Clean the container (inside & outside)						PM				
21	Macerator pump unit	Check for damage &corrosion						PM				
22	Macerator pump unit	Remove Pump and Clean inlet / impeller						PM				
23	Macerator pump unit	Check oil level of oil chamber (if oil chamber is installed)						PM				
24	Macerator pump unit	Clean and check function of backflow prevention						PM				
25	Drainage pipe system	Are the pipes on the pressure site installed correctly, free from damage and are the suspensions ok						PM				
26	Valves	Check correct function of all manual & automatic valves						PM				
27	Valves	Check valves for corrosion, dirt deposits and leakages						PM				
28	Final Check	Check the O&M manual and carry out additional required tasks						PM				

Change Log

July 2023 - First issue in new format. Simplification of task scope, alignment with CT.
June 2024 - Removed 24M because it has the same tasks that 12M.Removed task regarding CE certification.