amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	BUILDING, SMART ROOF MONITORING SYSTEM - 7
APM Object	BLDG.SRMS
APM EC	AMZ.BLDG.SRMS
BBM Handbook Title	Smart roof monitoring system
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Sep-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	/	**Delivered By:**	**OCB:** BBM
Evidence for CT:	YES	**Pricing template Position:**	7	**Related CT Areas:**	CT.FAC.ROOFTOPINSPECT	**Assets included in this PM:**	SMART ROOF MONITORING SYSTEM	**Schedule With:**	NO INFO		

Description of System / Technology (According to BBM Handbook)

NO INFO

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Base Station	Check orientation of solar panel (must be south)						PM	PM			
2	Base Station	Check weighting platform for damage and remove any dirt (e.g. leaves, bird droppings, etc.) Do not use any chemicals						PM	PM			
3	Base Station	On main Base Station, the wind sensor must be checked for free rotation					PM	PM	PM			
4	Base Station	On main Base Station, remove the sieve and clean at the precipitation sensor					PM	PM	PM			
5	Base Station	Replace Battery with a fully charged one, charge and store the replaced battery							PM			
6	Water Sensor	The measuring rods should be cleaned of dirt with a damp towel. Caution: Do not use any chemical cleaning aids					PM	PM	PM			
7	Water Sensor	Check the vertical alignment of the antenna and the positioning of the weight block.					PM	PM	PM			
8	Water Sensor	Replace Battery with a fully charged one, charge and store the replaced battery						PM	PM			
9	Snow Sensor	Check weighting platform for damage and remove any dirt (e.g. leaves, bird droppings, etc.) Do not use any chemicals					PM	PM	PM			
10	Snow Sensor	Check the vertical alignment of the antenna and the positioning of the weight block.						PM	PM			
11	Snow Sensor	Replace Battery with a fully charged one, charge and store the replaced battery						PM	PM			

Change Log

Error - Entry for specified object not found on change log