amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	LIFTS, PASSENGER LIFTS - 6
APM Object	LIFTS.PASSENGER
APM EC	AMZ.LIFTS.PASS
BBM Handbook Title	Passenger Lifts
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Jun-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	YES	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	Yes	**Pricing template Position:**	6	**Related CT Areas:**	CT.LIFT.PASSENGER			**Assets included in this PM:**	PASSENGER LIFT	**Schedule With:**	-		

Description of System / Technology (According to BBM Handbook)

A passenger lift is a type of lift that is designed to take passengers up and down a vertical lift shaft. The lift cab, emergency communication and lighting are also included.

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note: This PM includes Rope hoist & hydraulic hoists (elevators/lifts)

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Alarms	Are there any alarms indicated -> if yes identify & eliminate the root cause or create a WO			PM			PM				
2	Documentation	Are the circuit diagrams and relevant technical documentation available and complete			PM			PM				
3	Documentation	Are there manual entries in the drawings or technical documentation that indicate changes to the installation			PM			PM				
5	Safety	Are disconnecting devices lockable in the safe position (LOTO)			PM			PM				
6	Safety	Are safety markings, notices and pictograms present and legible			PM			PM				
7	Safety	Are all doors to the machinery & shaft rooms locked			PM			PM				
8	Safety	Are emergency release opening accessible on all landing doors			PM			PM				
9	Safety	Doors open again when the light barrier is interrupted			PM			PM				
10	Safety	Emergency call device is functioning correctly			PM			PM				
11	Safety	Is appropriate firefighting equipment available & free from damage						PM				
12	Safety	Check correct function of all other safety related switches/ measures like overload stop, etc.			PM			PM				
13	Control	The level selection buttons are free from damage and functioning correctly			PM			PM				
14	Doors	Doors are moving without unusual noise			PM			PM				
15	Doors	Door tracks are free from damage and clean -> clean if required			PM			PM				
16	Doors	Door leaves are free from damage & corrosion			PM			PM				
17	Doors	Doors can`t be opened before car reached end position of a level			PM			PM				
18	Doors	Door stop switch/reverse switch is functioning correctly			PM			PM				
19	Elevator car	The car floor is on the same level as the floor of the building (check each level)			PM			PM				
20	Elevator car	Is the light inside the car & in front of the elevator at each level sufficient & free from damage			PM			PM				
21	Elevator car	All surfaces are free from damage and corrosion (walls, ceiling & floor)			PM			PM				
22	Elevator car	Handrail, ramp protection, etc. are correctly fixed & free from damage			PM			PM				
23	Elevator car	Are there any unusual noises, vibrations or movements when elevator is operating			PM			PM				
24	Engine room & machinery shaft	Are the rooms freely accessible						PM				
25	Engine room & machinery shaft	Is the light inside the rooms & around technical components sufficient & free from damage						PM				
26	Engine room & machinery shaft	Remove all unnecessary flammable goods out of the rooms						PM				
27	Engine room & machinery shaft	Are components damaged or loose (e.g. cable trays, MCP, fire extinguisher)						PM				
28	Engine room & machinery shaft	Is the emergency release key/tool available						PM				
29	Engine room & machinery shaft	Is the ventilation in the rooms sufficient (humidity & temperature)						PM				
30	Engine room & machinery shaft	Are there any leakages on hydraulic systems						PM				
31	Engine room & machinery shaft	Are there any visible damage at the hoist						PM				
32	Engine room & machinery shaft	Is the brake functioning properly						PM				
33	Engine room & machinery shaft	Grease all greasing points to maintain a reliable function						PM				
34	Engine room & machinery shaft	Test the hydraulic oil and schedule an exchange if required						PM				
35	Electrical components	Is the air filter of the electrical panel/cabinet clean and the cooling fan functioning correctly. Please clean or change if necessary						PM				
36	Electrical components	Are all cables properly routed						PM				

37	Electrical components	Are all metal parts connected to the protection earth (ground)						PM					
38	Electrical components	Is the ground connection to the building ground as designed?						PM					
39	Electrical components	Did any circuit breaker trip -> if yes identify the root cause						PM					
40	Measurement	Measure the electrical current flow of hoist & hydraulic motor						PM					
41	Measurement	Compare to manufacturer specifications						PM					
42	Measurement	Please add the running hours into the notes						PM					
43	Thermographic scan	Perform thermographic scans & create a WO for over-temperature to determine the root cause immediately						PM					
44	Thermographic scan value	Add a detailed note for all over-temperature measurements -> list the location and temperature -> Upload the thermographic scan						PM					
45	Functional cleaning	Carry out a functional cleaning of all components						PM					
46	Final Check	Check the O&M manual and carry out additional required tasks						PM					

Change Log

July 2023 - First issue in new format. Simplification of task scope, alignment with CT.
June 2024 - Changed the APM description as shows the BBM Handbook.Removed task regarding CE certification.