amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	BUILDING WATER SUPPLY - 5
APM Object	WTR.SUPPLY
APM EC	AMZ.WS
BBM Handbook Title	Water System
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Jun-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	YES	**Pricing template Position:**	5	**Related CT Areas:**	CT.WATER.LEGIONELLA CT.WATER.COLDSERVICE CT.WATER.HOTSERVICE CT.WATER.LEAD CT.WATER.BACKFLOW	**Assets included in this PM:**	WATER SUPPLY PUMPS - COLD WATER SUPPLY TANK UNIT - WATER SUPPLY VALVES	**Schedule With:**	-		

Description of System / Technology (According to BBM Handbook)

Water System

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note: The tasks for pumps in this PM is designated to the water supply pumps (booster pumps)

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Documentation	Is the documentation of the equipment available and complete						PM				
2	Safety	Test all safety relevant switches						PM				
3	Safety	Are disconnecting devices lockable in the safe position (LOTO)						PM				
4	Attachments	Check if all components are properly fixed						PM				
5	Pumps & panel	Is there any damage or leakages at the pipes, insulation or pumps						PM				
6	Pumps & panel	Are there any unusual noises of the running pump						PM				
7	Pumps & panel	Measure power consumption of the pumps and compare to design						PM				
8	Pumps & panel	Are all cables properly routed						PM				
9	Pumps & panel	Are all cables, terminal blocks & devices properly labeled or marked						PM				
10	Pumps & panel	Are all metal parts of the unit connected to the protection earth (ground)						PM				
11	Pumps & panel	Were any obvious changes made (e.g. rewiring, hanging cables)						PM				
12	Pumps & panel	Visual check of cable connections such as pinched insulation in the contact area						PM				
13	Pumps & panel	Visual check for the protection against direct contact with live parts						PM				
14	Pumps & panel	Ensure all cable connections are correctly torqued according to manufacturers specification						PM				
15	Water filter	Backwash filter, if possible					PM	PM				
16	Water filter	Change filter inlet, if possible					PM	PM				
17	Water filter	In case of automatic filter backwash function, check for correct functionality						PM				
18	Softener unit	Check salt tablet level & top up salt tablets if necessary			SC			PM				
19	Softener unit	Measure the water hardness and adjust if necessary						PM				
20	Cold water tanks	Check if cold water tanks are free from damage			SC			PM				
21	Dosing & Chlorination Unit	Measure the water chlorine content in the water and adjust if necessary			SC			PM				
22	Valves & backflow preventer	Close the nearest supply valve in flow direction before the backflow preventer						PM				
23	Valves & backflow preventer	Open the maintenance opening on the supply site and release the water						PM				
24	Valves & backflow preventer	Check if there is not water flowing back from the building pipes						PM				
25	Valves & backflow preventer	If the water flow doesn`t stop means that the bp is defect and needs to be changed						PM				
26	Valves & backflow preventer	Close the maintenance opening & open the supply valve						PM				
27	Valves & backflow preventer	If there are no pressure gauges close to the bp, open the maintenance opening on the building site and check if the bp ensures a water flow into the building						PM				
28	Valves & backflow preventer	Check all water supply valves for correct functionalty & leakages						PM				
29	Final Check	Check the O&M manual of all installed components and carry out additional required tasks						PM				

Change Log

July 2023 - First issue in new format. Simplification of task scope, alignment with CT.
June 2024 - Merged the tasks from WTR.SUPPLY.VALV.BFP, Removed task regarding CE certification.