amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	BUILDING, OIL SEPARATOR - 5
APM Object	BLDG.OILSEP
APM EC	AMZ.BLDG.OILSEP.GRP
BBM Handbook Title	Oil Separator (Waste water containing oil / gasoline)
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Jun-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	YES	**Pricing template Position:**	5	**Related CT Areas:**	CT.ENVIRO.INTERCEPTOR			**Assets included in this PM:**	OIL SEPARATOR	**Schedule With:**	BLDG.GREASESEP		

Description of System / Technology (According to BBM Handbook)

Oil Separator (Waste water containing oil / gasoline)

Oil separators are designed to prevent oil and other hydrocarbons from entering the drainage system. They separate oil from water, and safely retain the oil until it is removed. Oil cannot be treated easily and will therefore cause severe pollution if allowed to enter mains sewers or drainage fields. Statutory controls enforce strict regulations on the discharge of such pollutants. Oil separators should be used in such applications as petrol stations, industrial yards and garages; or virtually anywhere that a risk of oil contamination exists. Discharge requirements for oil separators may vary by region.

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note - The drainage system to be checked within this maintenance is the pressure pipe system.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Guideline	If there are signs of clogging, schedule a CCTV inspection asap					PM	PM				
2	Documentation	Is the documentation of installed BBA available & complete						PM				
4	Safety	Are disconnecting devices lockable in the safe position (LOTO)					PM	PM				
5	Safety	Test all safety relevant switches						PM				
6	Separator unit	Check pumps, pipes, chambers and attachments for damage, corrosion, correct suspension & leakage					PM	PM				
7	Separator unit	Measurement of the layer thickness of the light liquids in the separator					PM	PM				
8	Separator unit	Schedule an emptying & cleaning if required as FWO (Waste Transfer Note must be provided)			SC		PM	PM				
9	Separator unit	Measure the sludge level					PM	PM				
10	Separator unit	Visual inspection of the water level before & after the coalescence separator (if installed)					PM	PM				
11	Separator unit	Check for any signs of leakage			SC		PM	PM				
12	Separator unit	Check the correct function of the coalescing device (if installed)					PM	PM				
13	Separator unit	Empty & clean the unit (inside & outside)					PM	PM				
14	Separator unit	Check for damage & corrosion						PM				
15	Separator unit	Clean and check function of backflow prevention						PM				
16	Separator unit	Check unit correct function if applicable					PM	PM				
17	Pump & panel	Check whether an alarm is displayed			SC			PM				
18	Pump & panel	If more than 1 pump installed, check if pumps starts one after the other						PM				
19	Pump & panel	Check the pumps for unusual noise & vibration (bearing and impeller)						PM				
20	Pump & panel	Measure power consumption of the pumps and compare to design						PM				
21	Pump & panel	Are all cables properly routed						PM				
22	Pump & panel	Are all cables, terminal blocks & devices properly labeled or marked						PM				
23	Pump & panel	Are all metal parts of the unit connected to the protection earth (ground)						PM				
24	Pump & panel	Were any obvious changes made (e.g. rewiring, hanging cables)						PM				
25	Pump & panel	Visual check of cable connections such as pinched insulation in the contact area						PM				
26	Pump & panel	Visual check for the protection against direct contact with live parts						PM				
27	Pump & panel	Ensure all cable connections are correctly torqued according to manufacturers specification						PM				
28	Drainage pipe system	Are the pipes on the pressure site installed correctly, free from damage and are the suspensions ok						PM				
29	Valves	Check correct function of all manual & automatic valves						PM				
30	Valves	Check valves for corrosion, dirt deposits and leakage						PM				
31	Final Check	Check the O&M manual and carry out additional required tasks						PM				

Change Log

July 2023 - First issue in new format. Simplification of task scope, alignment with CT.
June 2024 - Changed the APM description as shows the BBM Handbook.Removed task regarding CE certification.