amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	BUILDING, SEWAGE SYSTEM, SEWAGE WATER PUMPS - 5
APM Object	BLDG.SEWAGE.WTRPMP
APM EC	AMZ.BLDG.SEWAGE.PMP
BBM Handbook Title	Sewage Water Pumps (including pressure pipe system)
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Jun-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	TBC	**Pricing template Position:**	5	**Related CT Areas:**	CT.SEWAGE.SEWAGEPUMP			**Assets included in this PM:**	SEWAGE WATER PUMP	**Schedule With:**	-		

Description of System / Technology (According to BBM Handbook)

Sewage Water Pumps (including pressure pipe)

A sewage pump (also known as an ejector pump) has a tank that collects sewage. When the waste reaches a certain level, the pump turns on and pushes the waste into a sewer system or septic tank.

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note - The drainage system to be checked within this maintenance is the pressure pipe system.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	Guideline	Inspect for signs of clogging						PM	PM			
2	General	Is the documentation of installed BBA available & complete						PM	PM			
3	Panel & Electrical components	Check wether an alarm is displayed			SC			PM	PM			
4	Panel & Electrical components	Measure power consumption of the pumps and compare to design						PM	PM			
5	Panel & Electrical components	Are all cables properly routed						PM	PM			
6	Panel & Electrical components	Are all cables, terminal blocks & devices properly labeled or marked						PM	PM			
7	Panel & Electrical components	Are all metal parts of the unit connected to the protection earth (ground)						PM	PM			
8	Panel & Electrical components	Were any obvious changes made (e.g. rewiring, hanging cables)						PM	PM			
9	Panel & Electrical components	Visual check of cable connections such as pinched insulation in the contact area						PM	PM			
10	Panel & Electrical components	Visual check for the protection against direct contact with live parts						PM	PM			
11	Panel & Electrical components	Ensure all cable connections are correctly torqued according to manufacturers specification						PM	PM			
12	Panel & Electrical components	Test all safety relevant switches						PM	PM			
13	Sewage lifting unit	Check the for signs of leaks			SC			PM	PM			
14	Sewage lifting unit	Check the pump for unusual noises or vibrations.			SC			PM	PM			
15	Sewage lifting unit	Check pumps, pipes, chambers and attachments for damage, corrosion, suspension & leaks						PM	PM			
16	Sewage lifting unit	Check the pumps for unusual noise & vibration (bearing and impeller)						PM	PM			
17	Sewage lifting unit	Check if the unit is functioning correctly						PM	PM			
18	Sewage lifting unit	Check condition of filters and schedule an exchange if required (if applicable)						PM	PM			
19	Sewage lifting unit	Check if the level switch is functioning correctly and triggers start of the pump						PM	PM			
20	Sewage lifting unit	Clean the inside of the container and check for corrosion						PM	PM			
21	Sewage lifting unit	Clean and check function of backflow prevention						PM	PM			
22	Sewage lifting unit	Check oil level of oil chamber (if oil chamber is installed)						PM	PM			
23	Sewage lifting unit	If more than 1 pump installed, check if pumps starts one after the other						PM	PM			
24	Sewage lifting unit	Clean Level Switch						PM	PM			
25	Sewage lifting unit	Remove Pump and Clean inlet / impeller							PM			
26	Pump gasket	Tighten the gland if applicable (gasket DE Stoffbuchse)						PM	PM			
27	Drainage pipe system	Are the pipes on the pressure site installed correctly, free from damage and are the suspensions ok						PM	PM			
28	Valves	Check correct function of all manual & automatic valves						PM	PM			
29	Valves	Check valves for corrosion, dirt deposits and leaks						PM	PM			
30	Manual pump	Check correct function of the manual water pump						PM	PM			
31	Pit	Check overflow alarm switch of the pit for correct function (if applicable)						PM	PM			
32	Final Check	Check the O&M manual and carry out additional required tasks						PM	PM			

Change Log

July 2023 - First issue in new format. Simplification of task scope, aligmment with CT.
June 2024 - Changed the APM description as shows the BBM Handbook.