

1 Scope

This procedure applies to work at height.

1.1 Guardrails

Install guardrails before work begins.

Check | Owner | Frequency

Guardrail | Supervisor | Daily

2 Permit to work

The supervisor checks the permit before access.

2.1 Stop work

Stop work when fall protection is missing.