

NOTES:

Do not install J1 (DB-9) if you intend to mount a controller to the card. (your card wont fit) Only install J1 if you intend to run an external controller from this jack.

You must install jumpers to enable J1 or J2 Use 22 awg hookup wire to connect the signals as desired for your intended use.


The signals required for a repeater are noted on this drawing and wired for convenient access. All other signals are brought out to a test point for user access. Consult the GE-MASTR II Station Manual to identify these signals.

Insert card into far right hand "AUX CONTROL" slot J1212 for repeater control applications.

Holes in a grid pattern are provided for the customers convenience.

Cards that have been soldered are not returnable.

CARD EDGE FINGERS



Consult the GE MASTR-II Station Manual for signals not listed.

NOTICE


THIS DRAWING CONTAINS PROPRIETARY INFORMATION WHICH IS THE CONFIDENTIAL PROPERTY OF NHRO LLC. IT SHALL NOT BE COPIED, REPRODUCED, DISCLOSED, PUBLISHED OR USED IN PART OR WHOLE WITHOUT THE EXPRESSED WRITTEN PERMISSION OF NHRO LLC. SPECIFICATIONS SUBJECT TO CHANGE WITHOUT TOTICE OR OBLIGATION.


PLEASE READ ALL NOTES BEFORE BUILDING OR USING THIS KIT.

Wednesday, October 20, 2010


ev C

HI-PASS CTCSS FILTER





Controller Mounting Holes



NOTICE

THIS DRAWING CONTAINS PROPRIETARY INFORMATION WHICH IS THE CONFIDENTIAL PROPERTY OF NIRC LLC. IT SHALL NOT BE COPIED. REPRODUCED. DISCLOSED, PUBLISHED OR USED IN PART OR WHOLE WITHOUT THE EXPRESSED WRITTEN PERMISSION OF NIRC LLC. SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE OR OBLIGATION.

PLEASE READ ALL NOTES BEFORE BUILDING OR USING THIS KIT.

NHRC REPEATER CONTROLLERS 415 Fourth Range Road Pembroke, NH 03275 603-485-2248 http://www.nhrc.net Title NHRC-M2SC (GE MASTR II Station Card)