
Print <u>Exit</u>

6AR-FSE INTAKE / EXHAUST INTAKE SYSTEM GENERAL PARTS LOCATION



*1	Intake Air Resonator	*2	Air Cleaner Assembly
*3	Mass Air Flow Meter Sub-assembly	*4	Air Cleaner Hose Assembly Intake Air Resonator
*5	Throttle Body with Motor Assembly	*6	Intake Manifold

 $\ensuremath{\text{@}}$ 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.

1 of 1 4/6/2021, 4:40 PM