
Print <u>Exit</u>

6AR-FSE ENGINE CONTROL SFI SYSTEM DETAILS IGNITION COIL

CONSTRUCTION

a. The Direct Ignition System (DIS) provides 4 ignition coil assemblies, 1 for each cylinder. The spark plug caps, which provide contact to the spark plugs, are integrated with the ignition coil assembly. Also, an igniter is enclosed to simplify the system.



*1	Ignition Coil Assembly	-	-
*a	Igniter	*b	Iron Core
*c	Plug Cap	*d	Secondary Coil
*e	Primary Coil	-	-

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.

1 of 1 3/30/2021, 1:26 PM