Print Exit

6AR-FSE ENGINE CONTROL SFI SYSTEM CONTROL FUEL PUMP CONTROL (FOR HIGH-PRESSURE PUMP)

FUNCTION

a. The ECM performs variable control to achieve the high pressure fuel pressure in accordance with the driving conditions. A system that only discharges the necessary fuel amount via the spill control valve control has achieved drive torque reduction and reduced noise.

Control Pressure for Each Driving Condition

Condition	Control Pressure
Idling	4.0 to 8.0 MPa
Except Idling	2.75 to 20 MPa

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.

1 of 1 3/30/2021, 1:20 PM