EE 401 LabReports Sept. 18 Steps: 1. Unscrew screw holding side panel 2. Remove side panel 3. Lay on side to look down at motherboard 4. remove cables from hard drives 5. Unscrew and remove hard ridles 6. unplag all wires affached to motherboard t, remove cards from PCI/E slots 6. Unscrew screws holding power supply inplace 9. remove cables from (D drives 10. remove power supply 11. remove all SATA connectors 12. Unscrew screws holding fan in place 13, remove fan 14. Whilip and remove Ram sticks 15, twist and pull each of the 4 posts holding
Cpu fan and hedtsenk

16, remove cpu fan 17. unclip and remove cpu 18. remove heatsink covering northbridge 1a, unscrew and remove motherboard from case 2. unscreward remove Cont panel

22, unscrew and remove random periforals on exterior 23, slide off top panel 24, Slide off front panel 25. remonse power switch 24, unscrew and remove T6 screws on bottom of of hard drives 27. remove visible curcuit, board on hard drive 28, unscrew and remove T8 screws on to Pot hardon 29. remove top cover of hard drive 36, un screw and remove WLAN chip 31. unscrew and remove GPU heaf sink 32. Unscrew and remove CD drive base 33. Unclip, detach ribbons, and remove large curcuit board