RFID Reader


USER GUIDE

Nicholas Chow, Calvin Lai

RFID Reader User Guide

Installation

- 1. Open Visual Studio 2017, create an empty project and place all header and cpp files into project.
- 2. Left Click on project directory and go to properties.
- 3. Under C++, go to General and click on additional include directories.
- 4. Find the path of the **stapi** folder which includes Skyetek's API files, copy and paste the path.



- 5. Open Linker, find additional include directories, repeat step 4.
- 6. Under Linker, go to input. Click on additional include directories, this time copy and paste the path of the stapi.lib.
- 7. Download stapi.dll file from website. Place this file into your system32 and syswow64 folder.
- 8. Finally click build solution and run the program.

Program user guide

- 1. Connect the RFID device to your computer.
- 2. Run the program.
- 3. Click on Connection > Start from the menu.
- 4. Several messages will display to show connection of the reader. Once the reader has been detected, it will ask the user to start reading.
- 5. Get a tag and put it close to the reader.
- 6. Notice the window will output the tag code.
- 7. If user wants to stop scanning, simply press disconnect. RFID reader will stop scanning at this point.
- 8. User can terminate the program by pressing EXIT from the menu.