
[L23]Platform 设备驱动与LED类

对于Linux这么庞大的系统来说,他除了包含系统本身,还包含很多各种驱动,如果说驱动要挨个开发也太麻烦了,开发周期太长,所以都现在Linux都是基于Platform进行分离的,我们之前使用了GPIO子系统,那个严格来说还不算Platform但是却像Platform那样.



所以实际上一套环境里是包含platform_device以及platform_driver的,我们单片机开发TFT显示时候也是显示库和打点的底层函数,是同一个道理,而只需要我们的打点函数和显示库匹配,那么就会完成显示了.特别注意,这个驱动分离,是针对内核层面的,对于用户而言是没什么区别的.Linux内核里可以说一切都是和各种框架打交道(除了少数),只要掌握了,可以说Linux内核开发简直是畅通.

在Linux中由platform_device调用platform_driver来完成工作,而platform_device现在是不推荐的,推荐使用设备树的方法,但是对于驱动编写的人来说,最好是两者都实现,不过由于Linux是罗马一样,一步一步起来的,所以我们也先用普通驱动,再用dts驱动,而实际项目中,最好是都实现.

实际干活的platform_driver格式如下:

```
#incClude <linux/module.h>
#include <linux/of_gpio.h>
#include <linux/cdev.h>
#include <linux/uaccess.h>
#include <linux/platform_device.h>
static int led_probe(struct platform_device *pdev)
 /* 当驱动匹配成功,这个函数就会执行,和之前写的驱动的probe没什么区别. */
 return ret;
}
static int led_remove(struct platform_device *dev)
 /* 驱动卸载时候执行,和以前的设备驱动没区别. */
 return 0:
}
/* 设备树匹配列表 */
static const struct of_device_id led_of_match[] = {
  { .compatible = "taterli, led" },
  { /* 占位符 */ }
};
static struct platform_driver led_driver = {
 .driver = {
            = "taterli-led", /* 传统方法匹配,他也可以匹配列表. */
    .name
    .of_match_table = led_of_match, /* 设备树方法匹配 */
  .probe
          = led_probe,
  .remove = led_remove,
static int __init led_driver_init(void)
  return platform_driver_register(&led_driver);
```

```
static void __exit led_driver_exit(void)
{
   platform_driver_unregister(&led_driver);
}

module_init(led_driver_init);
module_exit(led_driver_exit);

MODULE_AUTHOR("Taterli <admin@taterli.com>");
MODULE_DESCRIPTION("LED GPIO");
MODULE_LICENSE("GPL");
```

如何通过传统方式绑定呢,那就要匹配driver中的name了,比如接下来我们要用的led驱动相关的device可以这么写.

```
#include <linux/module.h>
#include <linux/platform_device.h>
#define GPIO_OUTEN_2 0xE000A288
#define GPIO INTDIS 2 0xE000A294
#define APER_CLK_CTRL 0xF800012C
static void led_release(struct device *dev)
static struct resource led_resources[] = {
 [0] = {
   .start = GPIO_DATA_2,
   .end = GPIO_DATA_2 + 3,
   .flags = IORESOURCE_MEM,
 [1] = {
   .start = GPIO_DIRM_2,
   .end = GPIO_DIRM_2 + 3,
   .flags = IORESOURCE_MEM,
 [2] = {
   .start = GPIO_OUTEN_2,
   .end = GPIO_OUTEN_2 + 3,
   .flags = IORESOURCE_MEM,
 [3] = {
   .start = GPIO_INTDIS_2,
   .end = GPIO_INTDIS_2 + 3,
   .flags = IORESOURCE_MEM,
 [4] = {
   .start = APER_CLK_CTRL,
    .end = APER CLK CTRL + 3,
   .flags = IORESOURCE_MEM,
};
static struct platform_device led_device = {
 .name = "taterli-led",
  .id = -1,
  .dev = {
  /* 方法都是可选可选实现的. */
   .release = &led_release,
  .num_resources = ARRAY_SIZE(led_resources),
  .resource = led_resources,
static int __init led_device_init(void)
 return platform_device_register(&led_device);
static void __exit led_device_exit(void)
{
 platform_device_unregister(&led_device);
}
module init(led device init):
```

```
module_exit(led_device_exit);

MODULE_AUTHOR("Taterli <admin@taterli.com>");

MODULE_DESCRIPTION("LED GPIO Device");

MODULE_LICENSE("GPL");
```

如果是设备树就简单一些,熟悉吗,就是之前的LED的dts.

```
led {
   compatible = "taterli,led";
   status = "okay";
   default-state = "on";

   led-gpio = <&gpio0 54 GPIO_ACTIVE_HIGH>;
}
```

让这个框架,套到之前的驱动里,传统不用gpio子系统的方法要这么修改.

- 1. 引入头文件.
- 2. 修改led_init的ioremap,使得地址从device声明中取出.
- 3. 修改module init和module exit方法至platform相关函数.
- 4. 修改原来的init和exit方法的定义和返回.
- 5. 添加platform driver结构体.

```
#include <linux/types.h>
#include <linux/kernel.h>
#include <linux/delay.h>
#include <linux/ide.h>
#include <linux/init.h>
#include <linux/module.h>
#include <linux/errno.h>
#include <linux/gpio.h>
#include <asm/mach/map.h>
#include <asm/uaccess.h>
#include <asm/io.h>
#include <linux/cdev.h>
#include <linux/platform_device.h>
#define KERNEL_LED_DEVIE_CNT 1
#define KERNEL_LED_NAME "kernel_led"
static void __iomem *DATA;
static void __iomem *DIRM;
static void __iomem *OUTEN;
static void __iomem *INTDIS;
static void __iomem *APER;
struct kernel_led_dev
    dev_t devid;
    struct cdev cdev;
    struct class *class;
    struct device *device;
    int major;
    int minor;
};
static struct kernel_led_dev dev;
/* 设备打开时候会被调用 */
static int led_open(struct inode *inode, struct file *filp)
    filp->private_data = &dev;
    return 0;
/* 设备读取时候会被调用 */
static ssize_t led_read(struct file *filp, char __user *buf, size_t cnt, loff_t *offset)
{
```

```
char kbuf[1];
   if (cnt != 1)
       return -EFAULT;
    kbuf[0] = readl(DATA) & EMIO_PIN;
    ret = copy_to_user(buf, kbuf, cnt);
    if (ret)
        /* 复制失败了 */
       return -EFAULT;
   }
   return 0;
}
/* 设备写入时候会被调用 */
static ssize_t led_write(struct file *filp, const char __user *buf, size_t cnt, loff_t *offset)
   int ret;
   int val:
   char kbuf[1];
    if (cnt != 1)
       return -EFAULT;
   ret = copy_from_user(kbuf, buf, cnt);
   if (ret)
    {
       /* 复制失败了 */
       return -EFAULT;
   }
   val = readl(DATA);
    if (kbuf[0] == 0)
       val &= ~EMIO_PIN;
   }
    else
   {
       val |= EMIO_PIN;
   writel(val, DATA);
   return 0;
}
/* 设备释放时候会被调用 */
static int led_release(struct inode *inode, struct file *filp)
{
    return 0:
}
static struct file_operations fops =
       .owner = THIS_MODULE,
       .open = led_open,
       .read = led_read,
       .write = led_write,
       .release = led_release,
};
static int led_init(struct platform_device *mdev)
    int i;
   int val;
   int ret;
   struct resource *res[5];
    for (i = 0; i < 5; i++)
        res[i] = platform_get_resource(mdev, IORESOURCE_MEM, i);
        if (!res[i])
       {
           return -ENXIO;
```

```
}
    /* 寄存器映射 */
    DATA = ioremap(res[0]->start, resource_size(res[0]));
    DIRM = ioremap(res[1]->start, resource_size(res[1]));
    OUTEN = ioremap(res[2]->start, resource_size(res[2]));
    INTDIS = ioremap(res[3]->start, resource_size(res[3]));
   APER = ioremap(res[4]->start, resource_size(res[4]));
    /* 初始化 */
    val = readl(APER);
    val |= GPIO_CLK_EN;
   writel(val, APER);
    val = readl(INTDIS);
    val |= EMIO_PIN;
   writel(val, INTDIS);
   val = readl(DIRM);
    val |= EMIO_PIN;
   writel(val, DIRM);
   val = readl(OUTEN);
    val |= EMIO_PIN;
   writel(val, OUTEN);
   val = readl(DATA);
   val |= EMIO_PIN;
   writel(val, DATA);
    printk("APER reg 0x\%08x\n", readl(APER));\\
    printk("INTDIS reg 0x%08x\n", readl(INTDIS));
    printk("DIRM reg 0x%08x\n", readl(DIRM));
    printk("OUTEN reg 0x%08x\n", readl(OUTEN));
    printk("DATA reg 0x%08x\n", readl(DATA));
    /* 申请一个设备号 */
    \verb|ret = alloc_chrdev_region(&dev.devid, 0, KERNEL_LED_DEVIE_CNT, KERNEL_LED_NAME);|\\
    if (ret)
    {
       goto alloc_fail;
    dev.major = MAJOR(dev.devid);
    dev.minor = MINOR(dev.devid);
    dev.cdev.owner = THIS_MODULE;
    cdev_init(&dev.cdev, &fops);
    ret = cdev_add(&dev.cdev, dev.devid, KERNEL_LED_DEVIE_CNT);
    if (ret)
    {
       goto add_fail;
   }
    dev.class = class_create(THIS_MODULE, KERNEL_LED_NAME);
   if (IS_ERR(dev.class))
        ret = PTR_ERR(dev.class);
        goto class_fail;
    dev.device = device_create(dev.class, NULL, dev.devid, NULL, KERNEL_LED_NAME);
    if (IS_ERR(dev.device))
        ret = PTR_ERR(dev.class);
        goto dev_fail;
   }
    return 0;
dev_fail:
    class_destroy(dev.class);
class_fail:
    cdev_del(&dev.cdev);
   unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
alloc_fail:
/* 寄存器取消映射 */
```

```
iounmap(DATA);
    iounmap(DIRM);
    iounmap(OUTEN);
    iounmap(INTDIS);
    iounmap(APER);
    return ret;
static int led_exit(struct platform_device *mdev)
    device_destroy(dev.class, dev.devid);
    class_destroy(dev.class);
    cdev_del(&dev.cdev);
    unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
   iounmap(DATA);
    iounmap(DIRM);
   iounmap(OUTEN);
    iounmap(INTDIS);
   iounmap(APER);
    return 0;
}
static struct platform_driver led_driver = {
   .driver = {
       .name = "taterli-led",
    .probe = led_init,
    .remove = led_exit,
};
static int __init led_driver_init(void)
    return platform_driver_register(&led_driver);
static void __exit led_driver_exit(void)
    platform_driver_unregister(&led_driver);
module_init(led_driver_init);
module_exit(led_driver_exit);
MODULE_AUTHOR("Taterli <admin@taterli.com>");
MODULE_DESCRIPTION("Led GPIO");
MODULE_LICENSE("GPL");
```

测试就是先加载drvier,再加载device,再运行用户空间测试,相信大家都会了,就不多说了,还不会的就得翻查前面学习,当然实际上模块加载顺序错了也没关系,但是最好还是按照推荐方法.

如果是dts方法,那么怎么修改呢,我们的dts已经用到了gpio子系统,因此我们从那个例子开始改起,与前面例子差不多,唯一区别是换成gpio子系统,多了一个匹配列表,并且不需要再检测status和compatible了,因为匹配代表检测OK,连节点查找都省了,所以他节点也可以随便是其他名字,只要他compatible属性正确就行.

```
#include <linux/types.h>
#include <linux/kernel.h>
#include linux/delav.h>
#include <linux/ide.h>
#include <linux/init.h>
#include <linux/module.h>
#include ux/errno.h>
#include <linux/gpio.h>
#include <asm/mach/map.h>
#include <asm/uaccess.h>
#include <asm/io.h>
#include <linux/cdev.h>
#include <linux/of.h>
                               /* dts操作相关 */
#include <linux/of_address.h> /* dts地址相关 */
#include <linux/of_gpio.h> /* gpio子系统相关 */
#include <linux/platform_device.h>
```

```
#define KERNEL_LED_DEVIE_CNT 1 \,
{\tt \#define\ KERNEL\_LED\_NAME\ "kernel\_led"}
struct kernel_led_dev
    dev_t devid;
   struct cdev cdev;
    struct class *class;
   struct device *device;
    int major;
    struct device_node *nd; /* 设备节点 */
   int gpio;
                        /* gpio编号 */
};
static struct kernel_led_dev dev;
/* 设备打开时候会被调用 */
static int led_open(struct inode *inode, struct file *filp)
    filp->private_data = &dev;
   return 0;
}
/* 设备读取时候会被调用 */
static ssize_t led_read(struct file *filp, char __user *buf, size_t cnt, loff_t *offset)
    int ret;
    char kbuf[1];
   if (cnt != 1)
       return -EFAULT;
    ret = gpio_get_value(dev.gpio);
   if (ret < 0)
       return ret;
    /* 不是高就是低! */
    kbuf[0] = ret;
    ret = copy_to_user(buf, kbuf, cnt);
   if (ret)
   {
        /* 复制失败了 */
       return -EFAULT;
   }
   return 0;
}
/* 设备写入时候会被调用 */
static ssize_t led_write(struct file *filp, const char __user *buf, size_t cnt, loff_t *offset)
    int ret;
    char kbuf[1];
   if (cnt != 1)
       return -EFAULT;
   ret = copy_from_user(kbuf, buf, cnt);
   if (ret)
       /* 复制失败了 */
       return -EFAULT;
   gpio_set_value(dev.gpio, kbuf[0] ? 1 : 0);
   return 0;
/* 设备释放时候会被调用 */
static int led_release(struct inode *inode, struct file *filp)
{
   return 0;
```

```
}
 static struct file_operations fops =
         .owner = THIS_MODULE,
        .open = led_open,
        .read = led_read,
        .write = led_write,
        .release = led_release,
 };
 static int led_init(struct platform_device *mdev)
     const char *str;
    int ret;
     /* 新增的从dts获取数据的过程 */
    dev.nd = mdev->dev.of_node;
    /* I0当然也可以是一个数组 */
    dev.gpio = of_get_named_gpio(dev.nd, "led-gpio", 0);
    if (!gpio_is_valid(dev.gpio))
        /* IO是独占资源,因此可能申请失败! */
        return -EINVAL;
    }
     /* 申请IO并给一个名字 */
    ret = gpio_request(dev.gpio, "taterli-kernel-led");
    if (ret < 0)
        /* 除了返回EINVAL,也可以返回上一层传递的错误. */
        return ret;
    }
    ret = of_property_read_string(dev.nd, "default-state", &str);
    if (ret < 0)
        return -EINVAL;
    if (!strcmp(str, "on"))
        /* 设置输出和默认电平 */
        gpio_direction_output(dev.gpio, 1);
     else if (!strcmp(str, "off"))
        gpio_direction_output(dev.gpio, 0);
    else
    {
        return -EINVAL;
    /* 不需要寄存器映射了,因为有子系统! */
     /* 申请一个设备号 */
    ret = alloc_chrdev_region(&dev.devid, 0, KERNEL_LED_DEVIE_CNT, KERNEL_LED_NAME);
    if (ret)
    {
        goto alloc_fail;
     dev.major = MAJOR(dev.devid);
     dev.minor = MINOR(dev.devid);
     dev.cdev.owner = THIS_MODULE;
    cdev_init(&dev.cdev, &fops);
    ret = cdev_add(&dev.cdev, dev.devid, KERNEL_LED_DEVIE_CNT);
    if (ret)
        goto add_fail;
     dev.class = class_create(THIS_MODULE, KERNEL_LED_NAME);
     if (IS_ERR(dev.class))
        ret = PTR_ERR(dev.class);
        goto class_fail;
```

```
dev.device = device_create(dev.class, NULL, dev.devid, NULL, KERNEL_LED_NAME);
   if (IS_ERR(dev.device))
        ret = PTR_ERR(dev.class);
        goto dev_fail;
   }
    return 0;
dev_fail:
   class_destroy(dev.class);
class_fail:
   cdev_del(&dev.cdev);
   unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
alloc_fail:
    /* 这里就清爽很多了,释放10就行. */
    gpio_free(dev.gpio);
    return ret:
static int led_exit(struct platform_device *mdev)
    device_destroy(dev.class, dev.devid);
    class destroy(dev.class);
   cdev_del(&dev.cdev);
   unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
   gpio_free(dev.gpio);
   return 0;
}
/* 匹配列表 */
static const struct of_device_id led_of_match[] = {
    {.compatible = "taterli,led"},
    {}
};
static struct platform_driver led_driver = {
   .driver = {
       .name = "taterl-led", /* 即使不用也要保留一个! */
       .of_match_table = led_of_match,
   },
    .probe = led_init,
    .remove = led_exit,
};
static int init led driver init(void)
{
    return platform driver register(&led driver);
}
static void __exit led_driver_exit(void)
    platform_driver_unregister(&led_driver);
module_init(led_driver_init);
module_exit(led_driver_exit);
MODULE_AUTHOR("Taterli <admin@taterli.com>");
MODULE_DESCRIPTION("Led GPIO");
MODULE_LICENSE("GPL");
```

不过,现在代码已经好几百行了,我们有很多每次都用,而且一眼就知道很通用的代码块,他们其实完全能合并成一块,回顾一下初始化中我们干了什么.

- 1. 申请一个设备号.
- 2. 初始化/注册/添加 cdev.

- 3. 创建类.
- 4. 创建设备.

但是哪种设备不是大概这些流程啊,其实这些是设备最原始的接口函数,实际上像led,按键这些,甚至屏幕,触摸这些,都有标准,快捷的初始 化方法,但是我们要直到,用上面的四步可以创建任何字符设备,但是用简便方法,只能创建不太奇葩的设备.

接着继续看我们的写入方法,还要判断用户输入的是什么,比如1是点亮,0是灭掉,那么这个是约定吗?别人不可以用0是点亮,1是灭掉吗? 能的,为了解决这个问题,那么一类设备就应该给一类定义,先试试在用户空间操作LED,通过系统自带的GPIO驱动.

```
xilinx@pynq:/sys/class/gpio/gpiochip906$ cat label
zynq_gpio
```

可以看到ZYNQ_GPIO其实是导出了的,他实际范围是GPIO906~GPIO1023(分别对应54个MIO和64个EMIO),GPIO906是GPIO控制器的名字,为什么范围这么定义,这只能说设计一开始就这样定下来的,比如我们要操作EMIO第二GPIO,即961号IO,操作前记得在PL端预先配置,然后试试这个IO的功能,大家不妨多测试一下.

```
root@pynq:/sys/class/gpio# echo 961 > /sys/class/gpio/export
root@pynq:/sys/class/gpio# ls
export gpio961 gpiochip906 unexport
root@pynq:/sys/class/gpio# cd gpio961
root@pynq:/sys/class/gpio/gpio961# ls
active_low device direction edge power subsystem uevent value
root@pynq:/sys/class/gpio/gpio961# cat direction
in
root@pynq:/sys/class/gpio/gpio961# echo out > direction
root@pynq:/sys/class/gpio/gpio961# echo 0 > value
root@pynq:/sys/class/gpio/gpio961# echo 0 > value
```

这是个GPIO,他只有1和0两种关系,这是约定的,内核中其实也有一个专门的led-class,他除了1和0,还支持亮度,系统上也有对应的文件夹,就/sys/class/led,不妨可以进去看看,属性有不同.

```
root@pynq:/sys/class/leds/mmc0::# ls
brightness device max_brightness power subsystem trigger uevent
root@pynq:/sys/class/leds/mmc0::# cat brightness
0
root@pynq:/sys/class/leds/mmc0::# echo 255 > brightness
```

能看到,他提供更多的属性,其中有亮度,其中约定中最大亮度是255,最小亮度是0,那么就算是个渐变灯,我们也能控制了,我们实际上也要实现LED相关的函数,说了那么多,那如何把上面的gpio子系统方法改成led-class方法.

引入头文件:

```
#include <linux/leds.h>
```

字符设备相关的全部换成led classdev:

```
struct led_classdev cdev; /* Led设备 */
int gpio; /* gpio编号 */
};
```

修改初始化函数,但是不再直接写cdev,另外绑定亮度设置的函数,一般要提供两个接口,我这里都是同一个了.

```
static int led_init(struct platform_device *mdev)
{
    const char *str;
   int ret:
    /* 新增的从dts获取数据的过程 */
   dev.nd = mdev->dev.of node:
   /* I0当然也可以是一个数组 */
   dev.gpio = of_get_named_gpio(dev.nd, "led-gpio", 0);
   if (!gpio_is_valid(dev.gpio))
       /* IO是独占资源,因此可能申请失败! */
       return -EINVAL;
    /* 申请IO并给一个名字 */
   ret = gpio_request(dev.gpio, "taterli-kernel-led");
    if (ret < 0)
       /* 除了返回EINVAL,也可以返回上一层传递的错误. */
   ret = of_property_read_string(dev.nd, "default-state", &str);
   if (ret < 0)
   {
       return -EINVAL;
    if (!strcmp(str, "on"))
       /* 设置输出和默认电平 */
       gpio_direction_output(dev.gpio, 1);
    else if (!strcmp(str, "off"))
       gpio_direction_output(dev.gpio, 0);
   3
   else
   {
       return -EINVAL;
   }
   /* 不需要寄存器映射了,因为有子系统! */
    /* 申请一个设备号 */
   ret = alloc_chrdev_region(&dev.devid, 0, KERNEL_LED_DEVIE_CNT, KERNEL_LED_NAME);
   if (ret)
       goto alloc_fail;
    dev.major = MAJOR(dev.devid);
   dev.minor = MINOR(dev.devid);
    dev.cdev.owner = THIS_MODULE;
   cdev_init(&dev.cdev, &fops);
   ret = cdev_add(&dev.cdev, dev.devid, KERNEL_LED_DEVIE_CNT);
    if (ret)
   {
       goto add_fail;
   }
    dev.class = class_create(THIS_MODULE, KERNEL_LED_NAME);
   if (IS_ERR(dev.class))
       ret = PTR_ERR(dev.class);
       goto class_fail;
```

```
dev.device = device_create(dev.class, NULL, dev.devid, NULL, KERNEL_LED_NAME);
   if (IS_ERR(dev.device))
       ret = PTR_ERR(dev.class);
       goto dev_fail;
   return 0;
dev_fail:
   class_destroy(dev.class);
class_fail:
   cdev_del(&dev.cdev);
   unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
alloc_fail:
   /* 这里就清爽很多了,释放IO就行. */
    gpio_free(dev.gpio);
   return ret:
// 修改后
static int led_init(struct platform_device *mdev)
   struct kernel_led_dev *dev;
   struct led_classdev *led_cdev;
   const char *str;
   int ret;
   /* 为dev指针分配内存 */
   dev = devm_kzalloc(&mdev->dev, sizeof(struct kernel_led_dev), GFP_KERNEL);
   if (!dev)
       return -ENOMEM;
   platform_set_drvdata(mdev, dev);
    /* I0当然也可以是一个数组 */
    dev->gpio = of_get_named_gpio(mdev->dev.of_node, "led-gpio", 0);
    if (!gpio_is_valid(dev->gpio))
       /* IO是独占资源,因此可能申请失败! */
       return -EINVAL;
    /* 申请IO并给一个名字 */
   ret = gpio_request(dev->gpio, "taterli-kernel-led");
   if (ret < 0)
       /* 除了返回EINVAL,也可以返回上一层传递的错误. */
       return ret;
   }
   ret = of_property_read_string(mdev->dev.of_node, "default-state", &str);
   if (ret < 0)
       return -EINVAL;
   if (!strcmp(str, "on"))
       /* 设置输出和默认电平 */
       gpio_direction_output(dev->gpio, 1);
    else if (!strcmp(str, "off"))
       gpio\_direction\_output(dev->gpio,\ 0);
    }
    else
   {
       return -EINVAL;
    /* 初始化led_cdev变量 */
    led_cdev = &dev->cdev;
    led_cdev->name = "kernel_led";
                                                                  /* 设置设备名字 */
    led_cdev->brightness = LED_OFF;
                                                                  /* 设置LED初始亮度,LED_OFF就是0. */
```

替换注销函数为led-class方式.

```
// 修改前
static int led_exit(struct platform_device *mdev)
{
    device_destroy(dev.class, dev.devid);
    class_destroy(dev.class);
    cdev_del(&dev.cdev);
    unregister_chrdev_region(dev.devid, KERNEL_LED_DEVIE_CNT);
    gpio_free(dev.gpio);
    return 0;
}

// 修改后
static int led_exit(struct platform_device *mdev)
{
    struct kernel_led_dev *led_data = platform_get_drvdata(mdev);
    led_classdev_unregister(&led_data->cdev);
    return 0;
}
```

设置亮度函数中,我们这里用到了一个静态内敛函数,这个在内核中很常见,就是只需要传入结构体的其中一个地址,就知道结构体的首地址.

最后再把module_init和module_exit套成module_platform_driver,这样显得更加简洁,毕竟都是那两个函数.

```
// 修改前
static int __init led_driver_init(void)
{
    return platform_driver_register(&led_driver);
}
static void __exit led_driver_exit(void)
{
```

```
platform_driver_unregister(&led_driver);
}

module_init(led_driver_init);
module_exit(led_driver_exit);

// 修改后(同时删除上面两个函数!)

module_platform_driver(led_driver);
```

把没用的重复包含的头文件去掉.

```
//修改前
#include <linux/types.h>
#include <linux/kernel.h>
#include <linux/delay.h>
#include <linux/ide.h>
#include <linux/init.h>
#include <linux/module.h>
#include <linux/errno.h>
#include <linux/gpio.h>
#include <asm/mach/map.h>
#include <asm/uaccess.h>
#include <asm/io.h>
#include <linux/cdev.h>
#include <linux/of.h>
                            /* dts操作相关 */
#include ux/of_address.h> /* dts地址相关 */
#include ux/of_gpio.h> /* gpio子系统相关 */
#include <linux/platform_device.h>
#include <linux/leds.h>
// 修改后
#include <linux/module.h>
#include <linux/of_gpio.h>
#include <linux/platform_device.h>
#include <linux/leds.h>
```

删除所有传统的文件操作代码,以及全局定义的dev,因为在这里不需要我们再记录这些数据,我们在初始化时候已经devm_kzalloc了,最后文件整体就这个样子.

```
#include <linux/module.h>
#include <linux/of_gpio.h>
#include <linux/platform_device.h>
#include ux/leds.h>
struct kernel_led_dev
{
    struct led_classdev cdev; /* Led设备 */
                           /* gpio编号 */
    int gpio;
};
static\ void\ led\_brightness\_set(struct\ led\_classdev\ ^*led\_cdev,
                               enum led_brightness value)
    struct kernel_led_dev *led_data = container_of(led_cdev, struct kernel_led_dev, cdev);
    int level;
    if (value == LED_OFF)
        level = 0;
    else
        level = 1;
    gpio_set_value(led_data->gpio, level);
}
static\ int\ led\_brightness\_set\_blocking(struct\ led\_classdev\ *led\_cdev,
                                       enum led_brightness value)
    led_brightness_set(led_cdev, value);
    return 0;
static int led_init(struct platform_device *mdev)
```

```
struct kernel_led_dev *dev;
    struct led_classdev *led_cdev;
    const char *str;
   int ret;
    /* 为dev指针分配内存 */
    dev = devm_kzalloc(&mdev->dev, sizeof(struct kernel_led_dev), GFP_KERNEL);
   if (!dev)
       return -ENOMEM;
    platform_set_drvdata(mdev, dev);
    /* I0当然也可以是一个数组 */
    dev->gpio = of_get_named_gpio(mdev->dev.of_node, "led-gpio", 0);
    if (!gpio_is_valid(dev->gpio))
    {
       /* IO是独占资源,因此可能申请失败! */
       return -EINVAL;
   }
    /* 申请IO并给一个名字 */
   ret = gpio_request(dev->gpio, "taterli-kernel-led");
    if (ret < 0)
    {
       /* 除了返回EINVAL,也可以返回上一层传递的错误. */
       return ret;
   }
    ret = of_property_read_string(mdev->dev.of_node, "default-state", &str);
   if (ret < 0)
       return -EINVAL;
   }
   if (!strcmp(str, "on"))
       /* 设置输出和默认电平 */
       gpio_direction_output(dev->gpio, 1);
    else if (!strcmp(str, "off"))
       gpio_direction_output(dev->gpio, 0);
    else
    {
       return -EINVAL;
    /* 初始化led_cdev变量 */
    led_cdev = &dev->cdev;
    led_cdev->name = "kernel_led";
                                                                 /* 设置设备名字 */
                                                                 /* 设置LED初始亮度,LED_OFF就是0. */
    led_cdev->brightness = LED_OFF;
   led_cdev->max_brightness = LED_FULL;
                                                                /* 设置LED最大亮度.LED_FULL就是255,如果不是调光灯也可以写1,用户能读取这个知道该怎
                                                                 /* 亮度设置函数(不可打断) */
    led_cdev->brightness_set = led_brightness_set;
   led_cdev->brightness_set_blocking = led_brightness_set_blocking; /* 两端设置函数(可打断)*/
    /* 注册LED设备 */
   return led_classdev_register(&mdev->dev, led_cdev);
}
static int led_exit(struct platform_device *mdev)
    struct kernel_led_dev *led_data = platform_get_drvdata(mdev);
   led_classdev_unregister(&led_data->cdev);
   return 0;
}
/* 匹配列表 */
static const struct of_device_id led_of_match[] = {
    {.compatible = "taterli,led"},
static struct platform_driver led_driver = {
   .driver = {
      .name = "taterl-led",
       .of_match_table = led_of_match,
    .probe = led_init,
   .remove = led_exit,
```

```
};

module_platform_driver(led_driver);

MODULE_AUTHOR("Taterli <admin@taterli.com>");
MODULE_DESCRIPTION("Led GPIO");
MODULE_LICENSE("GPL");
```

验证过程稍微有些改变,因为我们的LED具体操作到/sys/class/leds/kernel_led了,最后还要引用一句,如果为了实现一些常见的LED功能,还可以使用内核提供的gpio-leds驱动,这里给出一个例子,写入此设备树后,可以在系统的/sys/class/leds/hello操作自己的LED,如何操作?看标准文档就行了.

```
leds {
  compatible = "gpio-leds";

hello {
    label = "hello";
    gpios = <&gpio0 55 0>;
    linux,default-trigger = "heartbeat";
    };
};
```

到现在,Linux的开发已经算入门了,其他开发也是各种platform,各种绑定对着做,但是Linux博大精深,绝对不是一两下能掌握透彻的,这是一个终生学习的过程.