# SIMPLY MICHIGAN
## INFOTAINMENT

Your vehicle specific files for completing the programming changes for your Sync 3 upgrade using FORScan are attached. **Please note that your APIM is already programmed, so its programming file is not included.** Please read the instructions fully before starting.

**You will receive a length error when loading the supplied ACM file. This is normal.** We leave the areas for your presets blank so we don't overwrite them, and this causes the error.

Use the instructions below for each attached file, selecting the appropriate module for that file. For example, an ACM file must be loaded into the ACM module. These instructions assume FORScan is already installed and activated with an extended license (or a trial extended license), and your OBD programmer is connected to your Windows laptop and configured for use with FORScan.

### Module definitions:

- APIM: Sync module
- ACM: Radio, low-end speaker amplifier, and CD player
- FCIM/HVAC: Climate control panel and HVAC control module(s)
- FCDIM: Small 4" screen, if applicable

### 4" to 8" Sync 3 Conversion FORScan Instructions

1. Install the Sync 3 hardware in your vehicle, if you have not already done so.
2. Save the attached file(s) to a location you can easily find on your laptop. You will need to open them within FORScan.
3. Turn on the vehicle's ignition. For push-button start vehicles, press the Start button without starting the engine. For keyed vehicles, turn the key to ON, not Accessory. The engine should remain off.
4. Connect FORScan to your vehicle using your OBD programmer. If FORScan asks whether you want to load a saved vehicle profile, select No. This forces FORScan to rescan the vehicle and detect the new APIM module.
5. Once connected and ready, click the Computer Chip icon on the left side of FORScan.

6. **Select APIM Module Configuration (As-Built Format), then click the Play arrow at the bottom.**

7. Allow FORScan to read the module. The current as-built programming will then appear on the screen.

8. Click Load All at the bottom of the window, then browse to and select the appropriate attached file you saved to your laptop.

9. The as-built values displayed in FORScan should update to reflect the loaded file.

10. Click Write All at the bottom of the FORScan window. Click OK if a confirmation window appears. The Sync 3 APIM will reboot. Then click the Stop button at the bottom, next to the Play button.

11. If your vehicle is equipped with SiriusXM and you are switching from a non-navigation Sync 2/3 unit to a navigation-equipped Sync 3 unit for the first time, modify the following line in ACM Module Configuration (As-Built Format), if present, to allow SiriusXM Data Services, such as SiriusXM Traffic, to function:

    Before:
    727-04-01: 0001 0255 53DE

    After:
    727-04-01: 0001 0155 53DD

    If this exact line is not present in your ACM, skip this change entirely. It does not apply to all vehicles.

    For vehicles in Canada: Use 0002 0143 41BA as the new line data instead.

12. If you are completing a 4" to 8" conversion, repeat the Load All and Write All procedure for the ACM (As-Built) and FCIM/HVAC (As-Built) modules, as applicable, using the corresponding attached files.

    Note 1: The supplied ACM file, if applicable, will display a length error when you open or load it. Ignore this specific error and continue by clicking Write All. The error occurs because the file does not include programming for the FM/AM/SiriusXM radio station presets.

    Note 2: Some vehicles require replacement of the physical HVAC module—not just the climate control button panel — for climate control to work properly after a 4" to 8" conversion. This is especially relevant when switching from manual to automatic climate control.

13. *Use FORScan to clear any APIM diagnostic trouble codes (DTCs), including those that existed before programming or appeared during the process.*

    *Some DTCs may remain in older vehicles, mainly pre-2015 models, where module firmware updates are unavailable to support newer CAN bus messages from the Sync 3 APIM.*

14. Turn the vehicle off and wait 5 minutes.

15. Turn the ignition back on, keeping the engine off. On the Sync 3 screen, open Settings → General, scroll down, and select Master Reset.

16. The Sync 3 APIM will reboot and is now ready to use.