SIMPLY MICHIGAN
INFOTAINMENT

Questions? Please contact us via email
nick@simplymichigan.co
Visit us at simplymichigan.co or scan the QR code

USB-C Hub with wireless Apple CarPlay, Android Auto and 30W Fast Charging

Thank you for your purchase! Please review the following information to ensure the proper operation of your hub.

Directions: After installing the hub, open your bluetooth settings on your phone and select the available connection, the device doesn't have a set name. Once it connects you'll be prompted to allow Apple CarPlay/Android Auto on your phone and it should automatically connect. You're all set! If you're using a bezel for this to fit in your vehicle, the bezel will be very tight, but it will fit with enough force. Insert one side all of the way in and then try the other side, then press hard on a corner and it'll eventually pop in.

This USB hub has two data channels; one channel is connected to the chip that controls the wireless Apple CarPlay and Android Auto and the other channel is connected to the lower USB-A port. When wireless Apple CarPlay or Android Auto is in use, the system is already communicating with your phone through the module. If another phone is connected to the lower USB-A port at the same time it may cause connection conflicts with the system and cause issues. **When using wireless Apple CarPlay or Android Auto please only use the upper USB-C fast charging port for charging; avoid connecting your phone to the lower USB-A port.** The lower port can be used for other devices like a USB flash drive for media playback, for example.

How does wireless Apple CarPlay and Android Auto work? Wireless functionality doesn't transfer audio and video though bluetooth. The phone initially connects to the adapter via bluetooth to pair then bluetooth is automatically disconnected when the adapter connects to your phone via WiFi; this is the main connection method to the device.

You may notice your phone being connected to a WiFi network (typically named "Sync3_xxxx), this is normal. The WiFi network name (SSID) may change occasionally as well. The hub may automatically switch WiFi channels to optimize signal quality and to reduce interference. If it ever asks for a password, the password will be 12345678. Please see our blog (Simply Connected) for updating instructions or visit our support page.