SIMPLY MICHIGAN
INFOTAINMENT

SCAN ME

Need support? Please visit our support website or contact us
https://support.simplymichigan.co or scan the QR code
Reach us at nick@simplymichigan.co

Thank you for your purchase! We greatly appreciate the business. You've helped our small business and other small businesses around the United States via our local and national supply chain. Our goal is to supply you with the best service possible without having to cut corners like our Chinese competition (or charge you double the price for it like our other larger .com competition)

Your purchase includes a 1 year warranty on all hardware from the date you receive it, unless you purchased SimplyCare, in which case the expiration of the warranty will be 3 years from the date of purchase. **The sticker on the hardware includes our internal inventory number and the VIN from the donor vehicle (if available)**. Please keep this information for your records.

Basic universal instructions are listed on the back of this page for 4" to 8" conversions as well as the programming steps. If you need a visual guide we recommend finding a video on YouTube for precise instructions for your exact model and year (not available for every model). If you need help finding a video please reach out and we can help.

SIMPLYCARE

Everyone runs into some bad luck and hardware failures do occasionally happen, it's not too late to protect yourself from an unexpected failure and future repair expenses for two extra years (for a total of 3 years). Covers full replacement if necessary. Save $10 by using coupon code 3YEARS. Scan QR or go to https://b.link/kv2tpcnq

SCAN ME

Thank you again for your support! If you have any concerns, suggestions or if you're in need of technical support please don't hesitate to reach out to us, we're always here to help. **Spreading the word about your great experience on Facebook, vehicle message boards, YouTube, Reddit, etc. is greatly appreciated and helps us immensely, you may even found out about us this way yourself. We would be very grateful for your recommendation.**

UNIVERSAL BASIC INSTRUCTIONS (4” to 8” Conversion)

1. Remove the climate/HVAC control panel surrounding your current display. Depending on your vehicle this can be extremely easy and straight forward or it might take a few extra steps. Typically there’s around 4-6 7MM bolts that you will need to remove to disconnect the bezel and/or display screen however your vehicle may differ. To get to the bolts Ford/Lincoln uses retention clips to hold most of the dash together. Giving them a good tug usually will separate them. Plastic pry tools can also be used. Before pulling the bezel away from the dash be sure to disconnect any wiring for your controls.

2. Use a 7MM socket and remove the bolts holding the screen to the vehicle. Slowly pull the screen out, reach behind the display and start disconnecting the wires. Disconnecting the battery is not necessary, just make sure that the radio is off before you disconnect it. For the main vehicle wiring harness, push in the tab on the top/middle of the harness and pull the lever back, this will pull the connector out of the APIM. For the GPS antenna and the USB cord, IF APPLICABLE, push down the clip and SLOWLY wiggle the connector back and fourth until it loosens, then remove. The GPS antenna connector is fragile and can get damaged if you use a lot of force. Depending on your conversion, you may also need to remove the ACM (cd player) so your conversion harness can connect to it.

3. Take the supplied GPS antenna (if your kit included one) and attach it somewhere inside your dash.

4. Add the included screen brackets to the new display using the provided screws and using a T8 or T15 torx bit (included).

5. Take your new Sync 3 display/APIM assembly and move it into place and reconnect all of the wiring. Add the included vehicle conversion harness and ensure everything is plugged in correctly. Depending on your vehicle, you may just have a couple of connections to make or a few. Re-install the 7MM bolts to secure the display to the vehicle. Keep the screen protector on the display until you’ve secured the display to the vehicle, the display screen is extremely fragile.

6. Re-assemble your dash, going in reverse. Remember to re-connect all wiring. Be careful with those 7MM bolts, if you drop them while trying to screw them back in you might lose them inside the dash.

7. Open your conversion accessory kit and snap together the USB hub and the hub bezel, if yours included one. Use a pry tool to pop out your old USB hub, it’s held in with retention clips. Disconnect your old USB hub and remove it.

8. Connect the supplied hub harness to your vehicle and then connect that to your new USB hub. Slide the new USB hub into your vehicle until it snaps in.

9. Turn on your vehicle and let the system boot up. It’s important to go to the SETTINGS menu, click GENERAL then scroll to the bottom and click “Master Reset”, this should wipe the slate clean (don’t worry, your programming won’t be effected) so you won’t run into any weird glitches later.

10. Enjoy your new Sync 3 infotainment system! **If you run into any issues do another master reset. Then do a soft reset by holding down the power button and the forward seek button for 5-10 seconds until the radio shuts off and restarts. If you continue to have problems please reach out to us for further assistance. Doing these resets fixes most issues after installation.**

Screen Bracket Modification

If you went the route of purchasing a standard display for your recessed display vehicle there isn't one certain way to perform the modification; and it changes for each vehicle as the brackets are different for all of them. Basically you need to get the brackets into the same position on the new display as they are on the old one. Before taking off the brackets on the old display you can mark them anywhere that they hang over the edge, etc. to help guide you lining them up on the new display. Once you get them into position you'll want to mark where the holes need to go and then drill the holes out. You'll also need to drill the holes on the other side of the bracket (that side that attaches to the vehicle) since the brackets will sit a bit wider than they normally would. You may also need to remove the guiding pins (if they're present) as they won't line up anymore. If this is needed you can drill out the backs of those pins and they should fall right out.

Other Notes

- You may receive e-mail requests asking for a review of your experience/purchase, please consider taking the time to do this, we appreciate your help. As mentioned before, spreading the word about your great experience on Facebook, vehicle message boards, YouTube, Reddit, etc. is greatly appreciated and helps us immensely, you may even found out about us this way yourself. We would be very grateful for your recommendation.

Misc Troubleshooting

- If you're seeing phantom/ghost touches on the display (if your system appears to be controlling itself) try cleaning the display really well, typically this will resolve that issue.

- If your system isn't working correctly, for any reason, try doing a soft reset followed by a master reset. Instructions are located on our website if you need help. This usually will resolve most issues that people will come across.

4" to 8" Conversions - Mustang

- If you're converting from a 4" display in a Mustang and are having issues with the hazard button working please make the following modification with FORScan
  - Open the BCM module and find line 726-29-02 and make the following changes: xxxx-xxx0-xxxx. Leave any values marked "x" alone and change the number/letter indicated
  - If that line does not exist (2020+) or if it doesn't work, change the other back to what it was originally and then try the following modification: While still in the BCM module find line 726-41-01 and change this value: x0xx-xxxx-xxxx
- To enable drive modes make the following changes in FORScan, if you get a CEL (check engine light) be sure to clear your DTC's and restart the vehicle

IPC Module	ABS (North American Vehicle)
Automatic Transmission:	**Base GT** - Line 760-02-02 Value: xxxx-3xxxx
Line: 720-06-01 Value: 6C7F-8000-18B1	**Performance GT** - Line 760-02-02 Value: xxxx-7xxxx
Manual Transmission:	**V6/Ecoboost** - Line 760-02-02 Value: 0200-117E
Line: 720-06-01 Value: 786F-0664-1897	