- 1. To configure Port B so that all 8 of its pins are set to output, the DDRB register must be configured as: 11111111
- 2. Assuming all 8 of Port D's pins have been configured as inputs, the PIND register would be used to read the individual bits of each pin.
- 3. The PORTx register is used to output data, however the DDRx register must also be set to output is that is wanted.

## Useful resources:

http://www.elecrom.com/avr-tutorial-2-avr-input-output/

http://www.avr-tutorials.com/digital/about-avr-8-bit-microcontrollers-digital-io-ports