- 631. What is meant by the term plumbo-solvent?
  - (a) The ability of water to dissolve copper
  - (b) The addition of chlorine to the water supply
  - (c) The ability of water to dissolve lead
  - (d) The use of lead-free solder fittings

632. Every passageway to an attic water heater shall have solid continuous flooring not less than

(a) 36 inches wide

(c) 60 inches wide

(b) 48 inches wide

(d) 24 inches wide