676. Pipe fitting is intended to make a change in direction, turn and offset, but their use must be planned carefully so that waste within the line has free passage, the fitting used in vertical to horizontal changes of direction is:

(a) long sweep bend

(c) wye fitting

(b) tee

(d) all of these

676. Pipe fitting is intended to make a change in direction, turn and offset, but their use must be planned carefully so that waste within the line has free passage, the fitting used in vertical to horizontal changes of direction is:

(a) long sweep bend

(c) wye fitting

(b) tee

(d) all of these