324. The distance between the trap and the vent should not be more than

(a) 5 ft

(c) 7 ft

(b) 6 ft

(d) 4 ft

324. The distance between the trap and the vent should not be more than

- (a) 5 ft
- (b) 6 ft

- (c) 7 ft
- (d) 4 ft