395. How do you connect the pump in series?

(a) Different RMP

(c) Same horsepower

(b) Same gpm

(d) Different pressure

396. The maximum fixture unit loading allowed on a 2-inch waste stack is ______.

(a) Four

(c) Sixteen

(b) Six

(d) Two