344. It is inserted into the water main and it serves as the control of the water service.

(a) Curb stop

(c) Water stop

(b) Corporation stop

(d) Meter stop

344. It is inserted into the water main and it serves as the control of the water service.

(a) Curb stop

(c) Water stop

(b) Corporation stop

(d) Meter stop