171. Where should the overflow pipe lead for the overhead tanks be installed on buildings?

(a) Soil stack

(c) Storm drain

(b) Scuppers

(d) Gutter

172. Critical love markings on a backflow prevention device or vacuum breaker are established by.

(a) Manufacturer

(c) Supplier

(b) Distributor

(d) Testing Laboratory