521. In plumbing, the unobstructed vertical distance through the free atmosphere, between the faucet supplying water and the flood-level rim of a fixture is called \_\_\_\_\_

(a) Air gap

(c) Flushing lane

(b) Airline

(d) Gooseneck

521. In plumbing, the unobstructed vertical distance through the free atmosphere, between the faucet supplying water and the flood-level rim of a fixture is called \_\_\_\_\_

(a) Air gap

(c) Flushing lane

(b) Airline

(d) Gooseneck