- 280. Why is it that the house sewer is usually the first phase of the plumbing layout that must be installed?
  - (a) As the basis of the basement elevation and plot plan of the building
  - (b) Excavation of the building may be drained during inclement weather
  - (c) To serve as a starting point for the house drain
  - (d) To be the reference point of the building elevations

- 280. Why is it that the house sewer is usually the first phase of the plumbing layout that must be installed?
  - (a) As the basis of the basement elevation and plot plan of the building
  - (b) Excavation of the building may be drained during inclement weather
  - (c) To serve as a starting point for the house drain
  - (d) To be the reference point of the building elevations