- 280. Why is it that the house sewer is usually the first phase of the plumbing layout that must be installed?
  - (a) As the basis of the basement elevation and plot plan of the building
  - (b) Excavation of the building may be drained during inclement weather
  - (c) To serve as a starting point for the house drain
  - (d) To be the reference point of the building elevations

281. What is the vertical distance between the dip and crown weir of the trap?

(a) Trap seal

(c) Leader

(b) Crown air

(d) Bleeder