- 162. What steps must be undertaken to avoid encountering airline cracks on the soldered joint of a hot water supply system when the water is turned on?
 - (a) Use a solder type that is suited for a particular fitting and pipe
 - (b) Apply heat evenly on the fitting before placing the solder on slot holes
 - (c) Thoroughly clean the joint to be soldered
 - (d) Faucets should be opened on the downstream side to relieve pressure on the line before soldering

- 162. What steps must be undertaken to avoid encountering airline cracks on the soldered joint of a hot water supply system when the water is turned on?
 - (a) Use a solder type that is suited for a particular fitting and pipe
 - (b) Apply heat evenly on the fitting before placing the solder on slot holes
 - (c) Thoroughly clean the joint to be soldered
 - (d) Faucets should be opened on the downstream side to relieve pressure on the line before soldering