676. Pipe fitting is intended to make a change in direction, turn and offset, but their use must be planned carefully so that waste within the line has free passage, the fitting used in vertical to horizontal changes of direction is:

(a) long sweep bend

(c) wye fitting

(b) tee

(d) all of these

677. What kind of plumbing tool is cheaply used for cutting cast-iron pipes, brick or stone?

(a) Cold chisel

(c) Cape chisel

(b) Diamond nose chisel

(d) Gouge