521. In plumbing, the unobstructed vertical distance through the free atmosphere, between the faucet supplying water and the flood-level rim of a fixture is called _____

(a) Air gap

(c) Flushing lane

(b) Airline

(d) Gooseneck

- 522. A piping system is designed to control and convey excess ground water to a suitable location.
 - (a) Stormwater drainage piping
 - (b) Sewer piping
 - (c) Vertical stack
 - (d) Downspout