487. At what angle do vent stacks attach to horizontal vent pipes?

(a) 90 degrees

(c) 22 ½ degrees

(b) 45 degrees

(d) 60 degrees

487. At what angle do vent stacks attach to horizontal vent pipes?

(a) 90 degrees

(c) 22 ½ degrees

(b) 45 degrees

(d) 60 degrees