- 98. Correct way to connect vent pipe on a horizontal drainage pipe.
 - (a) Vent pipe centerline taken off above the drainage centerline
 - (b) Vent pipe invert taken off below the drainage centerline
 - (c) Vent pipe taken off above the drainage centerline
 - (d) Vent pipe invert taken off above the drainage centerline

99. Another term for interceptor

(a) Basin

(c) Calorimeter

(b) Clarifier

(d) Calorifier