

### **Basic FEM for trusses (Day 1)**

Ole Sigmund and Kim Lau Nielsen

Department of Civil and Mechanical Engineering, Solid Mechanics


<u>Preparatory reading:</u> Handout Day 1 Chapter 1 in Cook et al.

202

DTU Civil and Mechanical Engineering

## DTU


### Simple truss structures (brush-up)



202

DTU Civil and Mechanical Engineering


# Simple truss structures (brush-up)



2022 DTU Civil and Mechanical Engineerin

DTU

### Simple truss structures (brush-up)



#### **Virtual Work Principle**

$$\int_{V} \{\delta \boldsymbol{\varepsilon}\}^{T} \{\sigma\} dV = \int_{S} \{\delta \mathbf{u}\}^{T} \{F\} dS + \int_{V} \{\delta \mathbf{u}\}^{T} \{\Phi\} dV + \sum_{i} \{\delta \mathbf{u}\}_{i}^{T} \{p\}_{i},$$

which has to hold for any kinematically admissible displacement variations  $\{\delta \mathbf{u}\}$ , associated strain variations  $\{\delta \epsilon\}$  and nodal displacement variations  $\{\delta D\}$ .

Or

$$\delta\Omega = \delta W$$

where

V is structural volume

S is surface area

 $\{F\}$  is surface traction

 $\{\Phi\}$  is body force

 $\{\delta \mathbf{u}\}$  is virtual displacement variation

 $\{\sigma\}$  is the stress vector

 $\{\delta \varepsilon\}$  is the virtual strain variation vector

 $\{p\}_i$  is a concentrated (nodal) load vector

Definition:

$$\delta\Omega \equiv \frac{\partial\Omega}{\partial D_i}\delta D_i$$

2022

DTII Civil and Mochanical Engineerin

## DTU

#### **Virtual Work Principle (in words)**

Or in words:

Arbitrary virtual displacement variations must lead to identical variations in internal and external work

Basically, it is and alternative way of expressing structural equilibrium (energy balance)

### VWP - 1 dof spring

$$F (KD = F)$$

Elastic (strain) energy:

$$\Omega = \frac{1}{2}KD^2$$

Work of external forces:

$$W = FD$$

 $\delta\Omega = \delta W \quad \forall \delta D (\neq 0)$ 

## DTU

#### VWP - 1 dof spring

Principle of virtual work (VWP):

$$\delta\Omega = \delta W$$
  $\forall \delta D (\neq 0)$  rain energy variation of external work

variation of strain energy

Variation of strain energy:

$$\delta\Omega = \delta(\frac{1}{2}KD^2) = KD \delta D$$

Variation of external work:


$$\delta W = \delta(FD) = F \delta D$$

Insert in VWP

$$KD\delta D = F\delta D$$
,  $\forall \delta D \ (\neq 0)$   $\Downarrow$   $KD = F$ 

#### **Virtual Work Principle (truss analysis)**

$$\int_{V} \{\delta \boldsymbol{\varepsilon}\}^{T} \{\boldsymbol{\sigma}\} dV = \int_{S} \{\delta \mathbf{u}\}^{T} \{F\} dS + \int_{V} \{\delta \mathbf{u}\}^{T} \{\boldsymbol{\Phi}\} dV + \sum_{i} \{\delta \mathbf{u}\}_{i}^{T} \{p\}_{i},$$



#### Simplifications:

LHS: Uniaxial and constant stress/strain in bar elements

$$\{\delta\varepsilon\}^T\{\sigma\} \to \delta\varepsilon \ \sigma \text{ and } \int_V \to \sum_e \int_{V_e} \to \sum_e A^e L_0^e$$

RHS: No distributed forces

$$\{F\} = \{0\}$$

RHS: No volume loads

$$\{\Phi\} = \{0\}$$

RHS: Only nodal loads

$$\sum_{i} \{\delta \mathbf{u}\}_{i}^{T} \{p\}_{i} = \{\delta D\}^{T} \{P\}$$


2022

DTU Civil and Mechanical Engineering

## DTU

#### **Virtual Work Principle (truss analysis)**

$$\sum_{e} A^{e} L_{0}^{e} \delta \varepsilon \ \sigma = \{\delta D\}^{T} \{P\} \qquad \forall \{\delta D\} \neq \{0\}$$




$$\{D\} = \{u_1 \ v_1 \ u_2 \ v_2 \ \dots \ u_N \ v_N\}^T$$

$$\{d^1\} = \{u_1 \ v_1 \ u_3 \ v_3\}^T$$


$$\{d^2\} = \{u_2 \ v_2 \ u_3 \ v_3\}^T$$

#### **Truss element**

Element geometry:



Deformed element:



DTU Civ

DTU Civil and Mechanical Engineerin

## DTU

#### **Truss element**

Initial and deformed length:

$$\begin{split} L_0 &= \sqrt{\Delta x^2 + \Delta y^2} \\ L_1 &= \sqrt{(\Delta x + \Delta u)^2 + (\Delta y + \Delta v)^2} \\ &= \sqrt{\Delta x^2 + \Delta y^2 + \Delta u^2 + \Delta v^2 + 2(\Delta x \Delta u + \Delta y \Delta v)} \\ &\approx L_0 + \frac{\Delta x \Delta u + \Delta y \Delta v}{L_0} \\ &\stackrel{\text{From 1st order Taylor-expansion assuming small displacements } (\Delta u \ll \Delta x)} \\ \end{split}$$

Elongation:

$$\Delta L = L_1 - L_0 = \frac{\Delta x \Delta u + \Delta y \Delta v}{L_0}$$

#### **Truss element**

Relative length change, i.e. strain:

$$\varepsilon = \frac{L_1 - L_0}{L_0} = \frac{\Delta x \Delta u + \Delta y \Delta v}{L_0^2}$$

Engineering/Cauchy strain - not the only choice!

Element displacement vector:

$$\{d^e\} = \{u_i \ v_i \ u_j \ v_j\}^T$$

$$\Rightarrow \qquad \varepsilon = \frac{1}{L_0^2} \{ -\Delta x - \Delta y \ \Delta x \ \Delta y \} \{ d \} = \{ B_0 \}^T \{ d \}$$

Definition of linear strain displacement vector:

$$\{B_0\} = \frac{1}{L_0^2} \{-\Delta x - \Delta y \ \Delta x \ \Delta y\}^T$$

Relates only to the initial geometry (NB! Not valid on Day 3!!)

202

DTU Civil and Mechanical Engineering

## DTU

### VWP - truss analysis

$$\sum_{e} A^{e} L_{0}^{e} \delta \varepsilon \ \sigma = \{ \delta D \}^{T} \{ P \}$$

Strain-displacement relation

$$\delta \varepsilon = \{B_0\}^T \{\delta d\}$$

Hookes' law (one dimension):

$$\sigma = E\varepsilon = E\{B_0\}^T\{d\}$$

Insert in LHS of VWP:

$$\sum_{e} A^{e} L_{0}^{e} \delta \varepsilon \ \sigma = \sum_{e} A^{e} L_{0}^{e} \{B_{0}\}^{T} \{\delta d\} E^{e} \{B_{0}\}^{T} \{d\}$$

$$= \sum_{e} \{\delta d\}^{T} \left[ E^{e} A^{e} L_{0}^{e} \{B_{0}\} \{B_{0}\}^{T} \right] \{d\}$$

$$= \sum_{e} \{\delta d\}^{T} [k^{e}] \{d\} = \{\delta D\}^{T} \left( \sum_{e} [k^{e}] \right) \{D\}$$

$$= \{\delta D\}^{T} [K] \{D\}$$

VWP in discretized form:

$$\{\delta D\}^T [K] \{D\} = \{\delta D\}^T \{P\}, \quad \forall \{\delta D\}$$

$$\downarrow \downarrow$$

$$[K] \{D\} = \{P\}$$

Local and global stiffness matrices

$$[k^e] = E^e A^e L_0^e \{B_0\} \{B_0\}^T$$
  
 $[K] = \sum_e [k^e]$ 

2022 DTII Civil and Mechanical Engineer

## Element stiffness matrix

Element stiffness matrix for bar element:

$$[k^e] = E^e A^e L_0^e \{B_0\} \{B_0\}^T$$

$$= \frac{E^e A^e}{(L_0^e)^3} \begin{bmatrix} \Delta x^2 & \Delta x \Delta y & -\Delta x^2 & -\Delta x \Delta y \\ \Delta x \Delta y & \Delta y^2 & -\Delta x \Delta y & -\Delta y^2 \\ -\Delta x^2 & -\Delta x \Delta y & \Delta x^2 & \Delta x \Delta y \\ -\Delta x \Delta y & -\Delta y^2 & \Delta x \Delta y & \Delta y^2 \end{bmatrix}$$

In code use short expression for clarity and compactness!

#### **Global stiffness matrix**


#### Assembly of element matrices:

$$[k^{1}] = \begin{bmatrix} k_{11}^{1} & k_{12}^{1} & k_{13}^{1} & k_{14}^{1} \\ k_{21}^{1} & k_{22}^{1} & k_{23}^{1} & k_{24}^{1} \\ k_{31}^{1} & k_{32}^{1} & k_{33}^{1} & k_{34}^{1} \\ k_{31}^{1} & k_{32}^{1} & k_{33}^{1} & k_{34}^{1} \end{bmatrix}$$

$$[k^{2}] = \begin{bmatrix} k_{11}^{2} & k_{12}^{2} & k_{13}^{2} & k_{14}^{2} \\ k_{21}^{2} & k_{22}^{2} & k_{23}^{2} & k_{24}^{2} \\ k_{31}^{2} & k_{32}^{2} & k_{33}^{2} & k_{34}^{2} \\ k_{21}^{2} & k_{22}^{2} & k_{23}^{2} & k_{24}^{2} \end{bmatrix}$$

$$[K] = \sum_{e} [k^{e}] = [k^{1}] + [k^{2}] =$$

$$\begin{bmatrix} k_{11}^{1} & k_{12}^{1} & 0 & 0 & k_{13}^{1} & k_{14}^{1} \\ k_{21}^{1} & k_{22}^{1} & 0 & 0 & k_{23}^{1} & k_{24}^{2} \\ 0 & 0 & k_{21}^{2} & k_{22}^{2} & k_{23}^{2} & k_{24}^{2} \\ 0 & 0 & k_{21}^{2} & k_{22}^{2} & k_{23}^{2} & k_{24}^{2} \\ k_{31}^{1} & k_{32}^{1} & k_{31}^{2} & k_{32}^{2} & k_{33}^{1} + k_{33}^{2} & k_{34}^{1} + k_{44}^{2} \\ k_{41}^{1} & k_{42}^{1} & k_{41}^{2} & k_{41}^{2} & k_{42}^{2} & k_{43}^{1} + k_{43}^{2} & k_{44}^{1} + k_{44}^{2} \end{bmatrix}$$



022 DTU Civ

DTU Civil and Mechanical Engineering


## DTU

### **Imposing Boundary conditions**

Solve FE problem:

$$[K]\{D\} = \{P\}$$

- Elimination of equations
- Method of 0's and 1's
- Penalty method
- Lagrangian multipliers



#### Enforcing BC's with method of 0's and 1's

Enforce 
$$D_1 = D_2 = D_3 = D_4 = 0$$

$$\begin{bmatrix} 1 & 0 & 0 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & k_{33}^1 + k_{33}^2 & k_{34}^1 + k_{34}^2 \\ 0 & 0 & 0 & 0 & k_{43}^1 + k_{43}^2 & k_{44}^1 + k_{44}^2 \end{bmatrix} \begin{bmatrix} D_1 \\ D_2 \\ D_3 \\ D_4 \\ D_5 \\ D_6 \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ 0 \\ P_5 \\ P_6 \end{bmatrix}$$

Can be extended to  $D_i \neq 0$  (see Cook 13.2)

202

DTU Civil and Mechanical Engineerin

## Enforcing BC's with penalty method

$$\begin{bmatrix} K_{11} & K_{12} & K_{13} & K_{14} & K_{15} & K_{16} \\ K_{21} & K_{22} & K_{23} & K_{24} & K_{25} & K_{26} \\ K_{31} & K_{32} & K_{33} & K_{34} & K_{35} & K_{36} \\ K_{41} & K_{42} & K_{43} & K_{44} & K_{45} & K_{46} \\ K_{51} & K_{52} & K_{53} & K_{54} & K_{55} & K_{56} \\ K_{61} & K_{62} & K_{63} & K_{64} & K_{65} & K_{66} \end{bmatrix} \begin{bmatrix} D_1 \\ D_2 \\ D_3 \\ D_4 \\ D_5 \\ D_6 \end{bmatrix} = \begin{bmatrix} P_1 \\ P_2 \\ P_3 \\ P_4 \\ P_5 \\ P_6 \end{bmatrix}$$

Enforce 
$$D_1 = D_4 = 0$$

$$\begin{bmatrix} K_{11} + \infty & K_{12} & K_{13} & K_{14} & K_{15} & K_{16} \\ K_{21} & K_{22} & K_{23} & K_{24} & K_{25} & K_{26} \\ K_{31} & K_{32} & K_{33} & K_{34} & K_{35} & K_{36} \\ K_{41} & K_{42} & K_{43} & K_{44} + \infty & K_{45} & K_{46} \\ K_{51} & K_{52} & K_{53} & K_{54} & K_{55} & K_{56} \\ K_{61} & K_{62} & K_{63} & K_{64} & K_{65} & K_{66} \end{bmatrix} \begin{pmatrix} D_1 \\ D_2 \\ D_3 \\ D_4 \\ D_5 \\ D_6 \end{pmatrix} = \begin{pmatrix} P_1 \\ P_2 \\ P_3 \\ P_4 \\ P_5 \\ P_6 \end{pmatrix}$$

In pratice:  $\infty$  = large number (e.g. 10<sup>8</sup> times max( $K_{ii}$ ))

Easy to extend to  $D_i \neq 0$ 

#### Solving the linear equations

Getting displacements:

$$[K]_{corr}\{D\} = \{P\}_{corr}$$

Solution methods:

- · Gauss-elimination using factorization
- Iterative methods

Fast methods:

• Cholesky factorization (Matlab: D=K\P)

202

TH Civil and Mechanical Engineerin

## DTU

### **Derived quantities**

Element strain:  $\varepsilon = \{B_0\}^T \{d\}$ 

Element stress:  $\sigma = E\varepsilon$ 

Element forces:  $N = \sigma A$ 

Reaction forces:  $\{R\}_{reaction} = [K]\{D\} - \{P\} = \sum_e \{B_0\} N^e L_0^e - \{P\}$  Cheaper !

### **General FEM procedure**

- 0) Discretize domain into a finite # of elements (many ways the more elements the better)
- 1) Node and element numbering
- 2) Build load vector {P}
- 3) Calculate  $[k^e]$  and assemble [K]
- 4) Enforce BC's
- 5) Solve for {D}
- 6) Compute  $\varepsilon$ ,  $\sigma$ ,  $N \dots$  (interpolation of solutions between nodes) -> u
- 7) Plot and evaluate results

202

TU Civil and Mechanical Engineering

## DTU

#### **Today**

- Download matlab template + example files from DTU Learn
- Add basic FEM procedure to fea.m remember always to keep copies of things that work!
- Work on exercises 1.1 and 1.2 (see them as guidelines for what kind of questions you will get in the first assignment).
- Do competition 1 (obligatory, hand-in Monday midnight!)
- Work on \*-exercises 1.3-1.6 (voluntary)

Being able to solve standard problems defined in 1.1-1.2 for complex and realistic structures and report and discuss the results perfectly is sufficient to get top grades

\*-exercises are for fun, further insight and may help in grade decision

#### **Exercises**

Edit the example 1.m file such that you can model the 9-bar truss structure shown in Figure 1.3.




Figure 1.3: A 9-bar truss structure.

Modify and expand the subroutines in "fea" to find displacements, strains and stresses for the truss structures in Fig. 1.2 and Fig. 1.3. Steps in the program development:

. . .

Check the results obtained by running the example from Fig. 1.3 with a simple hand-calculation for support reactions and element forces (calculate analytical element forces in at least 3 elements). **Hints:** In the FE-program, the support reactions may be found by calculating the residual (1.10) without inserting boundary conditions.

202

DTU Civil and Mechanical Engineering

## DTU

#### **Exercises**

#### Exercise 1.2

Use the interactive preprocessor program "FlExtract" (download it from the course web-page) to generate a large, more complex truss structure. Draw elements in tension with blue, elements in compression with red and non-loaded elements with green.

#### **Handout Code**

```
close all
%--- Input file ---- example1
                     % Input file
% Input file
%test1
\label{eq:neqn} \begin{split} &\text{Rest:} \\ &\text{neqn} = \text{size}(X,1) * \text{size}(X,2) ; &\text{% Number of equations} \\ &\text{% Number of elements} \end{split}
Kmatr=zeros(negn,negn);
                                                    % Stiffness matrix
                              % Force vector
% Displacement vector
P=zeros(neqn,1);
D=zeros(neqn,1);
                                              % Residual vector
% Element strain vector
% Element stress vector
R=zeros(neqn,1);
strain=zeros(ne,1);
stress=zeros(ne,1);
 %--- Calculate displacements -----
[P]=buildload(X,IX,ne,P,loads,mprop); % Build global load vector
 [Kmatr]=buildstiff(X,IX,ne,mprop,Kmatr); % Build global stiffness matrix
[Kmatr, P] = enforce (Kmatr, P, bound);
                                                   % Enforce boundary conditions
                                                    % Solve system of equations
[strain,stress]=recover(mprop,X,IX,D,ne,strain,stress); % Calculate element
                                                                   % stress and strain
PlotStructure (X, IX, ne, neqn, bound, loads, D, stress)
                                                                  % Plot structure
```

- 0) Discretize domain into a finite # of elements (many ways the more elements the better)
- 1) Node and element numbering
- 2) Build load vector {P}
- 3) Calculate  $[k^e]$  and assemble [K]
- 4) Enforce BC's
- 5) Solve for {D}
- 6) Compute  $\varepsilon$ ,  $\sigma$ ,  $N\dots$  (interpolation of solutions between nodes) -> u
- 7) Plot and evaluate results


022 DTU Civil and Mechanical Engineering

## DTU

#### **Initial input file**

```
% File example1.m, DAY1, modified 3/9 by OS
% Example: 3-bar truss
% No. of Nodes: 3
% No. of Elements : 3
1.00 0.00 ];
% Topology matrix IX(node1,node2,propno),
IX = [ 1 3 1 1 1 2 1
      2 3 1];
% Element property matrix mprop = [ E A ],
mprop = [ 1.0 1.0 ];
% Prescribed loads mat(node,dof,force)
loads = [ 3 2 -0.01 ];
% Boundary conditions mat(node,dof,disp)
bound = [ 1 1 0.0
1 2 0.0
         2 1 0.0];
% Control Parameters
plotdof = 6;
```

#### Todays goal!



DTU Civil and Mechanical Engineering


demo.m demo.m

#### **Competition 1**

Here is a competition: Who can make the stiffest truss structure? This corresponds to the truss structure with the smallest displacement (in the direction of the load) where the load is applied! 1

Rules: The truss structure should fit into the grey domain shown below. Supports may be used anywhere on the lower edge, whereas the position and size of the load are fixed. The bar areas and Young's moduli are fixed to A=1and E = 1, respectively. The maximum total length of bar elements is 6 and you may use as many hinges and elements as you want.

Create an input file called "group#.m" (where # is your group number) and mail it to Kim (knia@dtu.dk) by Monday, September 5th (at midnight). The teachers will evaluate the proposals and announce the prize-winner in the next



-0.001 -0.002 -0.003 -0.004 -0.005

-0.007 -0.008

Name -

Command History

<sup>&</sup>lt;sup>1</sup>The submission (not the ranking!) is part of the evaluation of the first report in the course!

## Groups Groups

- Form groups of two:
  - -Team up with partner with similar time availability and ambitions
  - -If no programming experience: find partner who has!
  - -If no solid mechanics experience: find partner who has!

022 DTU Civil and Mechanical Engineeri

### Computer exercises

Byg. 421 Grp. rum 002 EDB 010 EDB 003 EDB 014 Grp. rum Building 421 013 EDB 018 Aud 71 Aud 72

- Distribute in computer rooms
- Organize groups
- Read notes/exercises
- Use notes, book, brain, other students then teachers ...

Good luck and have fun!!

022 DTU Civil and Mechanical Engineeri