




Combos LH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Tab switching

T1-T4 → Alt Tab →
T2-T5 → Ctrl Tab →
T3-T6 → Win Tab →

Shift / caps

T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Gaming layer
T1-T2-T3 → Base layer reset

Combos (either side)

Tab forward

LT1-RT3 → Ctrl Tab →
LT1-RT2 → Alt Tab →
LT1-RT1 → Win Tab →

Tab reverse

LT2-RT3 → Ctrl Tab ←
LT2-RT2 → Alt Tab ←
LT2-RT1 → Win Tab ←

Shift / caps

LT3-RT3 → Shift (sticky)
LT3-RT2 → Caps Word
LT3-RT1 → Caps Lock

(Default combo set A)

Combos RH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Modifier chords

T1-T4 → Hyper (Shift-Ctrl-Alt-Win)
T2-T5 → Meh (Shift-Ctrl-Alt)
T3-T6 → Turbo (Shift-Ctrl)

Shift / caps


T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Typing layer
T1-T2-T3 → Base layer reset

Layer Activations (Hold)

Cursor
 Number **1 2 3**
 Function
 System
 Mouse
 Symbol
 Emoji
 World
 Lower



Combos LH

Sticky keys

T2-T3 → Globe (sticky)

T1-T2 → AltGr (sticky)

Tab switching

T1-T4 → Alt Tab →

T2-T5 → Ctrl Tab →

T3-T6 → Win Tab →

Shift / caps

T1-T5 → Shift (sticky)

T4-T5 → Caps Word

T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer

C1R5-C2R6 → Gaming layer

T1-T2-T3 → Base layer reset

Combos (either side)

Tab forward

LT1-RT3 → Ctrl Tab →

LT1-RT2 → Alt Tab →

LT1-RT1 → Win Tab →

Tab reverse

LT2-RT3 → Ctrl Tab ←

LT2-RT2 → Alt Tab ←

LT2-RT1 → Win Tab ←

Shift / caps

LT3-RT3 → Shift (sticky)

LT3-RT2 → Caps Word

LT3-RT1 → Caps Lock

(Default combo set A)

Combos RH

Sticky keys

T2-T3 → Globe (sticky)

T1-T2 → AltGr (sticky)

Modifier chords

T1-T4 → Hyper (Shift-Ctrl-Alt-Win)

T2-T5 → Meh (Shift-Ctrl-Alt)

T3-T6 → Turbo (Shift-Ctrl)

Shift / caps

T1-T5 → Shift (sticky)

T4-T5 → Caps Word

T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer

C1R5-C2R6 → Typing layer

T1-T2-T3 → Base layer reset

Layer Activations (Hold)

Cursor
Number 1 2 3

Function

System


Mouse

Symbol

Emoji

World

Lower



Combos LH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Tab switching

T1-T4 → Alt Tab →
T2-T5 → Ctrl Tab →
T3-T6 → Win Tab →

Shift / caps

T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Gaming layer
T1-T2-T3 → Base layer reset

Combos (either side)

Tab forward

LT1-RT3 → Ctrl Tab →
LT1-RT2 → Alt Tab →
LT1-RT1 → Win Tab →

Tab reverse

LT2-RT3 → Ctrl Tab ←
LT2-RT2 → Alt Tab ←
LT2-RT1 → Win Tab ←

Shift / caps

LT3-RT3 → Shift (sticky)
LT3-RT2 → Caps Word
LT3-RT1 → Caps Lock

(Default combo set A)

Combos RH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Modifier chords

T1-T4 → Hyper (Shift-Ctrl-Alt-Win)
T2-T5 → Meh (Shift-Ctrl-Alt)
T3-T6 → Turbo (Shift-Ctrl)

Shift / caps


T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Typing layer
T1-T2-T3 → Base layer reset

Layer Activations (Hold)

Cursor
Number 1 2 3
Function (x)
System
Mouse
Symbol
Emoji
World
Lower



Combos LH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Tab switching

T1-T4 → Alt Tab →
T2-T5 → Ctrl Tab →
T3-T6 → Win Tab →

Shift / caps

T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock

Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Gaming layer
T1-T2-T3 → Base layer reset

Combos (either side)

Tab forward

LT1-RT3 → Ctrl Tab →
LT1-RT2 → Alt Tab →
LT1-RT1 → Win Tab →

Tab reverse

LT2-RT3 → Ctrl Tab ←
LT2-RT2 → Alt Tab ←
LT2-RT1 → Win Tab ←

Shift / caps

LT3-RT3 → Shift (sticky)
LT3-RT2 → Caps Word
LT3-RT1 → Caps Lock

(Default combo set A)

Combos RH

Sticky keys

T2-T3 → Globe (sticky)
T1-T2 → AltGr (sticky)

Modifier chords

T1-T4 → Hyper (Shift-Ctrl-Alt-Win)
T2-T5 → Meh (Shift-Ctrl-Alt)
T3-T6 → Turbo (Shift-Ctrl)

Shift / caps


T1-T5 → Shift (sticky)
T4-T5 → Caps Word
T2-T6 → Caps Lock


Layer access

T5-T6 → Typing layer
C1R5-C2R6 → Typing layer
T1-T2-T3 → Base layer reset

Layer Activations (Hold)

Cursor
 Number **1 2 3**
 Function
 System
 Mouse
 Symbol
 Emoji
 World
 Lower






Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)


Note

ZMK macros may require additional software for interpretation
See 'Unicode and Emoji' section in README.md




Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)

- (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)

-  (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)




Layer Activation (Hold)


- (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)



Layer Activation (Hold)

- (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)






Layer Activation (Hold)

- (Hold) → Activate layer
- (Release) → Deactivate layer
- (Tap) → Unlock (if layer is locked)

Note

ZMK macros may require additional software for interpretation
See 'Unicode and Emoji' section in README.md



Hold or tap sticky modifiers on right half to choose characters (referenced in the Legend) from the clusters on the left half.