



ESP32 Programmer




Observations:

This is the USB ESP32 programmer used to flash ESP32 boards via UART. Boot & Enable options are available in ESP32 uC documentation.

Test Pins



PWR References



Author: Nicolae-Andrei Vasile

Sheet: /
File: ESP32-PLC-programmer.kicad_sch

Title: ESP32 Programmer

Size: A4 Date: 2023-12-01
KiCad E.D.A. kicad 7.0.10-7.0.10-ubuntu20.04.1

Rev: A
Id: 1/1