


# Making a PLA Sheet

How to use the PLA chips to make a flat thin sheet that can be cut in the Water Jet.


Written By: Elizabeth Marie Rand



# **TOOLS:**

- Toaster Oven (1)
- Baking Pan (1)
- Oven Mitt or Welding Glove (1)

## Step 1 — Calculating PLA Mass



- In order to get a PLA sheet with the desired thickness, we must use a specific amount of PLA shavings. Keep in mind a few things: PLA density is 1.24 gcm<sup>3</sup>, our tray is 31.115 cm x 22.542 cm, and a good sheet thickness is 0.3 cm.
- Use these formulas to calculate PLA mass needed:
  - volume = length of tray \* width of tray \* desired sheet thickness
  - mass = PLA density \* volume
- So, for this tray the PLA volume needed would be 210.42 cm<sup>3</sup> and the desired mass of PLA needed would be 260.92 grams.

# **Step 2** — **Preparing and Baking**







- Preheat the toaster oven to 175° C on 'bake'.
- Measure the mass of PLA by zero-ing the scale with a cup on it, and then adding the PLA until it reaches the desired mass.
- Pour the PLA onto the baking tray and spread it evenly.
- Once the oven is preheated, place the tray into it. It bakes for 2 hours.

#### Step 3 — Flipping the PLA Sheet







- After 2 hours, carefully remove the baking tray from the oven and set it down somewhere flat and safe.
- Wait around 20 minutes for it to cool, and then remove the PLA sheet from the baking tray.
  - This may take some effort but be sure not to break or bend the PLA sheet.
- Flip the PLA sheet over in the baking tray, and bake it in the oven for another 1 hour on 175° C.

## Step 4 — Removing the Sheet



- When the 1 hour is up, carefully take the baking tray out of the oven.
  Place it somewhere flat and safe again.
- Let it cool for 20 minutes and then remove the PLA sheet from the pan again.

Congratulations! You have made a PLA sheet.